SIEMENS

SINUMERIK 840D sl

CNC: ShopMill

Commissioning Manual

Valid for

Control SINUMERIK 840D sl/840DE sl

Software	Version
NCU system software for	
SINUMERIK 840D sl/840DE sl	1.5
with ShopMill	7.5

01/2008	Edition
01/2000	Laition

Hardware	1
Supplementary Conditions	2
Reserved Functions	3
Commissioning	4
PLC Program	5
Signal Description	6
Machine Data	7
Tool Management	8
Additional Functions	9
Customer–Specific Operator Interface	10
Miscellaneous	11
Abbreviations	Α
Index	В

SINUMERIK[®] documentation

Printing history

Brief details of this edition and previous editions are listed below.

The status of each edition is shown by the code in the "Remarks" columns.

Status code in the "Remarks" column:

- A New documentation.
- **B**.... Unrevised reprint with new Order No.
- C Revised edition with new status.

Edition	Order No.	Remarks
10/1997	6FC5 297–2AD80–0BP0	Α
11/1998	6FC5 297–2AD80–0BP1	С
03/1999	6FC5 297–5AD80–0BP0	С
08/2000	6FC5 297–5AD80–0BP1	С
12/2001	6FC5 297–6AD80–0BP0	С
08/2003	6FC5 297–6AD80–0BP1	С
11/2003	6FC5 297–6AD80–0BP2	С
02/2005	6FC5 297–6AD80–0BP3	С
08/2005	6FC5 397–4AP10–0BA0	С
11/2006	6FC5 397–4AP10–1BA0	С
01/2008	6FC5 397–4AP10–2BA0	С

Trademarks

All names identified by [®] are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of liability

We have checked that the contents of this document correspond to the hardware and software described. Since deviations cannot be precluded entirely, we cannot guarantee full agreement. The information given in this publication is reviewed at regular intervals and any corrections that might be necessary are made in the subsequent editions.

Further information is available in the Internet under: http://www.siemens.com/motioncontrol

This publication was produced with Interleaf V 7

© Siemens AG 2008

Other functions not described in this documentation might be executable in the control. However, no claim can be made regarding the availability of these functions when the equipment is first supplied or in the event of servicing.

We have checked that the contents of this document correspond to the hardware and software described. Nevertheless, differences might exist and therefore we cannot guarantee that they are completely identical. The data in this document is regularly checked and the necessary corrections are included in subsequent editions. Suggestions for improvement are also welcome.

Subject to change without prior notice.

Order No. 6FC5 397–4AP10–2BA0 Printed in the Federal Republic of Germany Siemens-Aktiengesellschaft

Preface

SINUMERIK documentation	 The SINUMERIK documentation is organized in three parts: General documentation User documentation Manufacturer/Service documentation A documentation overview with the available languages, updated monthly, can be found on the Internet under: http://www.siemens.com/motioncontrol Follow the menu items -> "Support" -> "Technical Documentation" -> "Documentation Overview".
	You can find information about training courses on offer and about the FAQs (frequently asked questions) on the Internet under: http://www.siemens.com/motioncontrol under "Support".
Target group	The present documentation is directed at the manufacturer of vertical process- ing centers or universal milling machines with SINUMERIK 840D sl, and pro- vides the information required for the configuration and commissioning of Shop- Mill.
Standard scope	This document provides information about the control system design and the interfaces of the individual components. In addition, the commissioning procedure of ShopMill with SINUMERIK 840D sl is described.
	For detailed information about individual functions, function assignment and performance data of individual components, please refer to the appropriate doc- ument for the subject concerned (e.g. manuals, description of functions etc.).
	User-oriented activities such as the creation of parts programs and control operating procedures are described in details in separate documents.
	Further descriptions of tasks to be performed by the machine tool manufacturer are also available for the standard SINUMERIK 840D sl. We may refer to them in this documentation if appropriate.
	This documentation only describes the functionality of the standard version. Additions or revisions made by the machine manufacturer are documented by the machine manufacturer.
	Other functions not described in this documentation might be executable in the control. However, no claim can be made regarding the availability of these functions when the equipment is first supplied or in the event of servicing.
	Further, for the sake of simplicity, this documentation does not contain all de- tailed information about all types of the product and cannot cover every conceiv- able case of installation, operation or maintenance.

Technical Support	If you have any technical questions, please contact our hotline:		
	Europe/Africa		
	Tel.: +49 (0) 180 Fax: +49 (0) 18 Internet: http://w) 5050–222) 5050–223 ww.siemens.com/automation/support–request	
	America		
	Tel.: +1 (0) 423 Fax: +1 (0) 423 E–mail: mailto:t	262 2522 262 2200 echsupport.sea@siemens.com	
	Asia/Pacific reg	ion	
	Tel.: +86 (0) 100 Fax: +86 (0) 10 E–mail: mailto:t	64 719 990 64 747 474 echsupport.asia@siemens.com	
	Note		
	Country–specifi Internet at: http://www.siem	c telephone numbers for technical support are provided on the ens.com/automation/service&support	
Questions about this	For questions o fax or e–mail to	n the documentation (suggestions, corrections), please send a the following address:	
documentation	Fax: +49 (0) 9131– 98 63315 E-mail: mailto:docu.motioncontrol@siemens.com		
	You can find a f	ax template in the appendix to this document.	
SINUMERIK Internet address	http://www.siem	ens.com/sinumerik	
Search guides	The alarms of S	INUMERIK 840D sI can be found in	
	References:	/DAsl/ Diagnostics Manual	
	For further usef refer to	ul information on commissioning and troubleshooting, please	
	References:	/FB/, D1, "Diagnostics Tools"	

Notes

The following symbols with special significance are used in the documentation:

Note

This symbol always appears in the document where further information is provided.

Safety information

This manual contains information which you must observe in order to ensure your own personal safety, as well as to avoid material damage. Notes relating to your safety are highlighted in the manual by means of a warning triangle; no warning triangle appears in conjunction with notes relating to material damage. Depending on the hazard level, warnings are indicated in a descending order as follows:



Danger

indicates that death or serious injury **will** result if proper precautions are not taken.



Warning

indicates that death or serious injury **may** result if proper precautions are not taken.



Caution

with a safety alert symbol, indicates that minor personal injury **may** result if proper precautions are not taken.

Caution

without a safety alert symbol, indicates that property damage **can** result if proper precautions are not taken.

Notice

indicates that an undesirable outcome or state **may** arise if the relevant notes are not observed.

If multiple levels of hazards can occur, the warning is always displayed with the highest possible level. If a warning notice with a safety alert symbol is to indicate physical injury, the same warning may also contain information about damage to property.

Qualified
personnelSetup and operation of the device/equipment/system in question must only be
performed using this documentation. Only qualified personnel should be al-
lowed to commission and operate the device/system. For the purpose of the
safety information in this documentation, a "qualified person" is someone who is
authorized to energize, ground, and tag equipment, systems, and circuits in
accordance with established safety procedures.Intended usePlease note the following:



Warning

This equipment is only allowed to be used for the applications described in the catalog and in the technical description, and only in conjunction with non–Siemens equipment and components recommended by Siemens. Correct, reliable operation of the product required proper transport, storage, positioning and assembly, as well as careful operation and maintenance.

Unit of measurement

In this manual, the units of the parameters are always indicated as metric values. The equivalent imperial units are shown in the table below.

Metric	Inch
mm	in
mm/tooth	in/tooth
mm/min	in/min
mm/rev	in/rev
m/min	ft/min

Contents

1	Hardware		
2	Supplem	entary Conditions	2-13
3	Reserved Functions		
4	Commis	sioning	4-17
	4.1	Prerequisites	4-17
	4.2 4.2.1 4.2.2 4.2.3 4.2.4 4.2.5 4.2.6 4.2.7	First commissioning . Sequence . Installation of ShopMill on NCU (HMI Embedded sl) . Installing ShopMill on PCU 50.3 . PLC commissioning . NCK commissioning . Display machine data . Acceptance report .	4-18 4-20 4-20 4-21 4-22 4-24 4-24
5	PLC Pro	gram	5-25
	5.1	Structure of the PLC program	5-25
	5.2	Example source files	5-25
	5.3	Standard interface signals for/from ShopMill	5-26
6	Signal D	escription	6-27
	6.1	HMI interface DB19	6-27
	6.2	HMI interface DB21	6-30
	6.3 6.3.1 6.3.2	Overview of the former ShopMill interface Signals to ShopMill (input signals) Signals from ShopMill (output signals)	6-31 6-31 6-33
7	Machine	Data	7-37
	7.1	NCK machine data for ShopMill	7-37
	7.2 7.2.1 7.2.2	Display machine data for ShopMill Overview of machine data display Description of display machine data	7-40 7-40 7-44
8	Tool Mar	nagement	8-67
	8.1	Overview of functions	8-67
	8.2	Commissioning sequence	8-70
	8.3 8.3.1 8.3.2 8.3.3	Commissioning in NCK Entry of NCK machine data Description of NCK machine data Creating and loading the configuration file	8-71 8-71 8-73 8-79

	8.4 8.4.1	Commissioning in the PLC Example for FC 100 and FB 110	8-85 8-87
	8.4.2	Signal description	8-89
	8.5	Display machine data	8-96
	8.6	Tool change cycle	8-97
	8.7	Manual tools	8-100
	8.8	Activating the spindle, coolant, and tool-specific functions	8-101
	8.9 8.9.1 8.9.2	Modifying texts for tool–specific functions ShopMill on NCU (HMI Embedded sl) PCU 50.3	8-103 8-103 8-105
	8.10 8.10.1 8.10.2 8.10.3 8.10.4 8.10.5 8.10.6	Configuring the operator interface Integrating additional list Configuring lists Creating the configuration file Adapting individual parameters Defining texts for the magazine locations on the intermediate buffer Designating a load magazine in the tool list sorted according	8-107 8-107 8-108 8-109 8-114 8-115
	8.10.7	Define texts	8-116 8-117
	8.11	Reading in tool data	8-120
9	Addition	al Functions	9-125
	9.1 9.1.1 9.1.2	Measuring cycles Product brief Display machine data measuring cycles	9-125 9-125 9-126
	9.2 9.2.1	Network link	9-133 9-133
	9.3 9.3.1 9.3.2	Cylinder surface transformation Function Example of how to set an axis configuration	9-134 9-134 9-135
	9.4	Swivel heads and tables	9-138
	9.5	Multiple clamping	9-139
	9.6	Measuring cycle support in the G code editor	9-141
10	Custome	r–Specific Operator Interface	10-143
	10.1	Configuring the customized boot screen	10-143
	10.2 10.2.1 10.2.2 10.2.3	Configuring the custom screenTransferring cycles to the machining planLinking cycles into the machining planIntegrating measuring cycles	10-144 10-148 10-149 10-151
	10.3 10.3.1	ShopMill Open (PCU 50.3)Basic menu bar	10-152 10-152
	10.4 10.4.1	User status display Configuring the user status display	10-153 10-154
	10.5	OP hotkeys, PLC keys	10-156

11	Miscella	aneous	11-157
	11.1 11.1.1 11.1.2 11.1.3 11.1.4 11.1.5	Access protection via password and keyswitch General Password Keyswitch settings Machine data for protection levels Operator interface for ShopMill on the NCU (HMI Embedded sl)	11-157 11-157 11-159 11-160 11-161 11-163
	11.2	ISO dialects	11-164
	11.3	Spindle control	11-165
	11.4	Analog spindles	11-166
	11.5	Automatically generated programs	11-167
	11.6	Version display	11-168
	11.7	Action log	11-169
	11.8 11.8.1 11.8.2	Mold making Commissioning Data storage, data transfer	11-170 11-170 11-172
Α	Abbrevi	ations	A-173
в	Index .		Index-175

Space for your notes

Hardware

System configuration	The hardware of SINUMERIK 84	The hardware configuration for ShopMill corresponds to the standard for SINUMERIK 840D sl.		
	References:	/IDsl/,	Commissioning CNC: NCK, PLC, drive, SINUMERIK 840D sl;	
		/GDsl/,	Device Manual NCU,	

Table 1-1 Basic components

Basic components	Order No.	Comment
TCU	6FC5312-0DA00-0AA0	
NCU 710.1	6FC5371-0AA10-0AA0	CNC: 3 MB; PLC: 128 KB
NCU 710.2	6FC5371-0AA10-0AA1	CNC: 3 MB; PLC: 512 KB
NCU 720.1	6FC5372-0AA00-0AA0	CNC: 3 MB; PLC: 128 KB
NCU 720.2	6FC5372-0AA00-0AA1	CNC: 3 MB; PLC: 512 KB
NCU 720.2PN	6FC5372-0AA01-0AA1	CNC: 3 MB; PLC: 512 KB
NCU 730.1	6FC5373-0AA00-0AA0	CNC: 3 MB; PLC: 128 KB
NCU 730.2	6FC5374-0AA01-0AA0	CNC: 3 MB; PLC: 128 KB
NCU 730.2 PN	6FC5373-0AA01-0AA1	CNC: 3 MB; PLC: 512 KB

Table 1-2 Operator components

Operator Components	Order No.	Comment
OP010 operator panel	6FC5203-0AF00-0AA0	
OP010C operator panel	6FC5203-0AF01-0AA0	
OP010S operator panel	6FC5203-0AF04-0AA0	
OP012 operator panel	6FC5203-0AF02-0AA1	
OP012T operator panel	6FC5203-0AF06-1AA0	
OP015 operator panel	6FC5203-0AF03-0AA0	
OP015A operator panel	6FC5203-0AF05-0AB0	
OP015AT operator panel	6FC5203-0AF05-1AB0	
TP015A operator panel	6FC5203-0AF08-0AB0	
TP015AT operator panel	6FC5203-0AF08-1AB0	
PROFIBUS DP direct key module	6FC5247-0AF11-0AA0	
Direct key module mounting kit	6FC5247-0AF30-0AA0	

Г

Table 1-2 Operator components

PCU 50.3 – C	6FC5210-0DF31-2AA0	1.5 GHz, 512 MB, Windows XP
PCU 50.3 – P	6FC5210-0DF33-2AA0	2.0 GHz, 1024 MB, Windows XP

Table 1-2 Operator components

Operator Components	Order No.	Comment
MCP 310	6FC5203-0AF23-1AA0	
MCP 310 IE	6FC5303-0AF23-1AA0	
MCP 483	6FC5203-0AF22-1AA2	
MCP 483C IE	6FC5303-0AF22-0AA0	
MCP 483 IE	6FC5303-0AF22-1AA0	
CNC full keyboard KB 310C	6FC5203-0AF21-0AA0	
CNC full keyboard KB 483C	6FC5203-0AF20-0AA1	
PC keyboard, standard	6FC5203-0AC01-3AA0	

Supplementary Conditions

Please observe the following supplementary conditions when using ShopMill:

- ShopMill is only executed in channel 1, mode group 1.
- Up to 5 axes plus a spindle are displayed on the ShopMill operator interface.
- The machine axes are assigned to fixed numbers (1=X, 2=Y, 3=Z).
- The spindle can be assigned to axis numbers 4, 5 or 6.
- ShopMill allows for a geometry axis interchange under the following preconditions.
 - Three geometry axes must always be present. The names of the channel axes (MD 20080) and the geometry axes (MD 20060) must be uniquely different. A geometry axis interchange can only be programmed for linear axes. A geometry axis interchange does not exist for spindles. Only ShopMill–approved add–on axes may be exchanged with geometry axes.
- ShopMill operates only with tool management.
 Spindle 1 must always be the change point (see configuration file). The loading point can be 1 or 2 (see MD 9673 \$MM CMM TOOL LOAD STATION).
- With ShopMill Open you are not allowed to change the position of the following softkeys. This means that a specific task must always be assigned to these functions in the REGIE.INI file.
 Task 0 (horizontal softkey 1): Operating area Machine
 Task 1 (horizontal softkey 2): Operating area Program manager
 Task 2 (horizontal softkey 3): Operating area Program
 Task 4 (horizontal softkey 5): Operating area Tools/Zero offsets
- Several operator panels can be used for ShopMill via TCU.
- The HMI and Windows screen savers must not be used together.
 References: /IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840Di/840D;
 /IHE/ Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl

Space for your notes

Reserved Functions

The following functions are utilized by ShopMill and must not be assigned for other purposes.

 PROG_EVENT
 The system cycle PROG_EVENT.SPF is used by the standard cycles and by ShopMill.

 If you also want to use the cycle PROG_EVENT.SPF for user functions, you must implement those user functions in the cycles CYCPE_US.SPF or CYCPE1US.SPF. Save these cycles in the directory for user cycles or manufacturer cycles.

Space for your notes

Commissioning

4.1 Prerequisites

Data transfer

For data transfer you require:

Hardware

- Programming device with Windows XP or PC with Ethernet
- Memory stick, if required (Order No.: 6ES7 648-0DC20-0AA0)
- Software
 - SIMATIC Step7, version 5.3 SP2 or higher (for Order No., see SIMATIC catalog)

ShopMill software

• ShopMill on NCU (HMI Embedded sl)

With the ShopMill variant on NCU (HMI Embedded sl), the software is already pre-installed on the CompactFlash Card:

- Drive software (Sinamics)
- PLC software
- NCK software
- ShopMill
- Cycles

The software is provided in 6 languages (German, English, French, Italian, Spanish, and Chinese).

• ShopMill for PCU 50.3

The required software can be found on the DVD "NCU–SysSW and ShopMill– HMI". The software is provided in 6 languages (German, English, French, Italian, Spanish, and Chinese).

The procedure for installing the software on PCU and NC/PLC is described in the following Commissioning sections.

Note

The exact contents of the DVD are located in the file SIEMENSD.RTF (German) or SIEMENSE.RTF (English). A compatibility list is located in the file 840D_sl_compatibility_list.xls.

4.2.1 Sequence

Before you begin commissioning, please read the general conditions and reserved functions.

For installation and commissioning, proceed as follows:

- ShopMill installation on PCU (for ShopMill on PCU 50.3 only). For ShopMill on NCU (HMI Embedded sl), the ShopMill software is preinstalled.
- 2. PLC commissioning
- 3. NCK commissioning
- 4. Install additional functions (optional)
- 5. Adapt display machine data
- 6. Customize the operator interface (optional)
- 7. Run a test using the acceptance certificate

You can commission tool management either together with NCK and PLC commissioning or afterwards. If tool management is already set up on the machine you only need to adapt the display machine data for tool management; (see Section 8.2 "Commissioning sequence").

You can find a detailed description of the commissioning process in the following documentation:

References: /IDsl/, Commissioning Manual CNC: NCK, PLC, drive, SINUMERIK 840D sl;

/IHE/, Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl;

/IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840D/840Di sl



Fig. 4-1 General sequence of first commissioning

 General sequence
 (1) The first step in the commissioning sequence is to configure the control system, i.e. to set up communication between all involved components. PLC, drive and NCK are commissioned

 References:
 /IDsl/, Commissioning Manual CNC: NCK, PLC, drive, SINUMERIK 840D sl

(2) In a second step, the individual functions are commissioned in several runs. The commissioning sequence for these functions is described in the following sections.

4.2.2 Installation of ShopMill on NCU (HMI Embedded sl)

For the purposes of operating ShopMill on NCU (HMI Embedded sl) the whole software is pre-installed on the CompactFlash Card. Only adaptations of the NCK and PLC remain to be carried out.

Note

ShopMill uses the alarm texts and PLC messages of the CNC ISO operator interface. You can find detailed information on this subject as well as the the software installation in the following document: **References:** /IHE/, Commissioning Base Software and HMI Embedded sI, SINUMERIK 840D sI

4.2.3 Installing ShopMill on PCU 50.3

If you wish to install ShopMill on the PCU 50.3, the HMI Advanced software must already be installed on the PCU 50.3.

After installation, the internal HMI Embedded on the NCU must be deactivated. It is deactivated or activated by means of the service program Win SCP. Start WinSCP and select "Open Terminal" under Commands. The "sc disable hmi" action deactivates the internal HMI Embedded. The "sc enable hmi" action activates the internal HMI Embedded.

References: /IDsl/, Commissioning Manual CNC: NCK, PLC, drive, SINUMERIK 840D sl; /IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840D/840Di

You can install ShopMill on the PCU 50.3 in one of three different ways:

- Installation via a network link
- Installation from data media (e.g. DVD)
- Installation Via USB interface

Note

ShopMill uses the alarm texts and PLC messages of the CNC ISO operator interface. You can find detailed information on this subject as well as the the software installation in the following document: **References:** /IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840D/840Di

4.2.4 PLC commissioning

To commission the PLC you must first create and then load a PLC user project. To commission the PLC, proceed as follows:



Fig. 4-2 PLC commissioning

4.2.5 NCK commissioning

The commissioning of the NCK features the following items:

- Set up axes and spindles
- Load ShopMill machine data, definitions and cycles
- Set up tool management

You only need to set up the axes and spindles if you have not yet done so on the machine. When setting up the axes and spindles please observe the general conditions; (see Section 2 "General conditions").

Similarly, you only need to set up tool management in the NCK if this does not yet exist.

Note:

Sample files are located in the directory under CYCLES\SC\PROG\TEMPLATES_DEU or CYCLES\SC\PROG\ TEMPLATES_ENG.





Fig. 4-3 NCK SINUMERIK 840D sl commissioning



Fig. 4-4 NCK SINUMERIK 840D sl commissioning



Fig. 4-5 NCK SINUMERIK 840D sl commissioning

4.2.6 Display machine data

After the installation of ShopMill on the PCU and the commissioning of NCK and PLC are completed, you still have to adapt the display machine data. The display machine data are listed in Section 7.2 "Display Machine Data for ShopMill".

4.2.7 Acceptance report

The acceptance certificate can be used to test the installed ShopMill functions once ShopMill commissioning has been completed. The acceptance certificate is included on the ShopMill DVD.

PLC Program

5.1 Structure of the PLC program

The tool management and the basic PLC program (FB1, FC2, ...) must be called in the OBs 1, 40 and 100.

For a description of the function blocks and the basic PLC program, please refer to:

References: /FB1/, Description of basic machine functions, P3 sl, "Basic PLC program"

Example source files

5.2 Example source files

Table 5-1

ShopMill supplies various source files for sample blocks. You can adapt and compile these source files or you can use your own blocks.

Source	Mnemonics	Note	Block	Comment
TM_W_GR. AWL TM_WO_GR. AWL	German	The indicated block numbers are pro- grammed in absolute terms.	FC 100	Sample block for config- uring tool management The block is called in OB100.
			FB 110	Sample block for data transfer of tool manage- ment. The block is called in OB1.
			DB 110	Instance data block for FB 110
TM_W_UK. AWL TM_WO_UK. AWL	English	same as TM_W_	GR.AWL and	TM_WO_GR.AWL

The sample blocks are located in the toolbox under \ShopMill_Turn.

5.3 Standard interface signals for/from ShopMill

5.3 Standard interface signals for/from ShopMill

The following presents a listing of the standard interface signals that are affected by the ShopMill interface (DB19).

Byte	Designation
DB19	Signals from operator panel (HMI——>PLC)
DBB21	Selection of operating areas see Section 6.1 "HMI interface DB19"
DBX18 Bit0	Update tool data see Section 6.1 "HMI interface DB19"
DBX20 Bit6	Simulation active see Section 6.1 "HMI interface DB19"
DBW24	Current image numbers of ShopMill see Section 6.1 "HMI interface DB19"
DB21	Signals to NCK channel (PLC—>NCK)
DBX7.5	Deactivate global start lock see Section 6.1 "HMI interface DB21"

Table 5-2	Standard interface	signals	for/from	ShonMill
14010 3-2	Stanuaru internace	Signals	101/110111	Shopivilli

Note

 A feed lock with stationary spindle must not be implemented in the PLC user program since the positioning of the axes to the next position with stationary spindle is carried out during feed for "index circle thread tapping with positioning on circle".

 $\hfill Siemens$ AG 2008 All Rights Reserved SINUMERIK 840D sI Commissioning CNC: ShopMill - 01/2008 Edition

Signal Description

6.1 HMI interface DB19

DB19	E_SimActiv			
DBX20.6	Simulation	 Simulation active		
Data block	Signal(s) fro	Signal(s) from ShopMill		
Edge evaluation: No	1	Signal(s) updated: Cyclic	Signal(s) valid from software version: ShopMill 5.3	
Significance of signal	0: Exit simu 1: Start simu	lation ulation		

DB19	E AcitivWA	
DBB21	Active MMC operating area	
Data block	Signal(s) from ShopMill	
Edge evaluation: No	Signal(s) updated: Cyclic	Signal(s) valid from software version: ShopMill 7.1
Significance of signal	OPEN (HMI Advanced) SK number (as predefined in the control (Task+1)) Classic (HMI Embedded) 201: SM machine 202: SM directory 203: SM program 204: SM alarms/messages 205: SM tool	

6 Signal Description

6.1 HMI interface DB19

DB19	mask number		
DBW24	Current screen number of ShopMill		
Data block	Signal(s) from ShopMill		
Edge evaluation: No	Signal(s) updated: Cyclic	Signal(s) valid from software version: ShopMill 7.5	
Significance of signal	The signal outputs the image number of the current is The following image number can be output: No. ShopMill image Manual machine mode: 19 Basic image 2 T,S,M 21 Setting basic NPV* 30 Zero point workpiece 5 Zero point workpiece – Set up edge 7 Zero point workpiece – User mask* 31 Zero point workpiece – Align edge/user mask* 32 Zero point workpiece – Distance 2 edges/user 33 Zero point workpiece – Random edge/user mask* 34 Zero point workpiece – Rectangular pocket 9 Zero point workpiece – 1 bore/user mask* 35 Zero point workpiece – 1 bore/user mask* 36 Zero point workpiece – 1 bore/user mask* 37 Zero point workpiece – 1 bore/user mask* 38 Zero point workpiece – 1 bore/user mask* 39 Zero point workpiece – 1 circular pin/user mas 39 Zero point workpiece – 1 circular pin/user mas 39 Zero point workpiece – 2 circular pins 40 Zero point workpiece – 3 circular pins 41 Zero point workpiece – 3 circular pins 42 Zero point workpiece – 2 circular pins 43 Zero point workpiece – 3 circular pins 44 Zero point workpiece – 3 circular pins 45 Zero point workpiece – 4 circular pins 46 Zero point workpiece – 4 circular pins 47 Zero point workpiece – Adjusting probe – leng 48 Zero point workpiece – Adjusting probe – leng 49 Zero point workpiece – Adjusting probe – leng 40 Measuring tool – Manual length /user mask* 41 Measuring tool – Auto length /user mask* 42 Measuring tool – Auto length /user mask* 43 Measuring tool – Auto length /user mask* 44 Measuring tool – Adjusting measuring probe*// 55 Measuring tool – Adjusting fixed point/user ma 47 Measuring tool – Adjusting fixed point/user ma 48 Face milling* 49 Arostioning 40 Face milling* 41 ShopMill Settings 42 MDA 44 Machine mode: 420 MDA 44 Simultaneous recording – Settings* 44 Simultaneous recording – Settings*	shopMill 7.5 ShopMill image. * mask* ask* sk* th*/user mask* user mask* ask*	
	243 Simultaneous recording – 3–plane view* 244 Simultaneous recording – Volume model*		
	250 Expanded softkey bar – Setting		

6.1 HMI interface DB19

DB19	mask number		
DBW24	Current screen number of ShopMill		
Data block	Signal(s) from ShopMill		
Edge evaluation: No	Signal(s) updated: Cyclic	Signal(s) valid from software version:	
Significance of signal	Operating area program manager:		
orgrinioarios er orgriar	300 Directory NC		
	310 Part programs*		
	320 Subroutines*		
	330 User directory 1*		
	340 User directory 2*		
	350 User directory 3*		
	360 User directory 4*		
	380 Standard cycles*		
	381 Manufacturer cycles*		
	382 User cycles*		
	305 User directory 6*		
	385 User directory 7*		
	386 User directory 8*		
	Operating area program:		
	400 Machining plan/G-code editor		
	411 Simulation – Settings*		
	412 Simulation – Top view*		
	413 Simulation – 3–plane view*		
	414 Simulation – Volume model*		
	Operating area Messages/alarms:		
	500 Messages		
	510 User mask*		
	520 User mask*		
	Operating area tools/zero offsets:		
	600 Tool list		
	610 Tool wear		
	620 User tool list*		
	630 Magazine		
	640 Zero offset		
	650 R parameter		
	600 Machino data		
	680 User data		
	Run screen		
	910 Run screen in operating area manual machin	e*	
	920 Run screen in operating area machine MDA*		
	930 Run screen in operating area auto machine*		
	* = If image is available		

6.2 HMI interface DB21

6.2 HMI interface DB21

In ShopMill, the start of a program can only be executed in the machine area by default. Starting a program in any of the other areas (e.g. tools) is prevented by a global start lock.

Note

You can specify, via MD 9719, bit 9, that it should be possible to start a program from all masks.

In automated sequences, e.g. a start from the PLC as used on a machine with a pallet change system, this global start lock can be deactivated by means of interface signal DB21.DBX7.5. This prevents a program start of this nature being locked by the operator interface.

DB21	suppressStartLock		
DBX7.5	Deactivate global start lock		
Data block	PLC> NCK		
Edge evaluation: No	Signal(s) updated:	Cyclic	Signal(s) valid from software version: ShopMill 7.1
Significance of signal	0: Do not cancel global start loc 1: Deactivate global start lock	K	

So that an alarm is output in the event of a start being attempted while the global start lock is activated, bit 6 in the machine data 16956 \$MN_ENABLE_ALARM_MASK must be set.

6.3 Overview of the former ShopMill interface

The ShopMill PLC program and the corresponding ShopMill interface DB82 are omitted in the new software release of ShopMill. The following tables show where you can find the old interface signals of the DB82.

6.3.1 Signals to ShopMill (input signals)

Table 6-1 Signals to ShopMill (input signals)

Address DB82 DBX	Name Comments	Spares
0.0 - 0.7	CMM_IN.transfer_base_sig Transfer mode for MTTS signal	Omitted since ShopMill PLC no longer exists
2.0	CMM_IN.base_sig.main_mode_mill.manual ShopMill manual mode	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX0.2 JOG.
2.1	CMM_IN.base_sig.main_mode_mill.automatic ShopMill automatic mode	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX0.0 AUTO.
4.0	CMM_IN.base_sig.reset RESET for ShopMill	Transfer is via FC19/FC24 to the standard inter- face DB21.DBX7.7 Reset.
4.1	CMM_IN.base_sig.nc_cycle_start Cycle start	Transfer is via FC19/FC24 to the standard inter- face DB21.DBX7.1 NC–Start.
4.2	CMM_IN.base_sig.nc_cycle_stop Cycle stop	Transfer is via FC19/FC24 to the standard inter- face DB21.DBX7.3 NC–Stop.
6.0	CMM_IN.sub_mode_mill.tool Operating area – tool	Omitted. Use the appropriate key on the operator panel; (see section 10.5 OP hotkeys, PLC keys).
6.1	CMM_IN.sub_mode_mill.directory Operating area – Directory	Omitted. Use the appropriate key on the operator panel; (see section 10.5 OP hotkeys, PLC keys).
6.2	CMM_IN.sub_mode_mill.messages Operating area – Alarms/messages	Omitted. Use the appropriate key on the operator panel; (see section 10.5 OP hotkeys, PLC keys).
6.3	CMM_IN.sub_mode_mill.program Operating area – program	Omitted. Use the appropriate key on the operator panel; (see section 10.5 OP hotkeys, PLC keys).
6.4	CMM_IN.sub_mode_mill.oem1 Operating area – OEM1	n.a.
6.5	CMM_IN.sub_mode_mill.oem2 Operating area – OEM2	n.a.
6.6	CMM_IN.sub_mode_mill.customer Operating area – Customer	n.a.
6.7	CMM_IN.sub_mode_mill.mda Operating area – MDA	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX0.1 MDA.
8.0	CMM_IN.spndle_interface_number Assignment of spindle/axis data	Omitted since ShopMill PLC no longer exists
9.0	CMM_IN.user_defined_spindle_control User-defined spindle control	Omitted since ShopMill PLC no longer exists

Address DB82 DBX	Name Comments	Spares
9.1	CMM_IN.spindle_start Spindle start	Standard interface DB3x.DBX30.1/30.2
9.2	CMM_IN.spindle_stop Spindle stop	Standard interface DB3x.DBX30.0
9.3	CMM_IN.spindle_left Spindle start	Standard interface DB3x.DBX30.2
9.4	CMM_IN.spindle_right Spindle start	Standard interface DB3x.DBX30.1
9.5	CMM_IN.program_extern_selected Program is selected in the PLC.	No longer required due to updated logic in Shop- Mill interface.
9.6	CMM_IN.disable_cnc_standard Locking switchover to CNC–ISO user inter- face	ShopMill Open (PCU 50.3): not available; ShopMill on NCU (HMI Embedded): lock for the remaining operating areas by means of protective levels
9.7	CMM_IN.cmm_activ_in_cnc_mode ShopMill PLC active during CNC-ISO oper- ation	Omitted since ShopMill PLC no longer exists
10.0	CMM_IN.program_test_request Select function for program test	MMC -> PLC DB21.DBX25.7 PLC -> NCK DB21.DBX1.7 Connect as in the PLC user program.
10.1	CMM_IN.dry_run_request Select DryRun function	MMC -> PLC DB21.DBX24.6 PLC -> NCK DB21.DBX0.6 Connect as in the PLC user program.
10.2	CMM_IN.m01_request Select function M01	MMC -> PLC DB21.DBX24.5 PLC -> NCK DB21.DBX0.5 Connect as in the PLC user program.
10.3	CMM_IN.skip_block_request Select function for skipping record	MMC -> PLC DB21.DBX26.0 ff PLC -> NCK DB21.DBX2.0 ff Connect as in the PLC user program
10.4	CMM_IN.boot_standard System boot in CNC-ISO user interface	ShopMill Open (PCU 50.3): Change PoweronTask in control, or remove Shop- Mill operating area from the control, or assign pro- tective levels to the ShopMill operating areas in the control; ShopMill on NCU (HMI Embedded): Assign a protective level to the ShopMill operating area
10.5	CMM_IN.nck_auto_req Prepare record search PLC	Omitted since operating area jog, automatic and MDA are now identical to the NCK modes
10.6	CMM_IN.spindle_act_m30_reset Spindle active after M30 and reset	Omitted since ShopMill PLC no longer exists
10.7	CMM_IN.ignore_nck_alarm Ignore NCK alarm in the event of cycle start	Omitted since the NC start of ShopMill is no longer manipulated
11.1	CMM_IN.get_tool_data Update tools data	Omitted since the NC start of ShopMill is no longer manipulated

6.3 Overview of the former ShopMill interface

Address DB82 DBX	Name Comments	Spares
11.5	CMM_IN.drf_request Select the function DRF	MMC -> PLC DB21.DBX24.3 PLC -> NCK DB21.DBX0.3 Connect as in the PLC user program.
12	CMM_IN.ext_m_cmd_1 1st expanded M function to output tool–spe- cific functions	Omitted since ShopMill PLC no longer exists (see also display MD 9739 to 9746)
13	CMM_IN.ext_m_cmd_2 2nd expanded M function to output tool–spe- cific functions	Omitted since ShopMill PLC no longer exists (see also display MD 9739 to 9746)

6.3.2 Signals from ShopMill (output signals)

Address DB82	Name Comments	Spares
DBX		
30.0	CMM_OUT.base_sig.main_mode_mill.manual ShopMill manual mode	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX6.2 JOG
30.1	CMM_OUT.base_sig.main_mode_mill.aute matic ShopMill automatic mode	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX6.0 AUTO
32.0	CMM_OUT.base_sig.reset Reset performed	Can be simulated with the interface signal DB21.DBX35.7 channel status reset
32.1	CMM_OUT.base_sig.nc_cycle_activ Cycle active	Transfer is via FC19/FC24 to the standard inter- face DB21.DBX
32.2	CMM_OUT.base_sig.nc_cycle_activ Cycle interrupted	Transfer is via FC19/FC24 to the standard inter- face DB21.DBX
34.0	CMM_OUT.sub_mode_mill.tool Operating area – Tool is selected	Standard interface signal DB19.DBB21 = 205
34.1	CMM_OUT.sub_mode_mill.directory Operating area – Directory is selected	Standard interface signal DB19.DBB21 = 202
34.2	CMM_OUT.sub_mode_mill.messages Operating area – Alarms/Messages is se- lected	Standard interface signal DB19.DBB21 = 204
34.3	CMM_OUT.sub_mode_mill.program Operating area – Program is selected	Standard interface signal DB19.DBB21 = 203
34.7	CMM_OUT.sub_mode_mill.mda Operating area – MDA is selected	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX6.1 MDA
36.0	CMM_OUT.cmm_plc_activ ShopMill PLC active	Omitted since ShopMill PLC no longer exists
36.1	CMM_OUT.cmm_mmc_activ ShopMill user interface active	ShopMill Open (PCU 50.3): is not being analyzed ShopMill on NCU (HMI Embedded): DB19.DBB21
36.2	CMM_OUT.spindle_start_req Spindle start requested (M3/M4 output to spindle)	Standard interface DB3x.DB64.6 and DB3x.DB64.7

 Table 6-2
 Signals from ShopMill (output signals)

6.3 Overview of the former ShopMill interface

Address DB82 DBX	Name Comments	Spares
36.3	CMM_OUT.spindle_stop_req Spindle stop requested, M5 output to spindle	Standard interface DB3x.DB64.6 and DB3x.DB64.7
36.4	CMM_OUT.spindle_right Spindle rotation right preselected	Standard interface DB3x.DB64.6 and DB3x.DB64.7
36.5	CMM_OUT.spindle_left Spindle rotation left preselected	Standard interface DB3x.DB64.6 and DB3x.DB64.7
36.7	CMM_OUT.ext_prog_sel External processing program is selected	n.a.
37.0	CMM_OUT.program_selection_done Acknowledgment from HMI that a program has been selected	Omitted because of the new start lock logic of the NCK. The program can be selected and started directly.
37.1	CMM_OUT.program_test_activ Function for program test is active	Standard interface signal DB21.DBX33.7
37.2	CMM_OUT.dry_run_activ Function for DryRun is active	Standard interface signal DB21.DBX318.6
37.3	CMM_OUT.m01_activ Function M01 is active	Standard interface signal DB21. DBX32.5
37.4	CMM_OUT.skip_block_activ Function for skipping record is active	Standard interface signal DB21. DBX26.0ff
37.7	CMM_OUT.start_up_activ ShopMill boot active	n.a.
38.1	CMM_OUT.tool_un_load_internal Load/unload tool without moving magazine	Standard interface signal DB71.DBX32.0 for the 1st loading point
38.2	CMM_OUT.drf_activ Function DRF is active	Standard interface signal DB21.DBX24.3
38.3	CMM_OUT.nc_start_ineffective NC start has no effect	Global start lock can be deactivated. Standard interface signal DB21.DBX7.5
42.0	CMM_OUT.tool_m_function_1_on Tool-specific function 1 active	Omitted since ShopMill PLC no longer exists (see also display MD 9739 to 9746)
42.1	CMM_OUT.tool_m_function_2_on Tool-specific function 2 active	Omitted since ShopMill PLC no longer exists (see also display MD 9739 to 9746)
42.2	CMM_OUT.tool_m_function_3_on Tool–specific function 3 active	Omitted since ShopMill PLC no longer exists (see also display MD 9739 to 9746)
42.3	CMM_OUT.tool_m_function_4_on Tool-specific function 4 active	Omitted since ShopMill PLC no longer exists (see also display MD 9739 to 9746)
42.4	CMM_OUT.tool_m_function_1_activ Tool-specific function 1 valid	Omitted since ShopMill PLC no longer exists (see also display MD 9739 to 9746)
42.5	CMM_OUT.tool_m_function_2_activ Tool-specific function 2 valid	Omitted since ShopMill PLC no longer exists (see also display MD 9739 to 9746)
42.6	CMM_OUT.tool_m_function_3_activ Tool–specific function 3 valid	Omitted since ShopMill PLC no longer exists (see also display MD 9739 to 9746)

Table 6-2 Signals from ShopMill (output signals)

6.3 Overview of the former ShopMill interface

Address DB82 DBX	Name Comments	Spares
42.7	CMM_OUT.tool_m_function_4_activ Tool–specific function 4 valid	Omitted since ShopMill PLC no longer exists (see also display MD 9739 to 9746)
44	CMM_OUT.mask_number Current image number from ShopMill	Standard interface signal DB19.DBW24

Table 6-2 Signals from ShopMill (output signals)

Space for your notes
7

Machine Data

7.1 NCK machine data for ShopMill

The commissioning of NCK requires that all relevant NCK machine data (including the tool management) are set with the ShopMill–specific values.

In the operating area "Tools – zero" open the mask "Machine data" by pressing the softkey "Machine data" in the extended softkey bar. All required machine data for ShopMill are displayed here with information about setpoints and actual values.

Correctly set machine data is marked with a tick. Machine data marked with an exclamation mark must be corrected accordingly. A red exclamation mark in the header (no., MD, target, actual) already points out to you that machine data must be corrected.

The following signs show the rule for setpoint to actual value:

- =: must be exact
- \leq : must be at least
- &: certain bits must be exact

If no rule is indicated for setpoint to actual value, it is only a suggestion.

NCK machine data with exact values must be set as specified. NCK machine data with minimum values can be adapted to the specific features of your machine.

The activation mode for each item of machine data is indicated in the column after the actual value display.

- po: Power On (softkey "NCK reset")
- cf: Configuration (softkey "Set MD effective")
- so: Immediately (no action required)
- re: Reset ("Reset" key on machine control panel)

7.1 NCK machine data for ShopMill

With the softkey "Actual=setpoint" you adjust incorrect values to the minimum requirements of ShopMill if you confirm the following question with "OK". If the actual value is too low, for example, the value of the machine data is set to the lowest setpoint. For bit masks only the missing bits are set.

Note

The file SIEMENSD.RTF or SIEMENSE.RTF provides a list with the required settings of the ShopMill machine data. You are advised to print these out. You can then check and if necessary correct the specific values more conveniently.

Note

Please note that the machine data record also contains machine data for configuring the memory.

For an exact description of all NC machine data, please refer to: **References:** /LIS1sl/, Lists (book 1); /LIS2sl/, Lists (book 2); /IDsl/, Commissioning CNC: NCK, PLC, drive, SINUMERIK 840D sl; /FB/, Description of Functions

NCU load The load placed on the NCU by the position controller and the interpolator must not exceed a maximum value of 70%. The load can be set via NCK machine data. To do that, proceed as follows:

- Change to the CNC–ISO operator interface and select the "Diagnosis" → "Service display" → "System resources" menu.
- Press "Start" softkey. The maximum value for "NCU load by position controller and interpolator" is cleared.
- Change to the ShopMill operator interface and in automatic operating mode select the "Simultaneous recording" function.
- Start the following test program:

G0 G91 LABEL: X1 Y1 Z1 X-1 Y-1 Z-1 GOTOB LABEL M30

- Change back to the CNC–ISO operator interface and select the "Diagnosis" → "Service display" → "System resources" menu.
- If the maximum value for "NCU load by position controller and interpolator" is greater than 70%, adapt the interpolator cycle in MD 10070 \$MN_IPO_SYS-CLOCK_TIME_RATIO or the position controller cycle in MD 10050 \$MN_SYSCLOCK_CYCLE_TIME. Adapting the interpolator cycle has the advantage that axis optimization is not altered.
- Repeat the steps described.

7.2 Display machine data for ShopMill

After the installation of ShopMill on the PCU and the commissioning of NCK and PLC are completed, you still need to adapt the display machine data. In any case, you must check the settings of the display machine data that are identified in table 7-1 with "*".

7.2.1 Overview of machine data display

MD	MD identifier	Comment	Preset
ber			uelault
9014	\$MM_USE_CHANNEL_DISPLAY_DATA	Use channel-specific display machine data	0
9020	\$MM_TECHNOLOGY	Basic configuration turning/milling	2
9422	\$MM_MA_PRESET_MODE	Preset/basic offset in JOG	1
9426	\$MM_MA_AX_DRIVELOAD_FROM_PLC1	Machine index of an analog spindle for the drive load display	0
9427	\$MM_MA_AX_DRIVELOAD_FROM_PLC2 Machine index of an analog spindle for the drive load display		
9428	\$MM_MA_SPIND_MAX_POWER	Factor for display of spindle utilization	100
9429	\$MM_MA_SPIND_POWER_RANGE	Display area for spindle utilization	200
9450	\$MM_WRITE_TOA_FINE_LIMIT	Limit value for wear fine	0.999
9451	\$MM_WRITE_ZOA_FINE_LIMIT	Limit value for fine adjustment	0.999
9460	\$MM_PROGRAM_SETTINGS	Settings in the Program area	H8
9478*	\$MM_TO_OPTION_MASK	Settings for ShopMill	1
9479*	\$MM_TO_MAG_PLACE_DISTANCE	Distance between individual tool holders	0
9480	\$MM_MA_SIMULATION_MODE	Switch fast view on/off	-1
9481	\$MM_MA_STAND_SIMULATION_LIMIT	Limit of the standard simulation in KB	200
9602	\$MM_CTM_SIMULATION_DEF_VIS_AREA	Simulation of default display area	100
9603	\$MM_CTM_SIMULATION_MAX_X	Simulation of maximum display X	0
9604	\$MM_CTM_SIMULATION_MAX_Y	Simulation of maximum display Y	0
9605	\$MM_CTM_SIMULATION_MAX_VIS_AREA	Simulation of maximum display area	1000
9626	\$MM_CTM_TRACE	Settings in ShopMill	0
9639	\$MM_CTM_MAX_TOOL_WEAR	Upper input limit for tool wear	1
9640	\$MM_CTM_ENABLE_CALC_THREAD_PITCH	Calculation of thread depth if pitch entered	0
9646	\$MM_CTM_FACTOR_O_CALC_THR_PITCH	Factor for calculating the external thread depth if pitch entered	0.6134
9647	\$MM_CTM_FACTOR_I_CALC_THR_PITCH	Factor for calculating the internal thread depth if pitch entered	0.5413
9650*	\$MM_CMM_POS_COORDINATE_SYSTEM	Position of coordinate system	0
9651*	\$MM_CMM_TOOL_MANAGEMENT	Tool management variant	4
9652*	\$MM_CMM_TOOL_LIFE_CONTROL	Tool monitoring	1
9653*	\$MM_CMM_ENABLE_A_AXIS	Enable 4th axis for operator interface	0
9654	\$MM_CMM_SPEED_FIELD_DISPL&_RES	Number of decimal places in the speed input field	0
9655	\$MM_CMM_CYC_PECKING_DIST	Retraction distance for deep hole drilling	-1
9656	\$MM_CMM_CYC_DRILL_RELEASE_DIST	Retraction distance for boring	-1
9657	\$MM_CMM_CYC_MIN_CONT_PO_TO RAD	Variation of smallest possible cutter radius	5
		in percent	

 Table 7-1
 Display machine data for ShopMill

MD	MD identifier Comment				
num-			default		
ber					
9658	\$MM_CMM_CYC_MAX_CONT_PO_TO_RAD	Variation of largest possible cutter radius	0.01		
9659	\$MM_CMM_CYC_DRILL_RELEASE_ANGLE	Tool orientation angle on retraction	_1		
9660*	\$MM_CMM_ENABLE_PLANE_CHANGE	Changing to machining plane (G17, G18, G19)	1		
9662*	\$MM_CMM_COUNT_GEAR_STEPS	Number of gear stages	1		
9663	\$MM_CMM_TOOL_DISPLAY_IN_DIAM	\$MM_CMM_TOOL_DISPLAY_IN_DIAM Display radius/diameter for tool			
9664	\$MM_CMM_MAX_INP_FEED_P_MIN	MM_CMM_MAX_INP_FEED_P_MIN Maximum feed in mm/min			
9665	\$MM_CMM_MAX_INP_FEED_P_ROT	Maximum feed in mm/rev	1.0		
9666	\$MM_CMM_MAX_INP_FEED_P_TOOTH	Maximum feed in mm/tooth	1.0		
9667*	\$MM_CMM_FOLLOW_ON_TOOL_ACTIVE	Tool preselection active	1		
9668*	\$MM_CMM_M_CODE_COOLANT_I_AND_II	M function coolant I and II	-1		
9669	\$MM_CMM_FACE_MILL_EFF_TOOL_DIAM	Effective cutter diameter for face milling	85.0		
9670	\$MM_CMM_SIARI_RAD_CONTOUR_POCKE	tour pockets plus half the final machining allowance (-1 = safety clearance)	-1.0		
9671	\$MM CMM TOOL LOAD DEFAULT MAG	Load tool in default magazine	0		
9672*	\$MM_CMM_FIXED_TOOL_PLACE	Fixed location coding	0		
9673*	\$MM_CMM_TOOL_LOAD_STATION	Number of loading point	1		
9674	\$MM_CMM_ENABLE_TOOL_MAGAZINE	M CMM ENABLE TOOL MAGAZINE Display of magazine list			
9675	\$MM_CMM_CUSTOMER_START_PICTURE	START_PICTURE Customized boot screen			
9680*	\$MM_CMM_M_CODE_COOLANT_I	M function coolant I	8		
9681*	\$MM_CMM_M_CODE_COOLANT_II	NT_II M function coolant II			
9682	\$MM_CMM_CYC_BGF_BORE_DIST	T Preboring depth for drill and thread milling			
9686*	\$MM_CMM_M_CODE_COOLANT_OFF	OLANT_OFF M function for coolant OFF			
9687	\$MM_CMM_TOOL_MOVE_DEFAULT_MAG	Reload tool in default magazine	0		
9688	\$MM_CMM_COUNT_GEAR_STEPS_S2	Number of gear stages for the front spindle	1		
9703*	\$MM_CMM_INDEX_AXIS_4	Axis index for 4th axis	0		
9704*	\$MM_CMM_INDEX_AXIS_5	Axis index for 5th axis	0		
9705*	\$MM_CMM_INDEX_SPINDLE	Axis index for spindle	4		
9706	SMM_CMM_GEOAX_ASSIGN_AXIS_4	Assignment of 4th axis to geometry axis	0		
9707	SMM_CMM_IGEOAX_ASSIGN_AXIS_5	Assignment of 5th axis to geometry axis	0		
9708	\$MIM_CMM_INDEX_SPINDLE_2	Axis index for 2nd spindle	0		
9710*	\$MIN_CMM_OPTION_MASK_2	Settings for ShopMill	<u>0</u> Н5		
9720*	\$MM_CMM_ENABLE B_AXIS	Enable 5th axis for operator interface	0		
9721*	\$MM_CMM_ENABLE_B_AXIO	Enable signal for cylinder surface trans-	0		
0.21	••••••• <u>-</u> ••••• <u>-</u> ••••••	formation	0		
9723*	\$MM_CMM_ENABLE_SWIVELING_HEAD	Enable swiveling	0		
9724	\$MM_CMM_CIRCLE_RAPID_FEED	Rapid feed for positioning on circular path	5000		
9725	\$MM_CMM_ENABLE_QUICK_M_CODES	Enable fast M functions	0		
9727	\$MM_CMM_ENABLE_POS_A_B_AXIS	Enable support for A/B axis	0		
9728	\$MM_CMM_DISPL_DIR_A_B_AXIS_INV	Adapting to the direction of rotation of the A/B axis	0		
9729	\$MM_CMM_G_CODE_TOOL_CHANGE_PROG	Program name for tool change in the G code	_		
9739	\$MM_CMM_M_CODE_TOOL_FUNC_1_ON	M code for tool-specific function 1 ON	-1		
9740	\$MM_CMM_M_CODE_TOOL_FUNC_1_OFF	M code for tool-specific function 1 OFF	_1		
9741	\$MM_CMM_M_CODE_TOOL_FUNC_2_ON	M code for tool–specific function 2 ON	-1		
9742	\$MM_CMM_M_CODE_TOOL_FUNC_2_OFF	M code for tool–specific function 2 OFF	1		

MD	MD identifier	Comment	Preset		
num- ber			default		
9743	\$MM_CMM_M_CODE_TOOL_FUNC_3_ON	M code for tool–specific function 3 ON	-1		
9744	\$MM_CMM_M_CODE_TOOL_FUNC_3_OFF	M code for tool–specific function 3 OFF	-1		
9745	\$MM_CMM_M_CODE_TOOL_FUNC_4_ON	M code for tool–specific function 4 ON	-1		
9746	\$MM_CMM_M_CODE_TOOL_FUNC_4_OFF	M code for tool–specific function 4 OFF	-1		
9747	\$MM_CMM_ENABLE_MEAS_AUTO	Enable automatic workpiece measurement	1		
9748	\$MM_CMM_MKS_POSITION_MAN_MEAS	Position man. tool measurement with fixed point	0		
9749*	\$MM_CMM_ENABLE_MEAS_T_AUTO Enable automatic tool measurement				
9750*	\$MM_CMM_MEAS_PROBE_INPUT Measuring input for workpiece probe				
9751*	\$MM_CMM_MEAS_T_PROBE_INPUT	Measuring input for tool probe	1		
9752	\$MM_CMM_MEASURING_DISTANCE	Max. measurement distance for workpiece measurement in the program	5		
9753	\$MM CMM MEAS DIST MAN	Max. measurement distance of the work-	10		
		piece measurement in manual mode			
9754	\$MM_CMM_MEAS_DIST_TOOL_LENGTH	Maximum measurement distance for tool	2		
0755		May massurement distance for tool rodius	4		
9755		for rotating. Spindle	1		
9756	\$MM_CMM_MEASURING_FEED	Measuring feed rate for workpiece mea- surement	300		
9757	\$MM CMM FEED WITH COLL CTRL	Plane feed with collision monitoring	1000		
9758	\$MM_CMM_POS_FEED_WITH_COLL_CTRL	M POS FEED WITH COLL CTRL Infeed with collision monitoring			
9759	\$MM_CMM_MAX_CIRC_SPEED_ROT_SP Maximum circumferential speed for tool measurement for rotating Spindle		100		
9760	\$MM_CMM_SPIND_SPEED_ROT_SP Maximum speed for tool measurement for rotating Spindle		1000		
9761	\$MM_CMM_MIN_FEED_ROT_SP	Min. feed rate for workpiece measurement	10		
		for rotating Spindle			
9762	\$MM_CMM_MEAS_TOL_ROT_SP	Measuring accuracy. of tool measurement for rotating. Spindle	0.01		
9763*	\$MM_CMM_TOOL_PROBE_TYPE	Tool probe type	0		
9764*	\$MM_CMM_TOOL_PROBE_ALLOWS_AXIS	Permissible axis directions of tool probe	133		
9765*	\$MM_CMM_T_PROBE_DIAM_LENGTH_MEA	Diameter tool probe length measurement	0		
9766*	\$MM_CMM_T_PROBE_DIAM_RAD_MEAS	Diameter tool probe radius measurement	0		
9767*	\$MM_CMM_T_PROBE_DIST_RAD_MEAS	Infeed tool probe upper edge for radius measurement	0		
9768*	\$MM CMM T PROBE APPROACH DIR	Plane approach direction for tool probe	-1		
9769	\$MM_CMM_FEED_FACTOR_1_ROT_SP	Feed rate factor 1 tool measurement for	10		
9770	\$MM_CMM_FEED_FACTOR_2_ROT_SP	Feed rate factor 2 tool measurement for rotating. sp.	0		
9771	\$MM_CMM_MAX_FEED_ROT_SP	Maximum feed for tool measurement for rotating Spindle	20		
9772	\$MM_CMM_T_PROBE_MEASURING_DIST	Measurement distance for tool measure- ment with stationary spindle	5		
9773	\$MM_CMM_T_PROBE_MEASURING_FEED Feed rate for tool measurement with sta- tionary spindle		300		
9774	\$MM_CMM_T_PROBE_MANUFACTURER	Tool probe type (manufacturer)	0		
9775	\$MM_CMM_T_PROBE_OFFSET Measurement result correction for tool measurement for rotating sp		0		
9776	\$MM_CMM_MEAS_SETTINGS Settings for measuring cycles		0		
9777	\$MM_CMM_ENABLE_TIME_DISPLAY	Control for time display	0x7F		
9778	\$MM CMM MEAS PROBE SOUTH POLF	Measuring probe length referenced to	1		
0770		lower edge	0		
3113		probe	U		
9855	\$MM_ST_CYCLE_TAP_SETTINGS	Settings for thread tapping	0		

MD num- ber	MD identifier	Comment	Preset default
9999	\$MM_TRACE	Test flags for internal diagnosis	0

7.2.2 Description of display machine data

9014	\$MM_USE_CHANNEL_DISPLAY_DATA			
MD number	Use channel-specific d	isplay machine data		
Default setting: 0	Min. input li	mit: 0	Max. input li	mit: 1
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: –
Data type: LONG			Valid as of software version: ShopMill 6.4	
Significance: In this MD you determine whether you want to use channel-specific display. 0 = No channel-specific display 1 = Channel-specific display Note: With ShopMill this must be set to MD = 0.				fic display.

9020	\$MM_TECHNOLOGY			
MD number	Basic configuration tu	rning/milling		
Default setting: 2	Min. input I	imit: 0	Max. input li	mit: 2
Change becomes effective	after: POWER ON	Protection level: 3/4		Units: –
Data type: BYTE			Valid as of software version: ShopMill 6.1	
Significance: In this MD you stipulate the basic configuration for simulation and free contour pro ming. 0 = No specific configuration 1 = Turning machine configuration 2 = Milling machine configuration				free contour program-

9422	\$MM_MA_PRESET_MODE				
MD number	Preset/basic offset in .	IOG			
Default setting: 1	Min. input l	imit: 0	Max. input li	mit: 3	
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: –	
Data type: BYTE			Valid as of software version ShopMill 6.4		
Significance: In this MD you stipulate the behavior of the function "Set zero offset" in "Machine – m mode. ≠ 2: Zero point is saved in the currently active zero offset, in other cases it is saved in basic offset = 2: Zero point is saved in basic offset				et" in "Machine – manual" cases it is saved in the	

9426 MD number	\$MM_MA_AX_DRIVELOAD_FROM_PLC1 Machine index of an analog spindle				
Default setting: 0	Min. input limit: 0 Max. input limit: 31				
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: –
Data type: BYTE				Valid as of software version	
ShopMill 6.4					
Significance: You enter the machine index of an analog spindle for the drive load display in this MD. The thread tapping is carried out with an analog tool spindle with compensation chuck.				d display in this MD. compensation chuck.	

9427	\$MM_MA_AX_DRIVELOAD_FROM_PLC2				
MD number	Machine ind	dex of an ana	alog spindle		
Default setting: 0		Min. input lir	nit: 0	Max. input li	mit: 31
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: –				Units: –	
Data type: BYTE				Valid as of s	oftware version
ShopMill 6.4					
Significance: You enter the machine index of an analog spindle for the drive load display in this MD.					d display in this MD.
The thread tapping is carried out with an analog tool spindle with compensation chuck.					

9428 MD number	\$MM_MA_SPIND_MAX_POWER Maximum value of the spindle performance display				
Default setting: 100	Min. input limit: 100 Max. input limit: ***				
Change becomes effective a	after: POWEF	RON	Protection level: 3/4		Units: %
Data type: WORD Valid as of software version ShopMill 6.4				oftware version	
Significance:	In this MD enter the factor by which the supplied spindle utilization will be multiplied.				

9429	\$MM_MA_SPIND_POWER_RANGE					
MD number	Display are	Display area for spindle utilization				
Default setting: 200		Min. input lir	mit: 100	Max. input li	imit: ***	
Change becomes effective	after: POWEF	RON	Protection level: 3/4		Units: %	
Data type: WORD				Valid as of s	oftware version	
				ShopMill 6.4	1	
Significance:	In this MD you stipulate the display range of the bar displaying spindle utilization. Depend- ing upon the value entered, the displayed percentage values and the extension of the color areas change. Value entered = 100: Percentage values 0, 80, and 100% are displayed. The color display changes from green to red starting at 80%. Value entered = > 100, e.g. 200: Percentage values 0, 100, and 200% are displayed. The colored display changes from green to red as of 100%					

9450	\$MM_WRIT	\$MM_WRITE_TOA_FINE_LIMIT				
MD number	Limit value	for wear fine	9			
Default setting: 0.999		Min. input lir	nit: –	Max. input li	mit: –	
Change becomes effective a	after: IMMED	ATELY	Protection level: 3/4		Units: mm	
Data type: DOUBLE				Valid as of software version ShopMill 6.3		
Significance: With this MD you define the upper incremental limit (limit value for wear fine) for tool wear (length, radius). The incremental upper limit is only effective if the active protection level is greater than the protection level set in MD 9203 USER_CLASS_WRITE_FINE. The absolute upper limit is set in MD 9639 \$MM_CTM_MAX_TOOL_WEAR.					wear fine) for tool wear level is greater than the DL_WEAR.	

9451	\$MM_WRIT	\$MM_WRITE_ZOA_FINE_LIMIT				
MD number	Limit value	Limit value for fine adjustment				
Default setting: 0.999	Pefault setting: 0.999 Min. input limit:		nit: —	Max. input limit: –		
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: mm	
Data type: DOUBLE				Valid as of software version		
ShopMill 6.3						
Significance:	When entering the fine adjustment the difference between the previous value and the new				vious value and the new	
	value must r	value must not exceed the value specified in this MD.				

9460	\$MM_PROC	\$MM_PROGRAM_SETTINGS			
MD number	Settings in	the Program	area		
Default setting: H8		Min. input lir	nit: —	Max. input I	imit: –
Change becomes effective after: IMMEDIATELY Pro			Protection level: 3/4		Units: Hex
Data type: LONG			Valid as of software version ShopMill 6.3		
Significance:	Bit 0 to 4: Re	eserved			
	Bit 5: Display hidden lines (;*HD*) in the G code editor				
	Bit 6: Reserved				
	Bit7: Deactivate G-program check (mold making)				

9478	\$MM_TO_OPTION_MASK				
MD number	Settings for ShopMill				
Default setting: 1		Min. input I	imit: 0000	Max. input limit: FFFF	
Change becomes effective	after: POWEF	RON	Protection level: 1	Units: Hex	
Data type: LONG				Valid as of software version	
				ShopMill 7.5	
Significance:	Bit 0: Displa	y tool param	neter "Number of teeth", "	Spindle", "Cooling water" and "Tool-spe-	
	cific function	is" in tool ma	anagement.		
	Bit 1: Reser	ved			
	Bit 2: Displa	y additional	list in the tool manageme	ent	
	Bit 3: Disabl	e creation of	r new tools directly on a r	nagazine location.	
	Bit 4 to bit 6	. Reserved	al paramatora if the teal	a are in the magazine (exception: wear	
	data)	e ealing of it	ou parameters il the tool	s are in the magazine (exception, wear	
	Bit 8: Evalua	ate file TO	All L INI for configuration	of the tool management user interface	
	Bit 9: Disabl	e loading/un	loading of tools if a progr	ram is being executed on the machine	
	Bit 10: Calcu	late tool we	ar data through addition.		
	Bit 11: Rese	rved	5		
	Bit 12: Disat	ole loading a	nd unloading at emerger	ncy off.	
	Bit 13: Displ	ay buffer ma	agazine in turning tool ma	anagement.	
	Bit 14: Rese	erved			
	Bit 15: Disab	ole loading/u	nloading tool on spindle.		
	Bit 16: Rese	erved			
	Bit 17: Hide	softkey "Rel	locate" in magazine list.		
	Bit 18: Hide	softkey "Pos	sition" in magazine list.		
	Bit 19: Rese	ervea	, alive atter and a second a		
	Bit 20: Always load tools directly on spindle.				
	Bit 22: Do p	ay basic len	gin for angle nead mill in occuring probe for the fu	detailed image.	
	Bit 22: Beenred				
	Bit 24: Maga	azine positio	ning in the wear list		
	Bit 25: Maga	azine numbe	er is always displayed in t	he loading and relocation dialog.	

9479	\$MM_TO_M	\$MM_TO_MAG_PLACE_DISTANCE			
MD number	Distance be	etween indivi	idual tool holders		
Default setting: 0		Min. input lir	nit: 0.0	Max. input li	mit: 10000.0
Change becomes effective	after: POWEF	RON	Protection level: 3/4		Units: mm
Data type: DOUBLE				Valid as of s ShopMill 6.3	oftware version
Significance:	You use this MD to specify the spacing between the individual tool holders for the graphical display of the tools and magazine locations in the tool management. 0 = The tools and magazine locations are not graphically displayed.				
	Note: If there are several magazines with different spacing between the tool holders on the ma- chine, the tools cannot be displayed proportionally to all magazines since there is only one setting option for the spacing.				

9480	\$MM_MA_SIMULATION_MODE				
MD number	Switch fast	view on and	l off		
Default setting: -1		Min. input li	nit: —1	Max. input li	mit: 2
Change becomes effective a	after: IMMEDI	ATELY	Protection level: 3/4		Units: –
Data type: BYTE			-	Valid as of s ShopMill 6.4	oftware version
Significance:	This MD is u -1 = The Sh 0 = You can 1 = Fast view 2 = If a progr \$MM_STAN the fast view	used to specifi opMill simula select betwe w is always d ram is smalle D_SIMULAT	fy whether fast view is alwa tion is displayed. en ShopMill simulation and isplayed. er than the limit specified in ION_LIMIT, the ShopMill si	ays active. d fast view . the machine c imulation is cal	lata 9481 Iled, for larger programs

9481 MD number	\$MM_MA_STAND_SIMULATION_LIMIT Limit of the standard simulation in KB				
Default setting: 200	Min. input limit: 200		nit: 200	Max. input limit: 2000000	
Change becomes effective after: IMMEDIATELY		Protection level: 3/4		Units: –	
Data type: INTEGER				Valid as of s	oftware version
				ShopMill 6.4	ļ
Significance:	With this MD,	With this MD, you specify the size as of which the program loads the fast view.			

9602	\$MM_CTM	\$MM_CTM_SIMULATION_DEF_VIS_AREA			
MD number	Simulation	Simulation of default display area			
Default setting: 100	Min. input limit: –10000		nit: –10000	Max. input limit: 10000	
Change becomes effective after: POWER ON		1 ON	Protection level: 3/4		Units: mm
Data type: LONG				Valid as of s	oftware version
				ShopMill 4.3	5
Significance:	This MD defines the size of the display area above the X coordinate. The Y coordinate is calculated automatically from this setting.				

9603 MD number	\$MM_CTM_SIMULATION_MAX_X Simulation of maximum display X				
Default setting: 0 Min. input lim			nit: —10000	Max. input li	mit: 10000
Change becomes effective after: POWER ON			Protection level: 3/4		Units: mm
Data type: LONG			·	Valid as of s	oftware version
				ShopMill 4.3	•
Significance:	Reserved				

9604 MD number	\$MM_CTM_ Simulation	\$MM_CTM_SIMULATION_MAX_Y Simulation of maximum display Y				
Default setting: 0		Min. input lir	nit: —10000	Max. input limit: 10000		
Change becomes effective after: POWER ON			Protection level: 3/4		Units: mm	
Data type: LONG			Valid as of s ShopMill 4.3	oftware version		
Significance:	Reserved					

9605 MD number	\$MM_CTM_SIMULATION_MAX_VIS_AREA Simulation of maximum display area				
Default setting: 1000		Min. input limit: –10000			mit: 10000
Change becomes effective after: POWER ON Protection			Protection level: 3/4		Units: mm
Data type: LONG			Valid as of software version		
	ShopMill 4.3				
Significance:	This machine data defines the second display area above the X coordinate. The Y coordi-				
	nate is calcu	nate is calculated automatically from this setting.			

9626 MD number	\$MM_CTM Settings in	TRACE ShopMill			
Default setting: 0		Min. input lir	nit: 0000	Max. input I	imit: FFFF
Change becomes effective	after: IMMED	ATELY	Protection level: 3/4		Units: Hex
Data type: WORD				Valid as of s ShopMill 7.	software version 1
Significance:	Bit 0: Free Bit 1: Displa only). Bit 2 to bit 1: Bit 13: Displ nostics purp Bit 14 to 16:	y system mes 2: Reserved ay cyclical lea oses only). Reserved	ssages from ShopMill in th ad time of ShopMill betwee	e dialog line (for diagnostics purposes d vertical softkey (for diag-

9639	\$MM_CTM_MAX_TOOL_WEAR			
MD number	Upper input limit fo	r tool wear		
Default setting: 1	Min. inp	ut limit: 0	Max. input limit: 10	
Change becomes effective a	after: IMMEDIATELY	Protection level: 3	3/4 Units: mm	
Data type: DOUBLE			Valid as of software version: ShopMill 6.3	
Significance:	With this MD you define the upper absolute limit for tool wear (length, radius). This means that the total value must not exceed the upper absolute limit when entering the wear value in the tool wear list. The incremental upper limit is defined in MD 9450 \$MM WRITE TOA FINE LIMIT.			

9640 MD number	\$MM_CTM_ENABLE_CALC_THREAD_PITCH Calculation of thread depth if pitch entered						
Default setting: 0		Min. input lin	nit: 0	Max. input li	mit: 1		
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: -							
Data type: BYTE Valid as ShopM					oftware version:		
Significance:	This MD is for calculating thread depth K for a metric thread according to pitch P (mm/rev) and thread type (external/internal thread). 0 = Thread depth K is not calculated 1 = Thread depth is calculated.						

9646 MD number	\$MM_CTM_FACTOR_O_CALC_THR_PITCH Factor for calculating the external thread depth if pitch entered					
Default setting: 0.6134	Min. input limit: – Max. input limit: –				mit: —	
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: –					Units: –	
Data type: DOUBLE				Valid as of s ShopMill 6.4	oftware version:	
Significance: The factor for converting thread pitch to thread depth for metric external threads is defined in this MD.					ternal threads is defined	

9647 MD number	\$MM_CTM_FACTOR_I_CALC_THR_PITCH Factor for calculating the internal thread depth if pitch entered					
Default setting: 0.5413	Min. input limit: – Max. input limit: –					
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: –						
Data type: DOUBLE				Valid as of s ShopMill 6.4	oftware version:	
Significance: The factor for converting thread pitch to thread depth for metric internal threads is defined i this MD.						

9650	\$MM_CMM	POS_COORDI	NATE_S	YSTEM			
MD number	Position of	coordinate syst	em				
Default setting: 0		Min. input limit:	0		Max. inp	ut limit: 4	47
Change becomes e	tective after: IMMED	PIATELY Pr	rotection	level: 3/4		Uni	its: –
Data type: BYTE					Valid as ShopMill	of softwa 4.3	are version
Significance:	This MD is machine. D lation and e interface . The coordir Also note M	used to adapt the epending upon th ntry fields with cir nate system can ta ID 9719 \$MM_CN	coordin le select cle direc ake on ti /IM_OP1	ates system o ed position, all stion data auto ne positions lis FION_MASK, t	f the operat l help displa matically ch sted below. pit 31.	or interfa lys, proc nange or	ace to that of the cess graphics, simu- n the ShopMill user
	Examples: 0: 16:	Vertical milling ma Horizontal milling	achine machin	e, boring mill			
-+Z	+Y ► +X 1 +Z	+Y +X	2	+Z	►+X	3	Y +Z V +X
+Z (4) +X	+Y +X	+Y +Y	6	+X	+Z	7	+X +Y +Z
B	-+Z →+Y ③ +X ▼	+Z ►+Y	19	+X	— ► +Y	+	Z +Y +X
+X + (2) +Y	+Z +Y	+Z		+Y	X Z	19	+Y +Z +X
G [†] Y	+X → _{+Z} (1)	+X +Z +Y	18	+Y	→ +Z	19	+Z +Y
+Y 20 +Z	+X +Z	+) +)	22	+Z	+Y	23	+Z +X +Y



9651 MD number	\$MM_CMM_TOOL_MANAGEMENT Tool management variant					
Default setting: 2		Min. input limit: 1 Max. input limit: 4				
Change becomes effective after: POWER ON Protection level: 3/4					Units: –	
Data type: BYTE				Valid as of s ShopMill 4.3	oftware version	
Significance:	Choice of two	o tool manag	ement variants:	L.		
	2: Tool management without loading/unloading					
	4: Tool mana	gement with	loading/unloading			

9652	\$MM_CMM_TOOL_LIFE_CONTROL						
MD number	Tool monitoring	Tool monitoring					
Default setting: 1	Min. input li	mit: 0	Max. input li	mit: 1			
Change becomes effective a	after: POWER ON	Protection level: 3/4		Units: –			
Data type: BYTE	Valid as of s ShopMill 4.3	oftware version					
Significance:	This MD is used to active 0 = Tool monitoring is no 1 = Tool monitoring is dis	te tool monitoring. t displayed splayed					

9653	\$MM_CMM_ENABLE_A_AXIS						
MD number	Enable 4th axis for op	Enable 4th axis for operator interface					
Default setting: 0	Min. input	limit: 0	Max. input li	mit: 3			
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: –			
Data type: BYTE			Valid as of s ShopMill 4.3	oftware version			
Significance:	Enable fourth axis (e.g.	A axis) for operator interfac	e:				
	0 = 4th axis is not displa	yed on the operator interfa	се				
	1 = 4th axis is displayed	on the operator interface					
	2 = 4th axis is displayed	on the operator interface a	ind can be prog	grammed			
	3 = 4th axis is displayed	on the operator interface c	only for reference	ce point approach			

9654 MD number	\$MM_CMM_SPEED_FIELD_DISPLAY_RES Number of decimal places in the speed input field					
Default setting: 0		Min. input limit: 0			mit: 4	
Change becomes effective	after: IMMEDI	ATELY	Protection level: 3/4		Units: –	
Data type: BYTE				Valid as of s	oftware version	
ShopMill 4.3						
Significance:	This MD is u	ised to stipula	ate the number of decimal p	places in para	neter field S (speed).	

9655	\$MM_CMM_CYC	\$MM_CMM_CYC_PECKING_DIST					
MD number	Retraction distar	Retraction distance for deep hole drilling					
Default setting: -1	Min.	. input lin	nit: —1	Max. input li	mit: 100.0		
Change becomes effective after: IMMEDIATELY Protection level: 3					Units: mm		
Data type: DOUBLE				Valid as of software version ShopMill 4.3			
Significance:	This MD is used to ing. Note: -1 means that the (parameter "V2", r	o detern value fo return di	nine the retraction distanc or the retraction distance stance).	e for deep hole	e drilling with chip break- I on the operator interface		

9656	\$MM_CMM_CYC_DRIL	\$MM_CMM_CYC_DRILL_RELEASE_DIST					
MD number	Retraction distance for	Retraction distance for boring					
Default setting: -1	Min. input I	imit: –1	Max. input li	mit: 10.0			
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: mm			
Data type: DOUBLE		Valid as of software version ShopMill 4.3					
Significance:	This MD is used to deter tion for boring. Note: -1 means that the value face.	mine the distance by which of the retraction distance D	the tool move	es free in X and Z direc-			

9657 MD number	\$MM_CMM_CYC_MIN_CONT_PO_TO_RAD Variation of smallest possible cutter radius in %					
Default setting: 5	Min. input limit: 0 Max. input limit: 50					
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: %	
Data type: WORD				Valid as of s ShopMill 4.3	oftware version	
Significance:	This MD is required for milling contour pockets. This parameter is used to stipulate the percentage by which the radius of the cutter being used may be smaller than the one used for generation.					

9658 MD number	\$MM_CMM_CYC_MAX_CONT_PO_TO_RAD Variation of largest possible cutter radius					
Default setting: 0.01	Min. input limit: 0.0 Max. input limit: 10.0					
Change becomes effective after: IMMEDIATELY Protection level:			Protection level: 3/4		Units: mm	
Data type: DOUBLE				Valid as of s ShopMill 4.3	oftware version	
Significance:	This MD is re amount by w generation.	This MD is required for milling contour pockets. This parameter is used to stipulate the amount by which the radius of the cutter being used may be larger than the one used for generation.				

9659	\$MM_CMM_CYC_DRILL_RELEASE_ANGLE						
MD number	Tool orientati	Tool orientation angle on retraction					
Default setting: -1	1	Min. input lin	nit: —1	Max. input li	mit: 360		
Change becomes effective a	after: IMMEDIA	TELY	Protection level: 3/4		Units: Degrees		
Data type: DOUBLE	Data type: DOUBLE Valid as of software version ShopMill 4.3						
Significance:	This MD is used to determine the spindle position (0360 ⁰) at which the tool, e.g. an inter- nal turning tool, remains in a boring. Note: -1 means that the value for the tool orientation angle can be entered on the operator inter- face.						

9660	\$MM_CMM_ENABLE_PLANE_CHANGE				
MD number	Changing to machining	plane (G17, G18, G19)			
Default setting: 1	Min. input li	mit: 0	Max. input l	imit: 1	
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: –	
Data type: BYTE	Valid as of software version				
			ShopMill 4.3	3	
Significance:	Enable change to machin	ning plane (G17, G18, G19):		
	0 = Changing to machining plane (G17, G18, G19) not possible				
	1 = Changing to machining plane (G17, G18, G19) possible				

9662 MD number	\$MM_CMM_COUNT_GEAR_STEPS Number of gear stages					
Default setting: 1		Min. input limit: 0 Max. input limit: 5				
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –		
Data type: BYTE				Valid as of s	oftware version	
	ShopMill 4.3					
Significance:	This MD is for setting the number of gear steps (0 to 5) for the spindle. The possibility of input in the operator interface is thus restricted.					

9663 MD number	\$MM_CMM_TOOL_DISPLAY_IN_DIAM Display radius/diameter for tool					
Default setting: 1	Min. input limit: 0 Max. input limit: 1					
Change becomes effective after: POWER ON			Protection level: 3/4		Units: –	
Data type: BYTE				Valid as of s ShopMill 4.3	oftware version	
Significance:	This MD is u	sed to define	how the tool should be di	splayed or ent	ered:	
	0 = radius					
	1 = diameter					

9664 MD number	\$MM_CMM_MAX_INP_FEED_P_MIN Maximum feed in mm/min					
Default setting: 10000.0		Min. input limit: 0.0 Max. input limit: 100000.0				
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: mm/min	
Data type: DOUBLE Valid as of software version ShopMill 4.3					oftware version	
Significance:	This MD is u	This MD is used to enter the upper limit for the feed rate input in mm/min.				

9665 MD number	\$MM_CMM_MAX_INP_FEED_P_ROT Maximum feed in mm/rev					
Default setting: 1.0	Min. input limit: 0.0			Max. input limit: 10.0		
Change becomes effective after: IMMEDIATELY			Protection level: 3/4		Units: mm/rev	
Data type: DOUBLE				Valid as of software version		
ShopMill 4.3						
Significance:	This MD is us	This MD is used to enter the upper limit for the feed rate input in mm/rev.				

9666 MD number	\$MM_CMM_MAX_INP_FEED_P_TOOTH Maximum feed in mm/tooth					
Default setting: 1.0		Min. input limit: 0.0			Max. input limit: 5.0	
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: mm/tooth	
Data type: DOUBLE				Valid as of s ShopMill 4.3	oftware version	
Significance:	This MD is u	This MD is used to enter the upper limit for the feed rate input in mm/tooth.				

9667	\$MM_CMM_FOLLOW_ON_TOOL_ACTIVE					
MD number	Tool preselection active	Tool preselection active				
Default setting: 1	Min. input li	mit: 0	Max. input li	mit: 1		
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: –		
Data type: BYTE		·	Valid as of software version			
			ShopMill 4.3			
Significance:	This MD is used to active	ate tool preselection in a m	lagazine (e.g. c	hain magazine); i.e. the		
	following tool is already brought to the loading point for a pending tool change.					
	0 = Tool preselection is not active					
	1 = Tool preselection is a	active				

9668	\$MM_CMM	\$MM_CMM_M_CODE_COOLANT_I_AND_II				
MD number	M function	M function coolant I and II				
Default setting: -1		Min. input lir	nit: —1	Max. input limit: 32767		
Change becomes effective a	after: IMMEDI	ATELY	Protection level: 3/4	Units: –		
Data type: WORD				Valid as of software version ShopMill 4.4		
Significance:	This MD is used to stipulate the M function if in the tools list coolants I and II are both activat the same time. Value: -1 = No M function xy = M function					

9669	\$MM_CMM_FACE_MILL	EFF_TOOL_DIAM		
MD number	Effective cutter diameter	er for face milling		
Default setting: 85.0	Min. input li	mit: 50.0	Max. input li	mit: 100.0
Change becomes effective	after: IMMEDIATELY	Protection level: 3/4		Units: %
Data type: DOUBLE			Valid as of s ShopMill 4.4	oftware version
Significance:	In this MD, you specify th used for plane milling. Th cut diameter and D = larg	e effective cutter diameter e effective cutter diameter lest cutter diameter.	if a tool of type is derived from = 85 = 100 fective milling D = 85/100 = 0	e "Cutter" (120) is to be n the ratio d/D, where d = diameter:).85 -> 85%

9670 MD number	\$MM_CMM_START_RAD_CONTOUR_POCKE Radius of approach circle for finishing contour pockets plus half the final machining allowance (-1 = safety clearance)				
Default setting: -1	Min. input	limit: —1	Max. input I	imit: 100.0	
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: mm					
Data type: DOUBLE			Valid as of software version ShopMill 4.4		
Significance:	This MD affects the radius of the approach circle when finishing contour pockets. -1 = The radius is selected such that the safety clearance for final machining is observed at the start point. >0 = The radius is selected such that the value of this machine data for final machining allowance is observed at the start point.				

9671	\$MM_CMM_TOOL_LOAD_DEFAULT_MAG					
MD number	Load tool in	Load tool in default magazine				
Default setting: 0	Min. input limit: 0 Max. input limit: 30					
Change becomes effective after: POWER ON Protection level: 3/4			Protection level: 3/4		Units: –	
Data type: BYTE				Valid as of software version		
				ShopMill 6.3		
Significance:	In this MD you define the magazine in which ShopMill first searches for an empty location when loading a tool.					

9672	\$MM_CMM	\$MM_CMM_FIXED_TOOL_PLACE					
MD number	Fixed locat	ion coding					
Default setting: 0		Min. input limit: 0			mit: 1		
Change becomes effective after: POWER ON Protection level: 3/4				Units: –			
Data type: BYTE			Valid as of software version				
				ShopMill 4.4	ŀ		
Significance:	This MD def	ines the state	of newly created tools:				
	0 = Tool with variable location coding in the magazine						
	1 = Tools wit	1 = Tools with fixed location coding in the magazine					

9673	\$MM_CMM_TOOL_LOAD_STATION						
MD number	Number of loading poin	Number of loading point					
Default setting: 1	Min. input li	mit: 1	Max. input li	mit: 2			
Change becomes effective	after: POWER ON	Protection level: 3/4		Units: –			
Data type: BYTE		Valid as of software version ShopMill 4.4					
Significance:	This MD is used to stipul loaded and unloaded. (The same loading point.) 1 = Loading point 1 2 = Loading point 2	ate the loading point at which he magazine and the spindle	ch the magazi e are always l	ne and the spindle are oaded/unloaded at the			

9674 MD number	\$MM_CMM Display of r	MM_CMM_ENABLE_TOOL_MAGAZINE Display of magazine list						
Default setting: 1		Min. input limit: 0			mit: 1			
Change becomes effective	after: POWEF	Protection level: 3/4		Units: –				
Data type: BYTE	Valid as of s ShopMill 4.4	oftware version						
Significance:	0 = Magazine list is not displayed 1 = Magazine list is displayed							

9675	\$MM_CMM	\$MM_CMM_CUSTOMER_START_PICTURE					
MD number	Customized	boot scree	n				
Default setting: 0		Min. input limit: 0		Max. input li	imit: 1		
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –			
Data type: BYTE			·	Valid as of software version			
				ShopMill 5.1	1		
Significance:	The custom	ized boot scre	een is activated as follows	:			
	0 = Siemens boot screen						
	1 = Custom	1 = Customized boot screen					

9680 MD number	\$MM_CMM_M_CODE_COOLANT_I M function coolant I					
Default setting: 8		Min. input limit: 0 Max. input limit:				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: -					Units: –	
Data type: WORD				Valid as of software version		
				ShopMill 5.1		
Significance: This MD is used to stipulate the M function for coolant I; this is output when the tool is changed.						

9681	\$MM_CMM	\$MM_CMM_M_CODE_COOLANT_II						
MD number	M function	M function coolant II						
Default setting: 7	Min. input limit: 0			Max. input limit: 32767				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: –								
Data type: WORD				Valid as of software version				
	ShopMill 5.1							
Significance:	This MD is used to stipulate the M function for coolant II; this is output when the tool is changed.							

9682 MD number	\$MM_CMM_ Preboring de	CYC_BGF_ epth for dril	BORE_DIST I and thread milling		
Default setting: 1		Min. input limit: 0			mit: 100
Change becomes effective after: IMMEDIATELY Protection levels			Protection level: 3/4		Units: mm
Data type: DOUBLE				Valid as of s ShopMill 6.2	oftware version
Significance:	This MD defin	nes the preb	oring depth for drill and thr	ead milling.	

9686 MD number	\$MM_CMM M function	\$MM_CMM_M_CODE_COOLANT_OFF M function for coolant OFF						
Default setting: 9		Min. input limit: 0 Max. input limit: 32767						
Change becomes effective after: IMMEDIATELY Protection level: 3/4					Units: –			
Data type: LONG				Valid as of software version				
	ShopMill 6.2							
Significance:	This MD is u	This MD is used to stipulate the M function for switching the coolant OFF; this is output						
	when the too	ol is changed.						

9687	\$MM_CMM	\$MM_CMM_TOOL_MOVE_DEFAULT_MAG					
MD number	Reload too	leload tool in default magazine					
Default setting: 0	tting: 0 Min. input limit: 0		nit: 0	Max. input limit: 30			
Change becomes effective after: POWER ON			Protection level: 3/4		Units: –		
Data type: BYTE				Valid as of software version			
ShopMill 6.3					•		
Significance:	In this MD y	In this MD you define the magazine in which ShopMill first searches for an empty location					
	when reloca	ting a tool.					

9688 MD number	\$MM_CMM	\$MM_CMM_COUNT_GEAR_STEPS_S2					
Default setting: 1	Number of	Min. input limit: 0 Max. input limit: 5					
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: –		
Data type: LONG			1	Valid as of software version			
				ShopMill 6.4			
Significance: This MD is for setting the number of gear stages (0 to 5) for the front spindle. The possibility of input in the operator interface is thus restricted.							

9703 MD number	\$MM_CMM_INDEX_AXIS_4 Axis index for 4th axis						
Default setting: 0	ault setting: 0 Min. input limit: 0			Max. input limit: 127			
Change becomes effective after: IMMEDIATELY Protection level			Protection level: 3/4		Units: –		
Data type: UBYTE			•	Valid as of s	oftware version		
ShopMill 5.3							
Significance:	The number	of the channe	el axis is entered in this M	D.			

9704	\$MM_CMM	\$MM_CMM_INDEX_AXIS_5					
MD number	Axis index f	Axis index for 5th axis					
Default setting: 0		Min. input limit: 0			mit: 127		
Change becomes effective after: IMMEDIATELY Prot			Protection level: 3/4		Units: –		
Data type: UBYTE			•	Valid as of s	oftware version		
ShopMill 5.3							
Significance:	The number	of the channe	el axis is entered in this MI	D.			

9705 MD number	\$MM_CMM Axis index f	\$MM_CMM_INDEX_SPINDLE Axis index for spindle				
Default setting: 4		Min. input limit: 0 Max. input limit: 127				
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –		
Data type: UBYTE				Valid as of software version ShopMill 5.3		
Significance:	The number	he number of the channel axis is entered in this MD.				

9706	\$MM_CMM_GEOAX_ASSIGN_AXIS_4					
MD number	Assignment of 4th axis	Assignment of 4th axis to geometry axis				
Default setting: 0	Min. input li	mit: 0	Max. input li	mit: 3		
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –		
Data type: BYTE				Valid as of software version ShopMill 6.4		
Significance:	In this MD, the 4th axis is assigned a geometry axis. The assignment becomes necessary if you are using the angle offset parameter when measuring a workpiece. 0 = no assignment 1 = 4th axis in the direction of the 1st geometry axis (X) -> A axis 2 = 4th axis in the direction of the 2nd geometry axis (Y) -> B axis 3 = 4th axis in the direction of the 3rd geometry axis (Z) -> C axis					

9707 MD number	\$MM_CMM_GEOAX_ASSIGN_AXIS_5 Assignment of 5th axis to geometry axis					
Default setting: 0		Min. input lir	nit: 0	Max. input li	mit: 3	
Change becomes effective	after: IMMEDI	ATELY	Protection level: 3/4		Units: –	
Data type: BYTE			Valid as of software version ShopMill 6.4			
Significance:	In this MD, t if you are us 0 = no assig 1 = 5th axis 2 = 5th axis 3 = 5th axis	In this MD, the 5th axis is assigned a geometry axis. The assignment becomes necessary if you are using the angle offset parameter when measuring a workpiece. 0 = no assignment 1 = 5th axis in the direction of the 1st geometry axis (X) -> A axis 2 = 5th axis in the direction of the 2nd geometry axis (Y) -> B axis 3 = 5th axis in the direction of the 3rd geometry axis (Z) -> C axis				

9708 MD number	\$MM_CMM_INDEX_SPINDLE_2 Axis index for 2nd spindle (front spindle)					
Default setting: 0		Min. input limit: 1 Max. input limit: 127				
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –		
Data type: BYTE				Valid as of software version		
ShopMill 6.4					ŀ	
Significance:	The number	The number of the channel axis for the front axis is entered in this MD.				

9718	\$MM_CMM_OPTION_M	ASK_2		
MD number	Settings for ShopMill			
Default setting: 0	Min. input lir	mit: 0000	Max. input li	mit: FFFF
Change becomes effective	after: IMMEDIATELY	Protection level: 1		Units: Hex
Data type: LONG			Valid as of s ShopMill 7.1	oftware version
Significance:	Bit 0: Do not jump to Auto for execution. Bit 1: Influence the simula Bit 2: Do not display the b entered. Bit 3 to bit 6: Reserved Bit7: Deactivate the funct for the swivel heads. Bit 8: Reserved Bit 9 to 12: Reserved Bit 13: The correction and	matic mode when an exter ation speed through feed ra basic offset in the measurin ion approaching and depar gle is inverted during boring	nal program (te override. g and progran ting along the I (E DE BOR	from the PLC) is selected n mask and cannot be software limit switches

9719	\$MM_CMM_OPTION_MASK					
MD number	Settings for S	Settings for ShopMill				
Default setting: H5	Ν	Min. input lir	nit: 0000	Max. input l	imit: FFFF	
Change becomes effective a	after: IMMEDIA	TELY	Protection level: 1		Units: Hex	
Data type: LONG				Valid as of s ShopMill 6.4	software version 1	
Significance:	Bit 0 to bit 8: F Bit 9: Start pro Bit 10 to 11: R Bit 12: Display Bit 13 to bit 17 Bit 18: When 0 Bit 19: Instead Bit 20: Display Bit 21: Enable Bit 22 to bit 25 Bit 26: Enable Bit 27: Enable Bit 28 to bit 30 Bit 31: Always handed coordi	Reserved ogram exect Reserved y of all axes 7: Reserved changing M d of "MCS" a y work offse basic reco 5: Reserved b directory "f d directory "C 0: Reserved s display coo linates syste	ution in all screens. (up to 14 axes) anual/MDA/Auto, change and "WCS" display texts "I rts not as "ZO1", but as "G rd display. Part programs" in program Subroutines" in program m ordinates system for G17 em) or down (left–handed	the mode but r Machine" and ' 54" (except in manager. anager. as follows: X to coordinates sy	not the ShopMill interface. "Workpiece". the work offset list). o right, Y up (right– /stem).	

9720	\$MM_CMM_ENABLE_B_AXIS				
MD number	Enable 5th a	axis for oper	ator interface		
Default setting: 0		Min. input lir	nit: 0	Max. input li	mit: 3
Change becomes effective a	after: IMMEDI	ATELY	Protection level: 3/4		Units: –
Data type: BYTE				Valid as of s	oftware version
				ShopMill 5.1	
Significance:	5. Enable fift	h axis (e.g. B	axis) for operator interfac	e:	
	0 = 5th axis i	s not display	ed on the operator interfac	e	
	1 = 5th axis i	s displayed c	on the operator interface		
	2 = 5th axis is displayed on the operator interface and can be programmed				
	3 = 5th axis i	s displayed c	on the operator interface or	nly for reference	ce point approach

9721	\$MM_CMM	ENABLE_T	RACYL			
MD number	Enable sign	Enable signal for cylinder surface transformation				
Default setting: 0		Min. input lir	nit: 0	Max. input li	mit: 1	
Change becomes effective a	after: IMMEDI	ATELY	Protection level: 3/4		Units: –	
Data type: BYTE	a type: BYTE Valid as of software ShopMill 5.1					
Significance:	Enable the c	ylinder surfac	ce transformation function of	on the operato	r interface:	
	0 = The cylin	nder surface t	ransformation function is n	ot displayed o	n the operator interface.	
	1 = The cylin	nder surface t	ransformation function is d	isplayed on th	e operator interface.	
	The cylinder surface transformation function can only be used if it has been started up in the CNC–ISO operator interface.					

9723	\$MM_CMM_ENABLE_SWIVELING_HEAD						
MD number	Enable swiv	Enable swiveling					
Default setting: 0		Min. input lir	nit: 0	Max. input li	mit: 1		
Change becomes effective a	after: IMMED	ATELY	Protection level: 3/4		Units: –		
Data type: BYTE				Valid as of software version ShopMill 5.1			
Significance:	Enable the S	Enable the Swiveling function on the operator interface. 0 = The Swiveling function is not displayed on the operator interface					
	 1 = The Swiveling function is displayed in the operator interface Swiveling can only be used if it has been started up in the CNC–ISO operator interface. 						

9724 MD number	\$MM_CMM_CIRCLE_RAPID_FEED Rapid feed for positioning on circular path					
Default setting: 5000	Min. input li	mit: 0	Max. input li	Max. input limit: 100000		
Change becomes effective after: IMMEDIATELY		Protection level: 3/4		Units: mm/min		
Data type: DOUBLE			Valid as of software version			
			ShopMill 6.2	2		
Significance:	Use this MD to set the ra	Use this MD to set the rapid traverse feed in mm/min for positioning on a circular path.				

9725	\$MM_CMM	_ENABLE_C	UICK_M_CODES				
MD number	Enable fast	Enable fast M functions					
Default setting: 0		Min. input lir	nit: –	Max. input li	mit: –		
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: –		
Data type: BYTE				Valid as of software version ShopMill 6.4			
Significance:	This MD is u by the PLC Bit 0: Coolar Bit 1: Coolar Bit 2: Coolar Bit 3: Coolar	used to enable without confir nt 1 ON nt 2 ON nt 1 and 2 ON nt OFF	e fast M functions. This me mation. I	ans that the M	1 functions are executed		

9727	\$MM_CMM_ENABLE_POS_A_B_AXIS					
MD number	Enable support for A/B	Enable support for A/B axis				
Default setting: 0	Min. input lir	nit: –	Max. input li	mit: –		
Change becomes effective a	Protection level: 3/4		Units: –			
Data type: BYTE				Valid as of software version ShopMill 6.4		
Significance:	This MD is used to deterr grammed for position san 0 = no support of A/B axis > $0 =$ support of A axis for < $0 =$ support of B axis for	This MD is used to determine whether the angle of the A/B axis can also be directly pro- grammed for position samples. 0 = no support of A/B axis for position samples > 0 = support of A axis for position samples, amount = number of channel axis				

9728	\$MM_CMM_DISPL_DIF	A_B_AXIS_INV			
MD number	Adapting to the direction	on of rotation of the A/B a	axis		
Default setting: 0	Min. input li	mit: 0	Max. input li	mit: 1	
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: –	
Data type: BYTE			Valid as of software version ShopMill 6.4		
Significance: With this MD, you can adapt the displayed and executed direction of rotation to the comissioning of the machine axes. The observation of the direction of rotation is carried the direction of the positive coordinate axis. 0 = right (to DIN) 1 = left			of rotation to the com- of rotation is carried out in		

9729 MD number	\$MM_CMM_G_CODE_TOOL_CHANGE_PROG Program name for tool change in the G code				
Default setting: -	Min. input lir	Min. input limit: – Max. input limit: –			
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –	
Data type: STRING (24)		Valid as of s ShopMill 6.4	oftware version		
Significance:	This MD is used to stipulate the program name for the tool change program. The tool change program is automatically called as soon as you have programmed a tool in the G code via softkey.				

9739	\$MM_CMM_M_CODE	TOOL_FUNC_1_ON		
MD number	M code for tool-specific	c function 1 ON		
Default setting: -1	Min. input lir	mit: — 1	Max. input li	mit: 32767
Change becomes effective		Units: –		
Data type: LONG			Valid as of software version	
Significance:	This MD is used to define	an M command for tool-s	pecific functio	n 1.
	The value –1 means that the M function is not output.			
	If both M commands of function 1 =-1, the corresponding field is not displayed on the inter-			
	face.			

9740	\$MM_CMM_M_CODE	TOOL_FUNC_1_OFF				
MD number	M code for tool-specifi	M code for tool-specific function 1 OFF				
Default setting: -1	Min. input I	imit: – 1	Max. input li	mit: 32767		
Change becomes effective		Units: –				
Data type: LONG			Valid as of software version			
				ShopMill 7.1		
Significance:	This MD is used to defin	e an M command for tool–s	pecific functio	n 1.		
	The value –1 means that the M function is not output.					
	If both M commands of function 1 =-1, the corresponding field is not displayed on the inter-					
	face.					

9741	\$MM_CMM_M_CODE	TOOL_FUNC_2_ON		
MD number	M code for tool-specifie	c function 2 ON		
Default setting: -1	Min. input li	nit: – 1	Max. input I	imit: 32767
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –
Data type: LONG			Valid as of software version	
			ShopMill 7.	1
Significance:	This MD is used to define	an M command for tool-s	specific functio	in 2.
	The value –1 means that the M function is not output.			
	If both M commands of function 2 =-1, the corresponding field is not displayed on the inter-			
	face.			

9742 MD number	\$MM_CMM_M_CODE M code for tool–specifi	_TOOL_FUNC_2_OFF c function 2 OFF			
Default setting: -1	Min. input li	Min. input limit: – 1 Max. input limit: 32767			
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –	
Data type: LONG			Valid as of software version ShopMill 7.1		
Significance:	This MD is used to define an M command for tool–specific function 2. The value -1 means that the M function is not output. If both M commands of function 2 = -1 , the corresponding field is not displayed on the interface.				

9743	\$MM_CMM	M_CODE	TOOL_FUNC_3_ON			
MD number	M code for	tool–specific	c function 3 ON			
Default setting: -1	<u>.</u>	Min. input limit: – 1 Max. input limit: 32767			mit: 32767	
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: –	
Data type: LONG	Data type: LONG			Valid as of software version		
				ShopMill 7.1		
Significance:	This MD is u	ised to define	an M command for tool-s	pecific functio	n 3.	
	The value -1 means that the M function is not output.					
	If both M commands of function 3 =-1, the corresponding field is not displayed on the inter-					
	face.					

9744	\$MM_CMM_M_CODE	TOOL_FUNC_3_OFF			
MD number	M code for tool-specific	c function 3 OFF			
Default setting: -1	Min. input lir	Min. input limit: – 1 Max. input limit: 32767			
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –	
Data type: LONG			Valid as of software version		
			ShopMill 7.1		
Significance:	This MD is used to define	an M command for tool-s	pecific functio	n 3.	
	The value –1 means that the M function is not output.				
	If both M commands of function 3 =-1, the corresponding field is not displayed on the inter-				
	face.				

9745	\$MM_CMM	M_CODE	TOOL_FUNC_4_ON			
MD number	M code for	M code for tool-specific function 4 ON				
Default setting: -1		Min. input lir	nit: — 1	Max. input li	mit: 32767	
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: –					Units: –	
Data type: LONG			Valid as of software version			
				ShopMill 7.1		
Significance:	This MD is u	ised to define	an M command for tool-s	pecific functio	n 4.	
	The value –1 means that the M function is not output.					
	If both M commands of function $4 = -1$, the corresponding field is not displayed on the inter-					
	face.					

9746	\$MM_CMM_M_CODE	TOOL_FUNC_4_OFF			
MD number	M code for tool-specifie	c function 4 OFF			
Default setting: -1	Min. input lir	nit: – 1	Max. input li	mit: 32767	
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: -					
Data type: LONG			Valid as of software version		
			ShopMill 7.1		
Significance:	This MD is used to define	an M command for tool-	specific functio	n 4.	
	The value –1 means that the M function is not output.				
	If both M commands of function $4 = -1$, the corresponding field is not displayed on the inter-				
	face.				

9748	\$MM_CMM_MKS_POSITION_MAN_MEAS					
MD number	Position ma	Position man. tool measurement with fixed point				
Default setting: 0		Min. input lir	nit: –	Max. input li	mit: –	
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: mm	
Data type: DOUBLE				Valid as of software version ShopMill 6.4		
Significance:	This MD is used to define the position of the fixed point in the machine coordinate system if a fixed point must be used as reference point for manual tool measuring. The position of the fixed point can also be determined via the function "Manual machine" \rightarrow "Measuring tool" \rightarrow "Adjusting fixed point". The determined position is then automatically entered into this MD.					

9777	\$MM_CMM_ENABLE_T	IME_DISPLAY			
MD number	Enable the time display	Enable the time display			
Default setting: 0x7F	Min. input li	nit: –	Max. input li	mit: –	
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: –	
Data type: BYTE			Valid as of s	oftware version	
			ShopMill 6.4		
Significance:	This MD is used to define	e the display of the runtimes	S.		
	Bit 0: Program progress of	display			
	Bit 1: Display time				
	Bit 2: Display date				
	Bit 3: Display machine runtime				
	Bit 4: Display processing time				
	Bit 5: Display utilization				
	Bit 6: Display program repeats				

Note

For a description of the display machine data for measuring cycles, please refer to Section 9.1.2 "Display machine data measuring cycles".

9855	\$MM_ST_CYCLE_TAP_SETTINGS				
MD number	Thread tapping setting with and without compensation chuck				
Default setting: 0	Min. input limit: –			Max. input limit: –	
Change becomes effective a	after: IMMED	IATELY	Protection level: 3/4	1	Units: –
Data type: WORD				Valid as of s ShopMill 6.3	oftware version 3
Significance:	For thread ta	apping withou	ut compensation chuck	1	
	ShopMill 6.3 For thread tapping without compensation chuck Units digit: Exact response 0: Exact stop response active as before cycle call 1: Exact stop G601 2: Exact stop G603 Tens digit: Feed-forward control 0: With/without feed-forward control active as before cycle call 1: With feed-forward control FFWON 2: Without feed-forward control FFWOF Hundreds digit: Acceleration 0: SOFT/BRISK/DRIVE active as before cycle call 1: With it feed-forward control FFWOF Hundreds digit: Acceleration 0: SOFT/BRISK/DRIVE active as before cycle call 1: Without jerk limiting SOFT 2: Without jerk limiting BRISK 3: Reduced acceleration DRIVE Thousands digit: MCALL 0: For MCALL Reactivate spindle operation 1: Remain in position control for MCALL For thread tapping with compensation chuck (see chapter 11.4 Analog spindles) Units digit: Exact response 0: Exact stop G603 Tens digit. Feed-forward control 0: With/without feed-forward control 0: With/without feed-forward control 0: With/without feed-forward control active as before cycle call 1: Exact stop G603 <td>nalog spindles)</td>			nalog spindles)	

9999 MD number	\$MM_TRACE Test flags for internal diagnosis				
Default setting: 0 Min. i		lin. input limit: 0000		Max. input limit: FFFF	
Change becomes effective after: POWER ON		١	Protection level: 1/1		Units: Hex
Data type: WORD				Valid as of software version ShopMill 6.3	
Significance:	Bit 0: Reserved Bit 1: Display system messages from HMI in the dialog line (for diagnostics purposes only). Bits 2 to 4: Reserved				

Space for your notes

8

Tool Management

8.1 Overview of functions

Option	ShopMill only runs when the tool management option is set. This is contained within the ShopMill package. The option is contained in the machine data block for ShopMill.		
	References: /FBW/, Description of Tool Management Functions		
Data	Data storage and management is carried out in the NCK. All data can be read and written by manual entry, via the initialization program, or by data transfer.		
Operation	Operation is performed via system screens.		
Programming	When using tool management it is possible to call the tool with another name, e.g. "Milling cutter 120 mm". It is still possible to call the tool via a T No. (tool number). The T no. is then the name of the tool.		
PLC	Separate PLC blocks are available for tool management to handle communica- tion between NCK and PLC.		
Tools	For ShopMill on NCU (HMI Embedded sl), a maximum number of 250 tools can be created. For PCU 50.3 (HMI Advanced), the maximum number of tools is limited by MD 18082 \$MN_MM_NUM_TOOL. 9 cutting edges each can be defined for each tool.		
Replacement tools	Maximum 98 replacement tools can be set up for each tool.		
Magazine	Chain and disk-type magazines can be managed. The maximum number of magazines is set in the NC. The magazine list can be hidden via the display MD 9674 \$MM_CMM_ENABLE_TOOL_MAGAZINE.		

Overview of functions

8.1

Location coding	Display MD 9672 \$MM_CMM_FIXED_TOOL_PLACE determines whether all tools have a fixed or variable location coding.				
	• Fixed location coding (MD 9672, value 1) means that the tool is permanently assigned to a magazine location. This concept can be used for machines with disk-type magazine.				
	 For variable location coding (MD 9672, value 0), a tool with a tool number or tool name can be returned to a different magazine location from its original one. This variant can be used for machines with chain magazine. Individual tools can be set to fixed location coding on the operator interface (tool wear). 				
Magazine location blocking	Magazine locations can be blocked, e.g. for oversized tools occupying adjacent magazine locations.				
Monitoring functions	The tool management system includes a tool monitoring function that monitors based on cutting edges either by tool life, tool loading operations or wear. Replacement tools (sister tools) are distinguished by their Duplo number (DP). The tool monitoring can be deactivated via the display MD 9652 \$MM_CMM_TOOL_LIFE_CONTROL. The wear monitoring is activated via the MD 18080, bit 5.				
Tool management without loading/ unloading	Tool management without the load/unload softkey can be set by means of value 2 in display MD 9651 \$MM_CMM_TOOL_MANAGEMENT.				
Tool management with loading/ unloading	Tool management with the load/unload softkey can be set by means of value 4 in display MD 9651 \$MM_CMM_TOOL_MANAGEMENT.				
Load	Loading brings the tool to its magazine location.				
Unload	Unloading removes the tool from the magazine.				
Sorting	Tools can be sorted in the tool list and the tool wear list according to magazine location, name, type, and tool number.				
Manual tools	Manual tools are tools that are stored in the tool list but not in the magazine. These tools must be attached/detached manually to/from the spindle.				

8.1 Overview of functions

Other functions

- Loading/unloading point for tools by means of display MD 9673 \$MM_CMM_TOOL_LOAD_STATION
- Number of input fields for tool–specific functions by means of display MD 9661 \$MM_CMM_ENABLE_CUSTOMER_M_CODES
- Display tools as diameter or radius via display MD 9663 \$MM_CMM_TOOL_DISPLAY_IN_DIAM

Modifying data

Note

Modifications to the tool and cutting edge data via system variables in the part program are displayed in the tool list on the ShopMill operator interface only if they refer to the tool currently loaded in the spindle. 8.2 Commissioning sequence

8.2 Commissioning sequence

You can either commission tool management together with ShopMill commissioning (see Section 4.2 "First Commissioning Sequence") or subsequently.

To commission tool management, proceed as follows:

- 1. NCK commissioning
- 2. PLC commissioning
- 3. Adapt display machine data
- 4. Create tool-changing cycle

If your machine already features a tool management, you do not have to install a separate tool management for ShopMill. That is, the commissioning of NCK, PLC and tool–changing cycle is omitted, only the display machine data have to be adapted.

For a precise description of tool management commissioning, please refer to: **References:** /FBIW/, Description of Functions Tool Management

Note

With PCU 50.3 you can also commission tool management (generating configuration file and PLC data) via the CNC–ISO operator interface.

References: /FBW/, Description of Tool Management Functions

8.3

Commissioning in NCK

Requirements

• PCU commissioning is performed and the connection to the NCK established.

8.3

NCK commissioning is carried out with the default machine data.

Implementation

- Enter the NCK machine data for tool management.
- Create a new configuration file for tool management or use and adapt the examples from the toolbox.
- Load the configuration file in the control.

8.3.1 Entry of NCK machine data

In order to use tool management the machine data for memory setting and for activating tool management must be set.

Machine data for
memory settingMemory space must be made available for tool management in the battery-
backed RAM.

The following machine data must be set:

MD 18080	Activate the memory for the tool management
MD 18082	Number of tools to be managed by the NCK
MD 18084	Number of magazines that the NCK can manage (min. 3);
	include intermediate memory and loading magazine in the count!
MD 18086	Number of magazine locations that the NCK can manage;
	include 3 intermediate memory locations (2 gripper and 1 spindle) and
	2 load locations in the count!
MD 18100	Number of cutting edges in the NCK

Note

ShopMill can manage 9 cutting edges per tool. Define the total number of all available cutting edges in MD 18105 MM_MAX_CUTTING_EDGE_NO. It is not necessary to enter the number of tools multiplied by 9 cutting edges. You can simply specify approximately how many cutting edges you will need in total.

Allocation of machine data for use with a dual gripper so that manual tools can be				
applied even with a completely allocated magazine (30 locations):				
18082=40;	40 tools (30 tools for the magazine + 10 tools as manual tools)			
18084=3;	1 magazine + 1 buffer magazine + 1 loading magazine			
18086=35;	30 magazine locations + 3 buffers + 2 loading locations			
18100=80;	80 cutting edges			

Note

The machine data settings serve only to reserve memory; locations are not assigned to the magazine, etc. until the configuration file is set up and loaded (see Section 8.3.3 "Creating and Loading the Configuration File").

Modifying the "memory-influencing" machine data also reformats the battery-backed RAM. Data must therefore be backed up in advance.

Machine data for activating tool	In addition, the following machine data must be set for activating the tool man- agement:			
management	MD 20310	Channel-specific activation of TM		
	MD 20320	Activation of tool life monitoring for the listed spindle		
	MD 20520	New teal offact for M function		
	MD 22550	M function for tool change		
	MD 22500			
	Note			
	Bits 0–3 of MD 20310 \$MC_TOOL_MANAGEMENT_MASK and MD 18080 \$MN_MM_TOOL_MANAGEMENT_MASK must always be set identically.			

Default

For a detailed description of the NCK machine data of the tool management, see the following chapter 8.3.2 "Description of NCK machine data for tool management".
8.3.2 Description of NCK machine data

18080	MM_TOOL_MANAGEME	NT_MASK				
MD number	Activate the memory for to	Activate the memory for tool management				
Default setting: 0x0	Min. input limit:	0	Max. in	nput limit: 0xFFFF		
Change becomes effective a	fter: POWER ON	Protection level: 1/4		Units: HEX		
Data type: DWORD		Valid as of software ver	rsion: 4.3	3		
Significance:	Activation of the tool mana	agement memory with "0	" means	:		
	The tool management dat	a set does not occupy ar	ny memo	ory; tool management is not		
	available.					
	Bit 0=1: Memory for data specific to tool management is available; the MDs for reser memory must be set accordingly (18086 MM_NUM_MAGAZINE_LOCATION, 18084 MM_NUM_MAGAZINE)					
	Bit 1=1: Memory is availab	ole for monitoring data				
	Bit 2=1: Memory is available for user data (CC data)					
	Bit 3=1: Memory is available for considering the adjacent location					
	Bit 4=1: Memory and function release for PI service _N_TSEARC = "Complex search for tools in magazine" is available.					
	Bit 5=1: Wear monitoring active (SW5 and later, 840D)					
	Bit 6=1: Wear grouping available (SW5 and later, 840D)					
	Bit 7=1: Reserve memory for magazine location adapters					
	Bit 8=1: Memory for opera	tion and/or setup correc	tions			
	Bit 9=1: Tools in a turret no longer vacate their turret location on tool change (in the display)					
	The coded type of memory reservation enables economic use of memory management for the functionality provided.					
	Example: Standard memory reserva MD = 3 (bit 0 + 1=1) mear	tion for tool managemen is tool management and	nt: tool mor	nitoring data are available		
	MD = 1 means tool manag	gement without tool moni	itoring da	ata		

18082	MM_NUM_TOOL			
MD number	Number of tools the NCK	Number of tools the NCK can manage		
Default setting: 40	Min. input limit: 0 Max. input limit: 600			iput limit: 600
Change becomes effective a	fter: POWER ON	Protection level: 2/4		Units: —
Data type: DWORD		Valid as of software version: 2.		
Significance:	The number of tools which the NCK can manage is entered here. The maximum number of tools equals the number of cutting edges in the NCK. Battery-backed memory is reserved for the number of tools.			
Additional references	Description of functions: Memory Configuration (S7), Tool Offset (W1)			

01/2008

18084	MM_NUM_MAGAZINE				
MD number	Number o	Number of magazines the NCK can manage			
Default setting: 3		Min. input limit:	0	Max. ir	nput limit: 32
Change becomes effective at	after: POWER ON Pr		Protection level: 2/4		Units: —
Data type: DWORD	Valid as of software version: 2.				
Significance:	Number of magazines that the NCK can manage (active and background magazines). This MD is used to reserve battery-backed memory for the magazines.				
	Important: One load magazine and a buffer magazine is set up in the tool management for each TOA unit. These magazines must be taken into account.				
	Value = 0: Tool management cannot be active because no data can be created.				
Additional references	Description of functions: Memory configuration (S7)				

10000	NANA NILIN				
18080	MM_NOM_MAGAZINE_LOCATION				
MD number	Number of	Number of magazine locations the NCK can manage			
Default setting: 35		Min. input limit: 0 Max. input limit: 600			put limit: 600
Change becomes effective at	iter: POWER ON Protection level:		Protection level: 2/4	Units: —	
Data type: DWORD	Valid as of software version: 2.				
Significance:	Number of magazines the NCK can manage. This MD reserves the battery-backed memory for the magazine locations.				
	Important: The locations in the intermediate memory and a loading magazine must be taken into account.				
	Value = 0: Tool management cannot be active because no data can be created.				
Additional references	Description of functions: Memory Configuration (S7)				

18100	MM_NUM_CUTTING_EDGES_IN_TOA			
MD number	Number of tool cutting edges per TOA block			
Default setting: 80	Min. input limit:	0	Max. inpu	ut limit: 1500
Change becomes effective at	fter: POWER ON	Protection level: 2/4	U	Jnits: —
Data type: DWORD		Valid as of software ver	sion: 2.	
Significance:	This MD is used to stipula For each tool – irrespectiv 250 bytes per TOA block of Tools with cutting edges of cutting edge. Example: Define 10 grinding tools ea The following minimum ref MM_NUM_TOOL = 10 MM_NUM_TOOL = 10 See also MM_NUM_TOO Special cases: If this machine data	te the number of cutting e e of the tool type – this m of the battery–backed me f type 400–499 (=grinding ach with one cutting edge quirements apply: DGES_IN_TOA = 20 L is altered the buffered da	edges in th nachine da emory. g tools) ad e. ta is lost.	ne NCK. tta reserves approximately ditionally occupy space for a
	References: /FBW/, '	Description of Tool Mana	igement Fi	unctions"
Additional references	Description of functions	s: Memory Configurati	on (S7)	

20310	TOOL_MA	NAGEMENT_MASK	
MD number	Channel-s	pecific activation of tool manage	ement
Default setting: 0x0,		Min. input limit: 0	Max. input limit: 0xFFFFF
Changes effective after PO	WER ON	Protection level	: 2/4 Units: HEX
Data type: DWORD		Va	alid as of software version: 2
Significance:	MD = 0:	Tool management inactive	
	Bit 0=1:	Iool management active	a are enclosed for the current channel
		The tool management function	is are enabled for the current channel.
	Bit 1=1:	Tool monitoring function active	
		The functions for monitoring th	e tools (tool life and
		workpiece count) are enabled	
	Bit 2=1:	OEM functions active	
		I ne memory can be used for 1	ne user data
	Bit 3=1	Consider adjacent location ac). tive
	Dit 0-11	Bit 0 to bit 3 must be set in M	D 18080
		MM_TOOL_MANAGEMENT_	MASK.
	Bit 4=1:	The PLC can request tool cha	nge preparation again with modified
		parameters.	
	With T sel	ection or M06 the part progra	m nauses until acknowledged by the PLC
	program	colori or moo the part progra	in pauloes and asknowledged by the F 20
	1 3		
	Bit 5=1:	When the tool command is our	tput the main run of the main spindle can be
	D	stopped within one OB1 cycle	(e.g. by read-in halt).
	Bit 5=0:	When the command is output	to the PLC the main run of the main spindle is
	Bit 6=1	When the tool command is ou	tout the main run of the auxiliary spindle can be
	Dit 0-11	stopped within one OB1 cycle	(e.g. by read-in halt).
	Bit 6=0:	When the command is output	to the PLC the main run of the main spindle is
		resumed.	
	Bit 7=1:	The main run of the main spin	dle is halted
	Bit 7–0	When the command is output	to the PLC the main run of the main spindle is
	Dit 7 =0.	resumed.	
	Bit 8=1:	The main run of the auxiliary s	pindle is halted until acknowledgment with
		status 1 is received via FC7, F	FC8.
	Bit 8=0:	When the command is output	to the PLC the main run of the auxiliary spindle is
	Rit Q.	Reserved 10-1: M06 is do	laved until "prepare change" is received
	51.5.	via FC8 (status 1) from the PL	C.
		The change signal (e.g. M06)	is only output
		when tool selection (DBX [n+	0].2) is acknowledged. The part program is
		halted with M06 until tool selec	ction is acknowledged.
	BIt 10=0:	I ne tool change ON command	a NCK -> PLC is not output until the PLC
		PI C command 3 (i.e. program	ming of M06 in a
		block containing no T).	
	Bit 11=1:	The preparation command is o	output even if it has already been issued once for
		the same tool.	
		I his system is used to position	The chain with the first "Ix"
		location (e.g. in front of the ch	anging station)
	Bit 11=0:	The preparation command car	be output only once for a tool
	Bit 12=1:	The preparation command is e	executed even if the tool is already in the spindle.
		This means that the T selection	n signal (DB72.DBXn.2) is set
		even if it has already been set	once for the same tool. (TxTx)
	Bit 12=0:	The preparation command is r	not executed if the tool is already inserted in the
		spinale.	

8 Tool Management

20310	TOOL MA	NAGEMENT MASK
MD number	Channel-s	pecific activation of tool management
Significance:	Bit 13=1:	Only for systems with sufficient memory capacity. Recording of
-		tool sequences in a diagnostics buffer. On reset the commands are transferred
		from the diagnostics buffer to the passive file system (NCATR xx.MPF under
		part program).
		This file is required by the Hotline.
		Tool sequences are recorded in the diagnostics buffer only on systems with
		sufficient memory (NCU572, NCU573).
	Bit 14=1:	An automatic tool change takes place on Reset and Start in accordance
		With the following machine data
		MD 20120 TOOL_RESET_NAME
		If the tool specified in TOOL BESET NAME is to be loaded (this is set in
		RESET MODE MASK), a tool-change command is output to the application
		interface on RESET or START (DB72).
		If RESET MODE MASK is set to retain the active tool and if the active tool is
		disabled in the spindle (by the user), a tool-change command for a
		replacement tool is output to the application interface.
		If no replacement tool is available,
		an error message is output.
	Bit 14=0:	No automatic tool change takes place on RESET and START.
	Bit 15=1:	The tool is not returned in response to several preparation commands
		(IX->IX). This method of function activation normite various combinations
		Finis method of function activation permits various complitations.
		MD 20310 TOOL MANAGEMENT MASK -3 (Bit0 $\pm 1 - 1$)
		Bit16=1: T location number is active
	Bit 15=0:	The tool is not returned.
	Bit 16=1:	T=location number is active.
	Bit 17=1:	Tool life decrementation can be started/stopped via the PLC in channel
		DB 2.1DBx 1.3.
	Bit 18=1:	Activation of monitoring
		"last tool in tool group".
	Bit 18=0:	No monitoring for "last tool in tool group"
	Bit 19=1:	Activation for bit 58
	Bit 19=0:	Functions described under bits 58 are not available.
	Bit 20=0:	The commands generated on PLC signal program testing active are not
		Magazine and tool data are not changed. Excention: The status
		of the tool activated in the test area can be changed to "active"
	Bit 20=1:	On PLC signal "program testing active" the commands generated are output
		to the PLC. In so doing, depending on the type of PLC acknowledgment,
		tool/magazine data in the NCK may be altered. If the acknowledgment
		parameters for the target magazine are set with the same values as the source
		magazine, the tool is not transported and thus no data is modified in the NCK.
		Exception: The status of the tool
	D'L OL O	activated in the test area can be changed to "active".
	Bit 21=0:	Ignore tool status "W" on tool selection.
	DIL 21=1:	tool change or tool proparation command
	Bit 22-0	Default setting
	Bit 22=0	If the function $T=$ "I ocation" (see Bit 16) is active, the tool groups are
		automatically divided into subgroups. \$TC_TP11 is the
		grouping and selection parameter. On transition to replacement tool
		only those tools in the tool group are recognized as replacement tools
		that in the \$TC_TP11-value have at least one bit of the tool
		set to the programmed location.
	Bit 23=0	Default setting
		Iool management selects the tool in the main run with optimum certainty; i.e.
		the interpreter must, it correction is required, wait for the end of tool selection.
	BIT 23=1	For single applications
		ine interpreter selects the tool itself, i.e. it correction is required, no synchron-
		the tool becomes no longer usable, a non-correctable alarm may result)
		the tool becomes no longer usable, a non-correctable alarm may result.)

20320 MD number	TOOL_TIME_MONITOR_MASK Activation of tool life monitoring for the spindle here specified			
Default setting: 1/2	Min. input limit: 1 Max. input limit: 4			put limit: 4
Change becomes effective at	ter: POWER ON	Protection level: 2/4	•	Units: —
Data type: DWORD	Valid as of software version: 2			
Significance:	Value = 1: Monitoring is carried out for spindle 1.			
	Value = 2: Monitoring is carried out for spindle 1 and spindle 2.			
Additional references	Description of functions: Memory Configuration (S7)			

22550	TOOL CHANGE MODE				
MD number	New tool offset for M funct	New tool offset for M function			
Default setting: 0	Min. input limit:	0	Max. input limit: 1		
Change becomes effective at	fter: POWER ON	Protection level: 2/4	Units: —		
Data type: BYTE		Valid as of software ver	sion: 1.1		
Significance:	A tool is selected in the pr determines whether the ne MD = 0 The new tool is changed in turning machines with tool MD = 1 The new tool is prepared 1 milling machines with a too position without interruptin The M function entered in from the spindle and loads change must be programm	ogram with the T function ew tool is loaded immedia mmediately with the T fur I turrets. for changing with the T fur ol magazine, in order to b og the machining process MD 22560 TOOL_CHAN is the new tool into the spi ned with the M function N	n. The setting in this machine data ately on execution of the T function: nction. This setting is used mainly on pring the new tool into the tool change IGE_M_CODE removes the old tool ndle. According to DIN 66025, this tool 106.		
Corresponding to	MD 22560 TOOL_CHANC	GE_M_CODE			
Additional references	Description of functions: C	Coordinate Systems (K2)			

22560	TOOL_CHANGE_M_CODE					
MD number	M function for	or tool change	Э			
Default setting: 6		Min. input lir	nit: 0		Max. input li	mit: 9999 9999
Changes effective after PO	WER ON		Protection le	evel: 2/4		Units: –
Data type: DWORD	Valid as of software version: 1.1				on: 1.1	
Significance:	This MD is only effective if MD 22550 TOOL_CHANGE_MODE = 1. If the T function is used only to prepare a new tool for a tool change (this setting is used mainly on milling machines with a tool magazine, in order to bring the new tool into the tool change position without interrupting the machining process), the tool change must be initi- ated with an additional M function. The M function entered in the MD initiates the tool change (remove old tool from the spindle and load the new tool in the spindle). This tool change is required to be programmed with M function M06, in accordance with DIN66025.					
Corresponding to	MD 22550 T	OOL_CHAN	GE_MODE			
Additional references	Description	of functions: ⁻	Tool Offset (W	/1)		

8 Tool Management

22562	TOOL CH	ANGE ERROR MODE				
MD number	Error reacti	on with programmed tool chan	ge			
Default setting: 0		Min. input limit: 0	Max. input li	mit: 3		
Changes effective after PO	WER ON	Protection leve	l: 2/4	Units: –		
Data type: DWORD		V	alid as of software versi	on: 5.1		
Significance:	If MD 2255	0 is set to 0, the default setting	of MD 22562 should no	t be altered.		
5	Bit 0=0:	Standard response:				
		The stop occurs on the NC re	cord where the error oc	curred.		
	Bit 0=1:	If the error occurs in the recorr concerning the preparation correparation command (M06) in At that time, the alarm is issued It is therefore not possible for reached.	rd with the tool change p ommand (T) is ignored u is being interpreted in th ed that was initiated by t the user to make correc	preparation, the alarm ntil the corresponding tool e program flow. he preparation command. ctions until this block is		
	Bit0 = 1:	With active tool management only: In preparing tool changes, the NCK detects only tools with data assigned to a magazine				
	Bit1 = 1:	Only with active tool management: The NCK even loads a tool whose data are known in the NCK, but which are not assigned to a magazine. In this case, the NCK attempts to automatically assign the tool data to the programmed spindle location.				
	Bit 2 = 0	In case of several loadable tools, an active tool is searched again. If none is available, the tool with the lowest Duplo number is selected. active D no. > 0 and active T no. = 0 results in offset zero active D no. > 0 and active D no. = $0 = 0$ results in the log offset zero.				
	Bit 2 = 1	active D no. > 0 and active T active D no. > 0 and active T	no. = 0 results in an alar D = 0 results in an alar	rm message arm message		
	Bit 3 and 4 on program	4: Only significant if tool management is active. Response of init. block generation am START if blocked tool is on the spindle and it is to be activated. See here in				
	\$MC STAF	RT_MODE_MASK and \$MC_R	ESET MODE MASK.			
	At RESET affected.	in particular, the response 'leav	ve disabled tool' active o	n the spindle is not		
	Bit 3 = 0	If the tool on the spindle is blo requests a replacement tool.	ocked: Generate tool cha If there is none an alarm	ange command that i is output.		
	Bit 3 = 1	The blocked status of the spir following part program should with the blocked tool.	ndle tool is ignored. The I be formulated such tha	tool becomes active. The t no parts are machined		
	Bit 4 = 0 Bit 4 = 1	An attempt is made to activate If the tool on the spindle is blo	e the spindle tool and its ocked T0 is programmed	replacement tool. I in the start init. block.		
Corresponding to	MD 22550	TOOL CHANGE MODE				
Additional references	Description	of functions: Tool Offset (W1)				

Examples

8.3.3 Creating and loading the configuration file

A configuration file must be created and loaded in the NCK for the commissioning of tool management.

Create a new configuration file for tool management or adapt the examples given in the Toolbox.

Note

Make sure that you adapt the data in the configuration file to match the machine data for tool management.

The configuration file must include the following settings:

- Define the type of search strategy
- Define the real magazine
- Define buffer magazine
- Define load magazine
- Define locations for the real magazine
- Define locations for the buffer magazine
- Define the spindle assignment
- Define the locations for the load magazine
- Define the distances for the real magazine

Transfer the configuration file to the NCK.

The following examples are contained in the toolbox under \ShopMill_Turn:

- TM_WO_GR.8X0 (configuration without dual gripper, e.g. for a disk-type magazine) containing the following:
 - 1 real magazine with 30 locations
 - 1 spindle
 - 2 loading points
- TM_W_GR.8X0 (configuration with dual gripper, e.g. for a chain magazine) containing the following:
 - 1 real magazine with 30 locations
 - 1 spindle
 - 2 grippers
 - 2 loading points

If necessary, adapt the configuration files in the lines typed in **bold** print.

```
Configuration file
                    % N TO TMA INI
TM_W_GR.8X0
                    CHANDATA (1)
                     ;Magazine configuration
                    ;Delete old data
                    $TC MAP1 [0]=0
                    $TC DP1 [0,0]=0
                    ;Type of search strategy
                    $TC MAMP2=257
                                           ; search for active tools
                                           ; 1st location forward
                    ;Magazine definition
                    ;-
                    ;Real magazine
                    $TC MAP1 [1]=1
                                           ; Magazine type (1: chain)
                    $TC MAP3 [1]=17
                                           ; Magazine status (17: active maga-
                    zine
                                           ; enabled for loading)
                    $TC MAP6 [1]=1
                                           ; Number of magazine rows
                    $TC MAP7 [1]=30
                                           ; Number of locations
                    ;Buffer magazine
                    $TC MAP1 [9998]=7
                                           ; Magazine type (7: buffer)
                    $TC_MAP3 [9998]=17
                    $TC_MAP6 [9998]=1
                                           ; number of buffer locations
                    $TC_MAP7 [9998]=3
                                           ; (3: spindle with dual gripper)
                    ;loading magazine
                    $TC MAP1 [9999]=9
                                           ; magazine type (9: loading magazine)
                    $TC_MAP3 [9999]=17
                    $TC MAP6 [9999]=1
                    $TC_MAP7 [9999]=2
                                           ; Number of loading points
                    ;Locations in the real magazine
                    ; Location no. 1
                    $TC_MPP1 [1,1]=1
                                           ; Location type (1: magazine loca-
                    tion)
                    $TC MPP2[1,1]=1
                                           ; Location type
                    $TC_MPP3[1,1]=1
                                          ; Adjacent location view (1: on)
                    $TC_MPP4 [1.1]=2
                                          ; Location status (2: Location free)
                    $TC_MPP5 [1,1]=1
                                           ; Location type index (1: Location
                    no. 1)
                    ; Location no. 2
                                           ; Location type (1: magazine location)
                    $TC MPP1 [1,2]=1
                    $TC_MPP2 [1.2]=1
                                           ; Location type
                    $TC MPP3 [1.2]=1
                                           ; Adjacent location view (1: on)
                    $TC_MPP4 [1,2]=2
                                           ; Location status (2: Location free)
                    $TC_MPP5 [1,2]=2
                                           ; Location type index (2: Location no. 2)
```

```
; Location no. 3
$TC MPP1 [1,3]=1
                    ; Location type (1: magazine location)
$TC MPP2 [1.3]=1
                     ; Location type
                     ; Adjacent location view (1: on)
$TC MPP3 [1.3]=1
$TC MPP4 [1,3]=2
                    ; Location status (2: Location free)
$TC_MPP5 [1,3]=3
                    ; Location type index (3: Location no. 3)
; Location no. 29
$TC MPP1 [1,29]=1
                     ; Location type (1: magazine location)
$TC MPP2 [1.29]=1
                     ; Location type
$TC MPP3 [1.29]=1
                     ; Adjacent location view (1: on)
$TC MPP4 [1,29]=2
                      ; Location status (2: Location free)
                      ; Location type index (29: Location no. 29)
$TC MPP5 [1,29]=29
; Location no. 30
$TC MPP1 [1,30]=1
                      ; Location type (1: magazine location)
$TC MPP2 [1.30]=1
                      ; Location type
                     ; Adjacent location view (1: on)
$TC_MPP3 [1.30]=1
$TC_MPP4 [1,30]=2
                     ; Location status (2: Location free)
$TC_MPP5 [1,30]=30
                      ; Location type index (30: Location no. 30)
;Locations in the buffer magazine
:-
;Spindle
$TC MPP1 [9998,1]=2
                    ; Location type (2: Spindle)
                    ; Location type
$TC MPP2 [9998,1]=0
                     ; Consider adjacent location
$TC MPP3 [9998,1]=0
$TC MPP4 [9998,1]=2
                     ; Location status (2: Location free)
$TC_MPP5 [9998,1]=1 ; Location type index (1: Location no. 1)
;Gripper 1
$TC MPP1 [9998,2]=3 ; Location type (3: Gripper)
$TC MPP2 [9998,2]=0
                     ; Location type
                     ; Consider adjacent location
$TC MPP3 [9998,2]=0
$TC MPP4 [9998,2]=2 ; Location status (2: Location free)
$TC_MPP5 [9998,2]=1 ; Location type index (1: Location no. 1)
;Gripper 2
$TC_MPP1 [9998,3]=3 ; Location type (3: Gripper)
$TC_MPP2 [9998,3]=0
                    ; Location type
                    ; Consider adjacent location
$TC_MPP3 [9998,3]=0
                    ; Location status (2: Location free)
$TC MPP4 [9998,3]=2
$TC_MPP5 [9998,3]=2
                      ; Location type index (2: Location no. 2)
;Assignment of buffers to spindle
;-
$TC_MLSR [2,1]=0
                      ; 1st gripper
                      ; 2nd gripper
$TC_MLSR [3,1]=0
;Locations in the loading magazine
;1st loading station
$TC MPP1 [9999,1]=7
                      ; Location type (7: Loading point)
$TC_MPP2 [9999,1]=0
                     ; Location type
$TC_MPP3 [9999,1]=0 ; Adjacent location view
$TC_MPP4 [9999,1]=2 ; Location status (2: Location free)
$TC_MPP5 [9999,1]=1 ; Location type index (1: Location no. 1)
```

	<pre>;2nd loading station \$TC_MPP1 [9999.2]=7 ; Location type (7: Loading point) \$TC_MPP2 [9999.2]=0 ; Location type \$TC_MPP3 [9999.2]=2 ; Location status (2: Location free) \$TC_MPP4 [9999.2]=2 ; Location type index (2: Location no. 2) ;Distances between load points/buffers and real ;magazine ; \$TC_MDP2 [1,1]=0 ; Spindle \$TC_MDP2 [1,2]=0 ; Gripper 1 \$TC_MDP2 [1,3]=0 ; Gripper 2 \$TC_MDP1 [1,1]=0 ; 1st loading point \$TC_MDP1 [1,2]=0 ; 2nd loading point</pre>						
	M17						
Variable description	The main variables for the configuration file are described here. For a detailed description of the system variables, please refer to:						
	References: /FBW/, Description of Tool Management Functions						
Magazine data	\$TC_MAP1[MagazineNo]= Magazine type						
	• 1: Chain						
	3: Revolver						
	• 5: Flat magazine						
	7: Internal magazine tool buffer						
	9: Internal magazine loading station						
Magazine data \$TC_MAP3	<pre>\$TC_MAP3[MagazineNo]= Magazine status</pre>						
	Bit mask (specification applies for bit=1):						
	Bit 0: Active magazine						
	Bit 1: Blocked						
	Bit 2: Magazine is at load position						
	Bit 3: Tool motion is active						
	Bit 4: Enabled for loading						
	Default = 17 means: Active magazine, enabled for loading						
Magazine data \$TC_MAP6	Number of magazines (in this case: 1)						
Magazine data \$TC_MAP7	Number of locations, e.g. number of buffer locations: 3 = 1 spindle and 2 grippers						

Search strategy \$TC_MAMP2

\$TC MAMP2= Type of search strategy

This mask is divided into a right and left byte.

- The right byte describes the tool search (bits 0 and 1).
- and the left byte describes the empty location search for the spindle tool.

A value must be specified for both strategies.

Bit mask (specification applies for bit=1):

- Bit 0: Search for active tool with tool designation (1)
- Bit 1: Search for next tool with tool designation (2)
- Bit 8: Search from 1st location onwards (256)
- Bit 9: Search from current location onwards (512)
- Bit 10: Search from last location backwards (1024)
- Bit 11: Search from current location backwards (2048)
- Bit 12: Search from current location symmetrically (4096)

Example: \$TC MAMP2=4097 (bit 12 and bit 0=1)

Bit 12: Search for empty location: search from current location symmetrically, Bit 0: Tool search: Search for active tool

Location type \$TC_MPP1

\$TC_MPP1[MagazineNo, LocNo]= Type of location:

- 1 = magazine location
- 2 = spindle
- 3 = gripper
- 4 = loader
- 5 = transfer location
- 6 = loading station
- 7 = loading point

Default: Value corresponding to location type

Location type \$TC MPP2

\$TC_MPP2[MagazineNo, LocNo]= Type of location:

Any values can be entered here. The values must match the tools to be loaded at the location.

Buffers and loading points have the value 0!

8 Tool Management

Consider adjacent	\$TC_MPP3[MagazineNo, LocNo]= Considering adjacent location ON = 1					
STC MPP3	• Value = 1: An adjacent location is considered for the location specified					
· _	• Value = 0: No adjacent location is considered for the location specified					
	• Value = 0: This must be entered for buffer and load locations.					
Location status	\$TC_MPP4[MagazineNo, LocNo] = Location status (bit mask)					
\$TC_MPP4	Bit 0: Blocked					
	Bit 1: Free/allocated					
	Default: 2 = Location free					
Location type	\$TC_MPP5[MagazineNo, LocNo] = Location type index					
index \$TC_MPP5	For \$TC_MPP1[Magazine no., Location no.]=1 (location type is the magazine location), the location number is entered here. For other location types, the type index is incremented:					
	Example with 2 grippers with location type 3					
	 the first gripper has location index 1 					
	the second gripper has location index 2					
Distances to	Distances to magazine					
magazine	<pre>\$TC_MDP2[MagazineNo, BufferNo.]= Distances between buffer and maga- zine</pre>					
	A value must be entered for each buffer, at least a zero. The value is not inter- preted here but is used only for assignment.					
	\$TC_MDP1[MagazineNo, BufferNo.]= Distances between load points and magazine					
	One value must be entered for each load location here. It is interpreted when calculating the location before the load point. Only for "Load point for spindle" (location 1) is the value not interpreted but used "only" for magazine assignment.					
Spindle assignment	\$TC_MLSR[LocationNo of BUFF, LocationNo of spindle] = Assignment between buffer and spindle. This enables determination of which buffer, e.g. gripper, may carry out tool change to the spindle.					
	In ShopMill the tool change is initiated by a tool–changing cycle. This cycle is called from the ShopMill cycles where a tool can be programmed.					

Requirements

• PCU commissioning is performed and the connection to the NCK established.

8.4

- The NCK commissioning with NCK machine data for the tool management is performed.
- The basic PLC program is loaded.

General



Fig. 8-1 Overview of tool management

FC 6 supplies data blocks DB71/72 with the information for the new and old tools. Block FC 6 is called by the basic PLC program and must not be called again in the PLC user program.

	So that the tool management always knows where the current tool is located, each location change must be notified to the tool management via FC8 (transfer block). The FC 8 (transfer block) is called by the user program. FB110 is provided as an example.
	The data blocks DB71/72 and 74 are set up automatically. The lengths of the data blocks are determined by the parameters for tool management in DB4. DB4 is written to by the PLC user program. FC100 is provided as an example.
Implementation	Implement call FC 8 and create PLC data (DB4). For this purpose, either adjust the blocks FC 100 and FB110 in the directory \ShopMill_Turn or use your own blocks.

8.4.1 Example for FC 100 and FB 110

The AWL sources TM_W.AWL and TM_WO.AWL are available as examples for the tool management in the directory \ShopMill_Turn.

Procedure

- Adapt one of the following source files and compile it:
 - TM_WO_GR.AWL (data transfer without dual gripper, e.g. for a disktype magazine)
 - TM_W_GR.AWL (data transfer with dual gripper, e.g. for a chain magazine)

Source files TM_WO_GR.AWL and TM_W_GR.AWL contain the following blocks

- FC 100 (block for the PLC data of tool management)
- FB 110, DB 110 (blocks for data transfer in tool management)

The blocks for transferring tool management data (FB110, DB110) must be adapted to suit the individual machine.

- Load the generated blocks to the PLC
- Call the blocks in OB 1 and OB 100:
 - Call FC 100 in OB 100 (before FB 1)
 - Call FB 110 in OB 1 (after FC 30)

The specified call sequence for these blocks is mandatory.

FC 100 Block FC 100 transfers the PLC data for tool management to DB4.

The PLC data is set up for 2 loading points (DB71) and a spindle (DB72). The signals for DB71 and DB72 are found in Chapter 8.4.2 "Signal Description".

The "Real MagLoc" parameter of FC 100 (number of locations of the real magazine) must be assigned values when FC 100 is called.

FB 110 Block FB 110 controls the data transfer for tool management.

The block includes the following functions:

- Acknowledge load/unload/relocate for 1st loading point
- Acknowledge prepare/change for 1st spindle
- Abort, i.e. negative acknowledgment for the above-mentioned functions

The acknowledgment for these functions can be enabled by the PLC via the input parameter of FB 110, e.g. confirm load/unload via user key. The default settings for the input parameters are for automatic acknowledgment meaning that block FB 110 can be used on test stations that do not have a link to the machine (see Table 8-1 or 8-2). Automatic acknowledgment is performed by means of interface signals from the tool management data blocks; each of these can be skipped.

Data transfer without dual gripper FB 110 from the AWL source TM_WO_GR.AWL may be used for data transfer without dual gripper.

Tool change from the magazine to the spindle is carried out in one step here. The tool magazine is changed directly into the spindle.

Table 8-1 Input parameters of FB 110 from TM_WO_GR.AWL

Signal	Туре	Default	Comment
Prepare_IF1	BOOL	TRUE	Acknowledge preparation for spindle 1
Change_IF1	BOOL	TRUE	Acknowledge change for spindle 1
Load_IF1	BOOL	TRUE	Acknowledge loading for loading point 1
Unload_IF1	BOOL	TRUE	Acknowledge unloading for loading point 1
Relocate_IF1	BOOL	TRUE	Acknowledge relocation for loading point 1
Position_IF1	BOOL	TRUE	Acknowledge positioning to loading point 1
Reset_IF_IF2	BOOL	FALSE	Abort for one of the above-mentioned func- tions

Note

MD 9673 CMM_TOOL_LOAD_STATION defines the interface via which the magazine will be loaded or unloaded.

Data transfer with dual gripper

FB110 from the AWL source TM_W_GR.AWL may be used for data transfer with dual gripper.

The tool change is carried out in two steps by the magazine in the spindle. The tool is first moved from the magazine to the gripper and then onto the spindle.

Table 8-2	Input parameters of FB110 from	TM W GR.AWL
	input parametere er i Brite nom	

Signal	Туре	Default	Comment
Prepare_IF1	BOOL	TRUE	Enable preparation for spindle 1
Change1_IF1	BOOL	TRUE	Enable change step 1 (via gripper 1/2) for spindle 1
Change2_IF1	BOOL	TRUE	Enable change step 2 (via gripper 1/2) for spindle 1
Load_IF1	BOOL	TRUE	Enable loading for load point 1
Unload_IF1	BOOL	TRUE	Enable unloading for load point 1
Relocate_IF1	BOOL	TRUE	Enable relocation for load point 1
Position_IF1	BOOL	TRUE	Acknowledge positioning to loading point 1
Reset_IF	BOOL	FALSE	Abort for one of the above-mentioned func- tions

Note

MD 9673 CMM_TOOL_LOAD_STATION defines which interface will be loaded/unloaded.

8.4.2 Signal description

Overview of The following data blocks are used by tool management; i.e. they must not be assigned by the PLC user program:

- DB 71 for loading/unloading stations
- DB 72 for spindle as change point
- DB 74 internal data block for tool management

If you need to change the data for magazines, buffers, or loading positions, delete data blocks DB 71 to DB 74 and restart the PLC.

Description of DB71

DB71 Data block	Signals of load/unload points NCK –>PLC interface							
Byte	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
				In	terfaces			
DBB 0	INT 8	INT 7	INT 6	INT 5	INT 4	INT 3	INT 2	INT 1
DBB 1	INT 16	INT 15	INT 14	INT 13	INT 12	INT 11	INT 10	INT 9
DBB 2, 3								
DBB n + 0				NC program positions magazine	Position at loading point	Relocate	Unload	Load
DBB n+1				Un	assigned			
DBB n+2				Assigned o	hannel (8bit–Int)			
DBB n+3				Tool managem	ent number (8bit	–Int)		
DBD n+4		\$P_VDITCP[0] User parameter 0 (DWord)						
DBD n + 8		\$P_VDITCP[1] User parameter 1 (DWord)						
DBD n + 12		\$P_VDITCP[2] User parameter 2 (DWord)						
DBW n + 16		Identifier for load/unload point (Int), (fixed value 9999)						
DBW n + 18				Location no. of	oad/unload poin	t (Int)		
DBW n + 20		Magazine no. (source) for loading/relocation/positioning (Int)						
DBW n + 22		Location no. (source) for loading/relocation/positioning (Int)						
DBW n + 24		Magazine no. (target) for loading/relocation/positioning (Int)						
DBW n + 26		Location no. (target) for loading/relocation/positioning (Int)						
DBW n + 28 HMI on PLC								Load/un- load with- out mov- ing maga- zine

Initial addresses of load/unload locations:

Loading/unloading location 1: n = 42: n = 343: n = 64

4: n = 94

Example calculation of address DBW n+24 (magazine no. target)

n = (m–1) * len + 4		m = location no. of loading station/point len = 30 (length of a loading point)	
m =2 ;	len = 30	n = (2–1) * 30 + 4 ==> n = 34 DBW (34 + 24) = DBW 58	

Address for magazine no. target of 2nd load point is DBW 58.

Load point 1 is intended for loading/unloading in all spindles. This must be observed for the loading interface assignment (applies to ShopMill on NCU (HMI Embedded sl)); it is automatically considered for PCU 50.3). Load point 1 is also used to relocate/position tools in any location (e.g. buffer location).

Description of DB72

Data block	Spindle as change position					
Interface NCK->PLC	Interface NCK->PLC					
Byte Bit7 Bit6 Bit5 Bit4 Bit3 Bit2 Bit1	Bit0					
DBB 0 INT 8 INT 7 INT 6 INT 5 INT 4 INT 3 INT 2	INT 1					
DBB 1 INT 16 INT 15 INT 14 INT 13 INT 12 INT 11 INT 10	INT 9					
DBB 2, 3						
DBBn + 0ReservedDetach manual toolAttach manual toolOldTool in BL No. (n+42)TOPrepare changeChange (initiation M06)	e tool Obliga- ed by: tory change					
DBB n + 1 Unassigned						
DBB n + 2 Assigned channel (8-bit Int)						
DBB n + 3 Tool management number (8bit–Int)						
DBD n + 4 \$P_VDITCP[0] User parameter 0 (DWord)						
DBD n + 8 \$P_VDITCP[1] User parameter 1 (DWord)						
DBD n + 12 \$P_VDITCP[2] User parameter 2 (DWord)	\$P_VDITCP[2] User parameter 2 (DWord)					
DBW n + 16 Buffer identifier (Int), fixed value 9998) equals "Target position for new tool"	Buffer identifier (Int), fixed value 9998) equals "Target position for new tool"					
DBW n + 18 Relative location (target) in buffer magazine (Int)	Relative location (target) in buffer magazine (Int)					
DBW n + 20 Magazine no. (source) for new tool (Int)	Magazine no. (source) for new tool (Int)					
DBW n + 22 Location no. (source) for new tool (Int)	Location no. (source) for new tool (Int)					
DBW n + 24 Magazine no. (target) for old tool (Int)	Magazine no. (target) for old tool (Int)					
DBW n + 26 Location no. (target) for old tool (Int)	Location no. (target) for old tool (Int)					
DBW n + 28 New tool: Location type (Int)						
DBW n + 30 New tool: Size on left (Int)						
DBW n + 32 New tool: Size on right (Int)	New tool: Size on right (Int)					
DBW n + 34 New tool: Size at top (Int)	New tool: Size at top (Int)					
DBW n + 36 New tool: Size at bottom (Int)						
DBW n + 38 Tool status for new tool	Tool status for new tool					
Tool has been usedTool with fixed loc. codePrewarn- ing limit reachedMeasure toolEnable tool	e Active tool					
DBW n + 40 New tool: Internal T number of NCK (Int)						
DBW $n + 42$ If DBX $(n+0.4) = 1$, then the buffer location of the old tool must be entered	If DBX $(n+0.4) = 1$, then the buffer location of the old tool must be entered here					
DBW n+44 Spare	Spare					

Initial addresses of spindles:

Spindle 1: n = 4Spindle 2: n = 52Spindle 3: n = 100m = Location number of change position len = 48

n = (m-1)* len + 4

Note

DBB (n+1) to DBW (n+46) are updated **only** by a T selection.

For a description of data blocks DB71 and DB74, please see **References:** /FBW/, Description of Functions Tool Management

DB 72					
DBX 0.0 – 0.15	Active status of interface 1–16				
Data block	Signal(s)				
Edge evaluation:	Signal(s) updated: Conditional Signal(s) valid from SW: 2				
Signal state 1	Associated interface has a valid block, a tool change request has been initiated.				
Signal state 0	Operation for this interface has ended.				

DB 72			
DBB(n+0)	Tool chang	e information	
Data block	Signal(s)		
Edge evaluation:		Signal(s) updated: Conditional	Signal(s) valid from SW: 5
Description	Bit 0: Obliga Bit 1: Chang Bit 2: Prepa Bit 3: "T 0" is Bit 4: Old too Bit 5: Attach Bit 6: Detach Bit 7: Reser	tory change te tool (initiated by M06) re change s programmed ol in buffer number (n+42) manual tool n manual tool ved	

Note

The bits in DBB (n+0) (prepare change, change tool,...) are <u>**not**</u> reset by the system. They are up–to–date only if the appropriate interface bit in DBB0 is set to "1". However, the bits can be reset by the user if necessary.

DB 72 DBB(n+2) Data block	Assigned ch	nannel	
Edge evaluation:	olgrial(0)	Signal(s) updated: Conditional	Signal(s) valid as of software version: 2
Description	Channel no.	to which active interface applies	

DB 72					
DBB(n+3)	Tool manag	Tool management no.			
Data block	Signal(s)				
Edge evaluation:		Signal(s) updated:	Conditional	Signal(s) valid from SW: 2	
Description	Associated t	ool management nu	mber		

DB 72				
DBD(n+4)	User param	eter 0 (DInt)		
Data block	Signal(s)	Signal(s)		
Edge evaluation:	Signal(s) updated: Conditional Signal(s) valid from SW: 2		Signal(s) valid from SW: 2	
Description	Programming of \$P_VDITCP[0]=(value) can be used to transfer a value to the PLC via the parts program.			

DB 72				
DBD(n+8)	User parameter 1 (DInt)			
Data block	Signal(s)	Signal(s)		
Edge evaluation:		Signal(s) updated: Conditional	Signal(s) valid from SW: 2	
Description	Programming of \$P_VDITCP[1]=(value) can be used to transfer a value to the PLC via the			
	parts progra	m.		

DB 72 DBD(n+12) Data block	User param Signal(s)	eter 2 (DInt)	
Edge evaluation:		Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Programming of \$P_VDITCP[2]=(value) can be used to transfer a value to the PLC via the parts program.		

DB 72				
DBW(n+16)	Buffer mag	Buffer magazine no. (fixed value 9998) target position for new tool		
Data block	Signal(s)			
Edge evaluation:		Signal(s) updated: Conditional	Signal(s) valid from SW: 2	
Description	Magazine no. 9998 for all buffer magazines, target magazine for new tool			

DB 72 DBW(n+18) Data block	Location ir Signal(s)	buffer magazine (spindle)	
Edge evaluation:		Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Location of spindle. The put.	buffer magazine to which the new tool e location number defined for this partic	must be loaded. This is normally the ular buffer during commissioning is out-

DB 72 DBW(n+20) Data block	Magazine no. (source) for new tool Signal(s)
Edge evaluation:	Signal(s) updated: Conditional Signal(s) valid from SW: 2
Description	Source magazine no. of new tool
Corresponding to	DBW(n+22)

DB 72				
DBW(n+22)	Location no. (source) for new tool			
Data block	Signal(s)	Signal(s)		
Edge evaluation:		Signal(s) updated: Conditional	Signal(s) valid as of SW:: 2	
Description	Source location no. of new tool			
Corresponding to	DBW(n+20)			

8 Tool Management

DB 72				
DBW(n+24)	Magazine no. (target) for old tool			
Data block	Signal(s)	Signal(s)		
Edge evaluation:		Signal(s) updated: Conditional	Signal(s) valid from SW: 2	
Description	Number of magazine to which old tool must be loaded.			
Corresponding to	DBW(n+26)			

DB 72			
DBW(n+26)	Location no. (target) for old tool		
Data block	Signal(s)		
Edge evaluation:	Signal(s) updated: Conditional Signal(s) valid from SW: 2		
Description	Number of location to which old tool must be loaded.		
Corresponding to	DBW(n+26)		

DB 72 DBW(n+28) Data block	New tool: L Signal(s)	ocation type	
Edge evaluation:		Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	The location type of the new tool is entered here.		
Corresponding to	Tool size: Le	ft, right, top, bottom	

DB 72	
DBW(n+30)	New tool: Size left
Data block	Signal(s)
Edge evaluation:	Signal(s) updated: Conditional Signal(s) valid from SW: 2
Description	Specification of new tool size on left in half locations.

DB 72 DBW(n+32)	New tool: S	ize right	
Data block	Signal(s)		
Edge evaluation:		Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Specification	n of new tool size on right in half locatio	ons.

DB 72 DBW(n+34)	New tool: S	Size top						
Data block	Signal(s)							
Edge evaluation:		Signal(s) updated: Conditional	Signal(s) valid from SW: 2					
Description	Specification	n of new tool size top in half locations.						

DB 72 DBW(n+36)	New tool: S	ize bottom	
Data block	Signal(s)		
Edge evaluation:		Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Specification	n of new tool size bottom in half location	S.

DB 72	
DBW(n+38)	Tool status for new tool
Data block	Signal(s)
Edge evaluation:	Signal(s) updated: Conditional Signal(s) valid from SW: 2
Description	Bit 0: Active tool Bit 1: Tool enabled Bit 2: Tool disabled Bit 3: Tool measured Bit 4: Prewarning limit reached Bit 5: Tool being changed Bit 6: Tool is fixed–location coded Bit 7: Tool has been in use

DB 72 DBW(n+40) Data block	New tool: Internal T no. of NCK
Edge evaluation:	Signal(s) updated: Conditional Signal(s) valid from SW: 2
Description	Display of internal T no. of NCK for the new tool.

DB 72				
DBW(n+42)	Reserved			
Data block	Signal(s)			
Edge evaluation:	r.	Signal(s) updated:		Signal(s) valid from SW:
Description			¥	

DB 72	Deserved		
DBW(n+44)	Reserved		
Data block	Signal(s)		
Edge evaluation:		Signal(s) updated:	Signal(s) valid from SW:
Description			

DB 72			
DBW(n+46)	Reserved		
Data block	Signal(s)		
Edge evaluation:		Signal(s) updated:	Signal(s) valid from SW:
Description			· · · ·

8.5 Display machine data

8.5 Display machine data

Display machine data can be used to activate certain functions and settings at the operator interface.

MD 9450 \$MM_WRITE_TOA_FINE_LIMIT Limit value for fine wear

MD 9478 \$MM_TO_OPTION_MASK Settings for ShopMill

MD 9639 \$MM_CTM_MAX_TOOL_WEAR Upper input limit for tool wear

MD 9651 \$MM_CMM_TOOL_MANAGEMENT Tool management variant

MD 9652 \$MM_CMM_TOOL_LIFE_CONTROL Tool monitoring

MD 9661 \$MM_CMM_ENABLE_CUSTOMER_M_CODES Number of input fields for tool—specific functions

MD 9663 \$MM_CMM_TOOL_DISPLAY_IN_DIAM Radius/diameter display for tool

MD 9667 \$MM_CMM_FOLLOW_ON_TOOL_ACTIVE Tool preselection active

MD 9671 \$MM_CMM_TOOL_LOAD_DEFAULT_MAG Load tool in default magazine

MD 9672 \$MM_CMM_FIXED_TOOL_PLACE Fixed location coding

MD 9673 \$MM_CMM_TOOL_LOAD_STATION Number of loading point

MD 9674 \$MM_CMM_ENABLE_TOOL_MAGAZINE Display of magazine list

MD 9687 \$MM_CMM_TOOL_MOVE_DEFAULT_MAG Relocate tool to default magazine

The default setting and machine data description can be found in Section 7.2 "Display Machine Data for ShopMill".

8.6 Tool change cycle

Process

The ShopMill tool change cycle performs the following tasks:



Fig. 8-2 ShopMill tool change cycle

Note

The number of teeth is stored in tool edge parameter 24 (\$TC_DP24), while the spindle direction of rotation, the coolant, and the tool–specific functions are stored in tool edge parameter 25 (\$TC_DP25).

You need to create a tool change cycle, e.g. L6, for the machine–specific parts of the tool change.

8.6 Tool change cycle

Example	The example L6.SPF is available for this purpose. The sample file is located in the directory CYCLES\SC\PROG\TEMPLATES_DEU or CYCLES\SC\PROG\TEMPLATES_ENG. This example requires:
	 MD 22550 \$MC_TOOL_CHANGE_MODE=1 Tool change via M function.
	 MD 10715 \$MN_M_NO_FCT_CYCLE[0]=6

- M function (M6) with which the tool change, i.e. the subroutine assigned via MD 10716 \$MN_M_NO_FCT_CYCLE_NAME[0], is called.
- MD 10716 \$MN_M_NO_FCT_CYCLE_NAME[0]="L6" Name of the subroutine (L6) that must be processed based on the M function defined in MD 10715. If the subroutine name must be entered via program or MDA, the name must be placed in quotes. This does not apply to manual inputs.
- MD 22560 \$MC_TOOL_CHANGE_M_CODE=206 M function (M206) with which the tool change is defined for the tool management.

PROC L6 SAVE

```
;
;Example of tool change cycle for machine manufacturer
;
DEF INT _WZ_IN_SP,_WZ_VOR
DEF REAL _WWP=...
                                   ; Tool change position
                                   ; MKS
DEF REAL _SPP=...
                                   ; Spindle position
                                  ; If no block search
IF (NOT $P SEARCH)
 F (NOT $P_SEARCH) ; If no block sea
_WZ_IN_SP=$TC_MPP6[9998,1] ; Tool on spindle
GETSELT( WZ VOR)
                                   ; Preselected tool
 ;
 IF (_WZ_IN_SP<>_WZ_VOR)
                                  ; If other tool
 ; Position spindle:
    SPOS= SPP
 ; Approach tool change position:
   SUPA DO GO G90 G40 G60 Z= WWP
ENDIF
ELSE
                                   ; If simulation active
IF (E_SIM_ACTIVE)
 ; Approach tool change position:
    SUPA DO GO G90 G40 G60 Z= WWP
ENDIF
ENDIF
;
;Load tool: Tool management and PLC
M206
M17
```

Note

In the example of tool change cycle L6 you must replace "..." with values in lines "DEF REAL_WWP=..." and "DEF REAL_SPP=...".

Tool change cycle L6 contains the following steps:

- 1. Position spindle (not when simulation is active)
- 2. Approach tool change positions in the machine coordinate system
- 3. Execute tool change (M206)

The tool must be at a safe height after tool change so that all motions in the plane are permissible.

8.7 Manual tools

Manual tools are tools which are required during machining, but are only available in the tool list but not in the tool-holding magazine. These tools must be attached/detached manually to/from the spindle.

Via MD 22562 \$MC_TOOL_CHANGE_ERROR_MODE, Bit 1=1, tools without magazine location assignment can additionally be selected on a tool change.

An alarm is output every time the manual tool is loaded, unloaded or replaced. (e.g.: "Channel 1, manual tool cutter20, duplo no. 1 load to tool holder 1." I.e. that manual tool cutter20 should be loaded into the spindle.)

Manual tools are identified by magazine location 1 in magazine 9999 in the interface to the PLC. Bit 5 in DB72 DBB (n+0) is set to load the tool and bit 6 to unload it.

8.8 Activating the spindle, coolant, and tool–specific functions

Spindle, coolant Here you can assign a direction of rotation (CW/CCW/OFF) and coolant to a tool.

WERKZEUGE	Cursor texts: "Spindle CW/CCW/OFF" "Coolant 1/2									
Werkzeugli	ste									
Nr.Typ Wer	•kzeugbez. D	ЭP	S Länge	ichneide Radius	1 Winkel	Ν	Ⅰ ₩	ו ⊲ 1	- ⇒ 2	Spez. Fkt
₩ 1 200 Bot	าก1	1	110.000	10.000	118.0		2			
2 200 Bot	1 r 2	1	120.000	15.000	118.0		2			

Fig. 8-3 Tool list: Coolant and direction of spindle rotation

You assign the coolants to the appropriate M functions via the following machine data: MD 9680 \$MM_CMM_M_CODE_COOLANT_I MD 9681 \$MM_CMM_M_CODE_COOLANT_II

MD 9668 \$MM_CMM_M_CODE_COOLANT_I_AND_II MD 9686 \$MM_CMM_M_CODE_COOLANT_OFF

Tool-specific
functionsTool-specific functions 1...4 are intended for other machine functions that can
be activated for a tool, for example, third coolant, speed monitoring, tool break-
age etc.

WERK	ZEUG	Ε	Cursor texts: "Tool–spec. fct 14" —]	
Wer	·kzeu	gliste									
Nr.	Typ	Werkzeugbez.	DP	Länge	òchneide Radius	1 Winkel	Ν	₽	⊸ 1	⇒ S 2 F	pez. kt
₩ 1	200	Bohr 1	1	110.000	10.000	118.0		2			
2	200	Bohr2	1	120.000	15.000	118.0		2			

Fig. 8-4 Tool list: Tool–specific functions 1...4

Up to 8 M functions can be programmed for the activation or deactivation of the tool–specific functions. The definition occurs via the following machine data:

MD 9739 \$MM_CMM_M_CODE_TOOL_1_ON MD 9740 \$MM_CMM_M_CODE_TOOL_1_OFF MD 9741 \$MM_CMM_M_CODE_TOOL_2_ON MD 9742 \$MM_CMM_M_CODE_TOOL_2_OFF MD 9743 \$MM_CMM_M_CODE_TOOL_3_ON MD 9744 \$MM_CMM_M_CODE_TOOL_3_OFF MD 9745 \$MM_CMM_M_CODE_TOOL_4_ON MD 9746 \$MM_CMM_M_CODE_TOOL_4_OFF

8.8 Activating the spindle, coolant, and tool–specific functions

	The M functions for the tool–specific functions are generated by the ShopMill cycles in a single record (up to 4 M commands are possible). The number and also the sequence of the M commands are dependent upon the machine data settings (MD9739 – MD9746) and the programming. With machine data setting "–1", no M command is issued for the corresponding tool–specific function. The same applies if no entry (neither "on" nor "off") is made during programming in the menu "Programs" –> "Line/circle" –> "Machine functions". If M functions smaller than 100 are used, the number and sequence of M commands is irrelevant since they are available in the operator PLC in the decoded area (DB21.DBB194 – DB21.DBB206), regardless of the number and he sequence during programming. However, if M functions above 100 are used, they must be decoded in the operator PLC. In this case, the number and the sequence (M function 1 – M function 4) must be observed. The display machine data are predefined so that no M values are output for the corresponding functions. For example, only the "On" statuses can be output via separate M commands and "Off" via a joint M command.
Example	Machine data settings: MD 9739 \$MM_CMM_M_CODE_TOOL_1_ON : 90 MD 9740 \$MM_CMM_M_CODE_TOOL_1_OFF : 91 MD 9741 \$MM_CMM_M_CODE_TOOL_2_ON : 92 MD 9742 \$MM_CMM_M_CODE_TOOL_2_OFF : -1 MD 9743 \$MM_CMM_M_CODE_TOOL_3_ON : 94 MD 9744 \$MM_CMM_M_CODE_TOOL_3_OFF : 95 MD 9745 \$MM_CMM_M_CODE_TOOL_4_ON : 96 MD 9746 \$MM_CMM_M_CODE_TOOL_4_OFF : 97
	The following functions are programmed in the menu Programs" \rightarrow "Line/circle" \rightarrow "Machine functions". Tool–specific function 1: on Tool–specific function 2: off Tool–specific function 3: not programmed Tool–specific function 4 : off The ShopMill interface generates the following M functions: M90 M97
Hiding fields in tool list	The fields in the tool list for displaying the tool–specific functions can be hidden via settings of the respective machine data. If both M commands of a function $=-1$, the corresponding field is not displayed on the interface.
Special properties in "MANUAL" mode	In "MANUAL" mode, no spindle direction of rotation, coolant and tool–specific functions are output to the ShopMill interface. On tool change in the "MANUAL" mode, these functions can be initiated by the operator using the keys on the machine control panel (implementation via PLC user program).
Change cursor texts	You can change the cursor texts for "Coolant 1/2 on/off" and "Tool–spec. fct. 1," (see Section 8.9 "Modifying Texts for Tool–specific Functions").

8.9 Modifying texts for tool–specific functions

8.9.1 ShopMill on NCU (HMI Embedded sl)

For tool–specific functions, you can modify the parameter texts in the "Prog. edit" \rightarrow "Linear Circular" \rightarrow "Machine Function" menu and the cursor texts in the tool list. Cursor texts are texts, shown in the message line when the cursor is positioned on the relevant input field.

The texts of the tool–specific functions can be changed in the text file ALUC.TXT. For this purpose, select the texts in the directory /siemens/sinumerik/cycles/lng/deu you want to change and save the text files edited in the editor in the directory – /oem/sinumerik/cycles/lng/deu or

- /user/sinumerik/cycles/lng/deu

.

Text numbers

The texts are assigned to the following text numbers in the file ALUC.TXT:

Cursor texts in the "Tool list" menu	Text number
Tool-specific function 1 (tool-spec. fct. 1)	89911
Tool-specific function 2 (tool-spec. fct. 2)	89912
Tool-specific function 3 (tool-spec. fct. 3)	89913
Tool-specific function 4 (tool-spec. fct. 4)	89914
Coolant 1	89921
Coolant 2	89922
Parameter texts in the menu "Program linear/circular machine functions"	
Tool-specific function 1 (tool-spec. fct. 1)	89915
Tool-specific function 2 (tool-spec. fct. 2)	89916
Tool-specific function 3 (tool-spec. fct. 3)	89917
Tool-specific function 4 (tool-spec. fct. 4)	89918
Coolant 1	89919
Coolant 2	89920

This means that text numbers 89911 and 89915 etc. refer to the same functions.

Note

The maximum number of character is 23 for the cursor texts and 14 for the parameter texts.

Language assignment	Each language directory contains a file named ALUC.TXT.	
Example	The cursor text "Tool–spec. function 1" in the tool list should be changed to "Air cooling".	
	You must make the following entry in text file ALUC.TXT: 89911 0 0 "Air cooling"	
	The two parameters 2 and 3 separated by blanks are control characters for text output and must always be set to 0.	
	More detailed information can be found in the following documentation: References: /IHE/, Commissioning Base Software and HMI Embedded s SINUMERIK 840D sl	sl,

8.9.2 PCU 50.3

For tool–specific functions, you can modify the parameter texts in the "Prog. edit" \rightarrow "Linear Circular" \rightarrow "Machine Function" menu and the cursor texts in the tool list. Cursor texts are texts, shown in the message line when the cursor is positioned on the relevant input field.

The desired texts must be entered in the text file F:\DH\CUS.DIR\ALUC_xx.COM. The file ALUC_xx.COM may have to be created in the directory CUS.DIR. In the file F:\USER\MBDDE.INI, add the following line in the section [TextFiles]: UserZYK=F:\dh\cus.dir\aluc_

Text numbers The texts are assigned to the following text numbers in the file ALUC xx.COM:

Text assignment

Cursor texts in the "Tool list" menu	Text number
Tool-specific function 1 (tool-spec. fct. 1)	89911
Tool-specific function 2 (tool-spec. fct. 2)	89912
Tool-specific function 3 (tool-spec. fct. 3)	89913
Tool-specific function 4 (tool-spec. fct. 4)	89914
Coolant 1	89921
Coolant 2	89922
Parameter texts in the menu "Program linear/circular machine functions"	
Tool-specific function 1 (tool-spec. fct. 1)	89915
Tool-specific function 2 (tool-spec. fct. 2)	89916
Tool-specific function 3 (tool-spec. fct. 3)	89917
Tool-specific function 4 (tool-spec. fct. 4)	89918
Coolant 1	89919
Coolant 2	89920

This means that text numbers 89911 and 89915 etc. refer to the same functions.

Note

Table 8-4

The maximum number of character is 23 for the cursor texts and 14 for the parameter texts.

Language assignment

The text language is assigned via the name of the text file. "xx" is replaced by one of the following codes in the text file name:

8.9 Modifying texts for tool-specific functions

Abbreviation xx	Language
gr	German
uk	English
fr	French
it	Italian
sp	Spanish
nl	Dutch
dk	Danish
fi	Finnish
SW	Swedish
pl	Polish
tr	Turkish
ch	Simplified Chinese
tw	Chinese (Traditional)
ko	Korean
hu	Hungarian
ро	Brazilian Portuguese
ru	Russian
cz	Czech
ja	Japanese

Table 8-5 Language assignment

Example

The cursor text "Tool-spec. function 1" in the tool list should be changed to "Air cooling".

You must make the following entry in text file ALUC GR.COM: 89911 0 0 "Air cooling"

The two parameters 2 and 3 separated by blanks are control characters for text output and must always be set to 0.

In the file F:\USER\MBDDE.INI, add the following line in the section [TextFiles]: UserZYK=F:\dh\cus.dir\aluc_

More detailed information can be found in the following documentation: **References:**:

> /IHA/,Commissioning Base Software and HMI Advanced, Operator Interface Extension, SINUMERIK 840D sl/840D/840Di

8.10 Configuring the operator interface

There are two ways you can modify the existing operator interface for the tool management system:

- In tool management, in addition to the tools, wear, and magazine lists, an additional list can also be activated on the 3rd horizontal softkey; (see section 8.10.1 "Integrating additional list").
- Dependent upon the tool, you can configure the existing or user-defined parameters in the lists (see chapter 8.10.2 "Configuring lists").

8.10.1 Integrating additional list

If you want to activate an additional list or change the lists, proceed as follows:

 Setting machine data 9478 \$MM_TO_OPTION_MASK, bit 2=1 Activate additional list

You can now call up a list with the following parameters in the tool management using the 3rd horizontal softkey:

- "LROU"
- "Location type"
- Specifying texts for additional list (optional) If you want to change the softkey label (OEM tool list) and header (OEM tool list) of the additional list, you must define new texts (see chapter 8.10.7 "Defining texts").

8.10.2 Configuring lists

To modify existing lists (including an integrated additional list) you must proceed as follows:

Activate the configuration file	Set the following machine data:
	MD 9478 \$MM_TO_OPTION_MASK, bit 8 Analyze the file TO_MILL.INI
	The configuration file TO_MILL.INI, in which you configure changes from the standard settings, is analyzed (see chapter 8.10.3 "Creating the configuration file").
Activate use of OEM data	If you use user-defined OEM data, set the following machine data:
	MD 18080 \$MN_MM_TOOL_MANAGEMENT_MASK, Bit 2 Provide memory for user data
	MD 18094 \$MN_MM_NUM_CC_TDA_PARAM Number of user-defined parameters
	MD 18095 \$MN_MM_TYPE_CC_TDA_PARAM[n]=4 Data type (REAL) of user-defined parameters
	MD 20310 \$MC_TOOL_MANAGEMENT_MASK, Bit 2 Activate user functions
	Texts for user-defined parameters (optional) If you want to change the column headers and cursor texts of the user-defined parameters, define new texts (see chapter 8.10.7 "Defining texts").
Adapt the configuration file	Define all changes from the standard settings in the configuration file TO_Mill.INI (see chapter 8.10.3 "Creating the configuration file").
8.10.3 Creating the configuration file

You must store all the changes you have made to the lists from the default setting in the TO_MILL.INI configuration file.

Please note the following:

- After the column "DP number" you can define further columns and also hide existing columns.
- The number of columns displayed is limited by the width of the window because each column has a fixed width. Horizontal scrolling is not possible.
- Per column define cutting edge parameters only, tool parameters only, or magazine parameters only.
- Define the cutting edge parameters in consecutive columns.

The sample file TO_MILL.INI, which can be adapted, is located in ShopMill on NCU (HMI Embedded sl) under CYCLE_STORAGE\SEQUENCER_CYCLES\TEMPLATES_DEU. The adapted file is then found on the CF card (NCU 7x0) under – oem\sinumerik\hmi\cfg\ – user\sinumerik\hmi\cfg\.

For ShopMill on PCU 50.3, this example is located on the supplied CD under Tools\TEMPLATES_DEU. The file is copied to the directory OEM or USER.

Syntax

Entries in the configuration file are subject to the following syntax rules; (see also example at end of this section):

First specify in which tool management list you would like to make changes. [DISPLAY_IDENTIFIER] DISPLAY_IDENTIFIER: Tool management list Next define the changes themselves:

- Modify a specific column for all tools:
 COLUMNx=CONTENTS_IDENTIFIER
 COLUMN: Column command
 x: Column number, 1 12
 CONTENTS_IDENTIFIER: Parameter or property of tool
- Modify a specific column for a specific tool: TOOL_IDENTIFIER = x=CONTENTS_IDENTIFIER TOOL_IDENTIFIER: Tool type
- Define different columns for each tool: TOOL_IDENTIFIER = CONTENTS_IDENTIFIER / CONTENTS_IDENTIFIER / ... TOOL_IDENTIFIER = CONTENTS_IDENTIFIER / CONTENTS_IDENTIFIER / ...

The parameters or properties of a tool are listed one after the other by means of a CON-TENTS_IDENTIFIER and are separated from one another by a slash "/". If the default setting is to be used for individual columns, you still need to insert a forward slash.

If, for example, you only want to modify the last few columns, specify the number (x) of the first column you would like to modify and list the respective CONTENTS_IDENTIFIERs for the subsequent columns.

TOOL_IDENTIFIER = x=CONTENTS_IDENTIFIER / CONTENTS_IDENTIFIER / ..

Note

Using the COLUMN command, you can first define one column identically for all tools and then adapt it specifically for individual tools.

You can mark comments by means of a semicolon (;) symbol.

If errors occur during evaluation of the configuration file, refer to the TO_INI_F.LOG file for a description of the error. For the ShopMill on NCU (HMI Embedded sl) version, the file is located on drive I:, for PCU 50.3 in the directory F:\MMC0W32\TMP.

Identifier The following tables list the SCREEN_IDENTIFIERS, TOOL_IDENTIFIERS, and CONTENTS IDENTIFIERS available for defining the columns.

SCREEN_IDENTIFIER	Tool management list
TOOL_LIST	Tool list
TOOL_LIST_2ND_EDGE	Tool list, further cutting edges
TOOL_WEAR	Tool wear list
TOOL_WEAR_2ND_EDGE	Tool wear list, further cutting edges
TOOL_MAGA	Magazine list
TOOL_LIST_OEM	Additional list
TOOL_LIST_OEM_2ND_EDGE	Further cutting edges

Table 8-6 SCREEN_IDENTIFIER

TOOL_IDENTIFIER	ΤοοΙ
SHANK_END_CUTTER	(End) cutter
POINTED_DRILL	(Twist) drill
TO_SCREW_TAP	Screw tap
END_MILL_CUTTER	Facing tool
ANGLE_HEAD_CUTTER	Angle head mill
LOCATOR	Centering tool
EDGE_TRACER	Edge probe
3DTRACER	3D probe
3DCUTTER_110	Cylindrical die mill
3DCUTTER_111	Ball end mill
3DCUTTER_121	End mill with corner rounding
3DCUTTER_155	Bevel cutter
3DCUTTER_156	Bevel cutter with corner rounding
3DCUTTER_157	Tapered die-sinking cutter

Table 8-7 TOOL_IDENTIFIER

Table 8-8 CONTENT_ID

CONTENT_ID	Parameter type *	Parameter or property	Field width in number of char- acters
EMPTY		Empty field	
NOT_USED		Empty column	
LENGTH	S	Length	7
RADIUS	S	Radius	7
RADIUS_ DIAM	S	Radius with possible diameter calculation	7
ANGLE	S	Angle	5
N	S	Number of teeth	2
SPINDLE	S	Spindle direction	1
COOL1	S	Cooling water 1	1
COOL2	S	Cooling water 2	1
MFCT1	S	Tool–specific function 1	1
MFCT2	S	Tool–specific function 2	1
MFCT3	S	Tool–specific function 3	1
MFCT4	S	Tool–specific function 4	1
DLENGTH	S	Wear length	7
DRADIUS	S	Wear radius	6
DRADIUS_ DIAM	S	Wear radius with possible diameter cal- culation	6
T_OR_C	W	Method of wear monitoring	1
P_TIME	S	Tool life	7

Table 8-8	CONTENT_ID
-----------	------------

CONTENT_ID	Parameter type *	Parameter or property	Field width in number of char- acters
PW_TIME	S	Tool life warning limit	7
P_COUNT	S	Quantity	7
PW_COUNT	S	Pre-warning limit for count	7
P_WEAR	S	Wear	7
PW_WEAR	S	Prewarning limit for wear	7
T_LOCKED	W	Tool disabled	1
T_SIZE	W	Oversized tool	1
T_FIXED	W	Tool in fixed location	1
T_STATE	w	Status code: Active/prewarning limit reached/blocked	5
T_MAG_ PLACE_TYPE	W	Magazine location type The parameter is not contained in the stan- dard tool list of ShopMill. Column header: Location type Cursor text: Magazine location type Input: Number of magazine location type Entry requirement: The tool must be lo- cated outside a magazine.	5
P_LOCKED	М	Magazine location locked	6
MAG_T_ LOCKED	w	Display only: Tool disabled	1
MAG_T_SIZE	W	Display only: Oversized tool	1
MAG_T_ FIXED	w	Display only: Tool in fixed location	1
H_NBR	S	H number of an ISO dialect program	3
TPC1	W	Parameter 1	7
TPC2	W	Parameter 2	7
TPC3	W	Parameter 3	7
TPC4	W	Parameter 4	7
TPC5	W	Parameter 5	7
TPC6	W	Parameter 6	7
TPC7	W	Parameter 7	7
TPC8	W	Parameter 8	7
TPC9	W	Parameter 9	7
TPC10	W	Parameter 10	7

* Parameter types: S = cutting edge data, W = tool data, M = magazine data.

Parameter "H number" will only be displayed if ShopMill is set up for ISO dialects (see Section 11.2 "ISO Dialects").

Example	
---------	--

[TOOL LIST] ;Standard values for columns COLUMN1 = H NBRCOLUMN2 = LENGTHCOLUMN3 = RADIUS DIAM COLUMN4 = EMPTYCOLUMN5 = EMPTY COLUMN6 = SPINDLE COLUMN7 = COOL1COLUMN8 = COOL2 COLUMN9 = MFCT1COLUMN10= MFCT2 COLUMN11= MFCT3 COLUMN12= MFCT4 ;Deviations from standard values SHANK END CUTTER = 5=N POINTED DRILL = 4=ANGLE LOCATOR = 3=EMPTY/ANGLE $3DCUTTER_{110} = 5=N$ $3DCUTTER_{111} = 5=N$ $3DCUTTER_{121} = 5=N$ $3DCUTTER_{155} = 5=N$ 3DCUTTER 156 = 5=N $3DCUTTER_{157} = 5=N$

;Tool list

8.10.4 Adapting individual parameters

Using the configuration file to_mill.ini, you can change the default settings for specific tool parameters.

Table 8-9	PARAMETER	IDENTIFIER
	-	

PARAMETER_IDENTIFIER	Parameter
T_MAG_PLACE_TYPE	Magazine location type
TPC1	Parameter 1
TPC2	Parameter 2
TPC3	Parameter 3
TPC4	Parameter 4
TPC5	Parameter 5
TPC6	Parameter 6
TPC7	Parameter 7
TPC8	Parameter 8
TPC9	Parameter 9
TPC10	Parameter 10

Magazine location	You can change the input field into a toggle field for the parameter "Magazine
type	location type". The following values are entered: You must define the values of the toggle field in the section T_MAG_PLACE_TYPE, by assigning values to cursor texts.

Value = Text ID

Valid text IDs and information on defining texts are provided in Chapter 8.10.7 "Defining texts").

Example

[T_MAG_PLACE_TYPE] DEFAULT = 89891 1 = 89868 2 = 89869 5 = 89872 9 = 89876

In this example, in the column "location type" you can select the values 1, 2, 5 or 9 using the "alternative" softkeys. Here, the values have been randomly selected. Cursor texts that have been saved are displayed for the selected values. If the actual value of the parameter devices from the configured values, then the text, saved as DEFAULT, is displayed as cursor text.

OEM parameter You can change the input fields into toggle fields for the OEM tool parameters. In so doing, specific values are entered. You must define the values of the toggle field in Sections TPC1 ... TPC10, by assigning cursor texts to the values (refer to Chapter 8.10.7 "Defining texts"). Also refer to the example on "Magazine location type" parameters. You can define the width of the toggle field or the input field to a specific number of characters. The standard width is 7 characters. Further, for the input field, you can also specify the data type (integer or double), however, only if you have not specified a toggle field. If you do not change the data type, then, the double data type set as default, is used. [TPC1] Example WIDTH = 2TYPE = INTEGER In this example, the input fields of the column OEM tool parameter 1 are 2 char-

8.10.5 Defining texts for the magazine locations on the intermediate buffer

The magazine locations of the buffer are shown, as standard using symbols in the tool manager lists. You can assign texts to the location using the configuration file to mill.ini.

acters wide. You can only enter integer values in the input fields.

ID for the buffer: BUFFER

In the section BUFFER, the magazine locations of the buffer are assigned texts.

Magazine location = Text ID

Valid text IDs and information on defining texts are provided in Chapter 8.10.7 "Defining texts").

Example

[BUFFER] DEFAULT = 89768 1 = 89790 2 = 89791 3 = 89792

In this example, three magazine locations of the buffer (spindle, gripper 1 and gripper 2) are assigned texts for the display in the tool manager lists. A default text is displayed for additional magazine locations of the buffer.

8.10.6 Designating a load magazine in the tool list sorted according to magazines

If the tool list is sorted according to magazines, all of the magazine locations are displayed in an increasing sequence according to magazine location and magazine number. Using the configuration time to_mill.ini, a magazine can be high-lighted as load magazine by sorting this magazine so that it is directly located after the magazine locations of the buffer.

ID for the load magazine: OEM_LOAD_MAGAZINE

Example

[OEM_LOAD_MAGAZINE] MAGAZINE = 3

In this example, magazine 3 is configured as load magazine,. The magazine locations of magazine 3 are displayed directly after the magazine locations of the buffer in the tool list sorted according to magazine locations.

8.10.7 Define texts

Texts (softkey name and list header for additional lists, column headers, and cursor texts for user-defined parameters) are assigned to specific text numbers in a text file.

These are subject to the following syntax: Text number 0 0 "Text"

The two parameters 2 and 3 separated by blanks are control characters for text output and must always be set to 0.

The column header in the parameter name can consist of three lines, each line with its own text number; (see Table 8-10).

Table 8-10 Text assignment	ment
----------------------------	------

Text type	Text number
3rd horizontal softkey	89923
List header	89924
Column header parameter TPC1	89925, 89926, 89927
Cursor text parameter TPC1	89931
Column header parameter TPC2	89928, 89929, 89930
Cursor text parameter TPC2	89932
Column header parameter TPC3	89953, 89954, 89955
Cursor text parameter TPC3	89965
Column header parameter TPC4	89937, 89938, 89939
Cursor text parameter TPC4	89949
Column header parameter TPC5	89940, 89941, 89942
Cursor text parameter TPC5	89950
Column header parameter TPC6	89943, 89944, 89945
Cursor text parameter TPC6	89951
Column header parameter TPC7	89956, 89957, 89958
Cursor text parameter TPC7	89966
Column header parameter TPC8	89946, 89947, 89948
Cursor text parameter TPC8	89952
Column header parameter TPC9	89959, 89960, 89961
Cursor text parameter TPC9	89967
Column header parameter TPC10	89962, 89963, 89964
Cursor text parameter TPC10	89968

Example: 89924 0 0 "Tool data"

The texts must not exceed the following number of characters: Softkey: 6 List header: 20 Column header parameter: 7 (dependent on the column width) Cursor text parameters: 45 A line break in the softkey text can be made by inserting two consecutive blanks.

Note

Some texts for the parameters TPC1 and TPC2 are already prefilled with sample texts which can be changed.

Magazine location type, OEM parameter, magazine locations of the buffer	The texts for the magazine locations of the buffer and the cursor texts for the parameter, magazine location type and OEM parameter must be located as toggle field in the number range 89700 to 89899.
ShopMill on NCU (HMI Embedded sl)	For ShopMill on NCU (HMI Embedded sl), enter the texts and numbers in the text file ALUC.TXT. There is an ALUC.TXT text file in each language directory.
PCU 50.3	With the PCU 50.3 enter the texts and numbers in the text file F:\DH\CUS.DIR\ALUC_xx.COM. If the ALUC_xx.COM file does not exist, you need to create it in the CUS.DIR directory. The texts are assigned to a language by means of the text file name. In the text file name "xx" is replaced by one of the following codes:

	0 0 0
Abbreviation XX	Language
gr	German
uk	English
fr	French
it	Italian
sp	Spanish
nl	Dutch
dk	Danish
fi	Finnish
SW	Swedish
pl	Polish
tr	Turkish
ch	Simplified Chinese
tw	Chinese (Traditional)
ko	Korean
hu	Hungarian
ро	Brazilian Portuguese
ru	Russian

Table 8-11 Language assignment

Table 8-11	Language assignment

Abbreviation XX	Language
CZ	Czech
ja	Japanese

In the file F:\USER\MBDDE.INI or F:\OEM\MBDDE.INI add the following line in the section [TextFiles]:

UserZYK=F:\dh\cus.dir\aluc_

8.11 Reading in tool data

8.11 Reading in tool data

You can import tool data that you have measured on an external tool presetting station directly into the tool management of ShopMill.

Save the tool data as an INI file.

The header in the file must be exactly as follows:

;TOOL MAGAZIN ZEROPOINT,TOOL=2,MAGAZIN=0,NPV=0,BNPV=0

However, you can modify the values for "Tool" and "Magazine".

Tool=1:	Delete all existing tools in tool management and replace with new tools.
Tool=2:	Add new tools to tool management
Magazine=0:	Do not evaluate magazine location number (\$TC_MPP6)
Magazine=1:	Evaluate magazine location number (\$TC_MPP6)

Note

Always keep to the precise order (including blanks) in the header. If you enter an incorrect header line, the INI file on opening will be evaluated as a G code program. Starting the program with "Cycle start" causes existing data in tool management to be overwritten by the data contained in the program.

The tool data must be assigned the following variables in the INI file, where:

- x = tool number
- y = cutting edge number

Table 8-12 Variable assignment

Variable	Description	Value			
\$TC_TP1[x]	Duplo number	Number			
\$TC_TP2[x]	Tool name	Name			
\$TC_TP3[x]	Number of adjacent half locations on the left to be blocked for oversized tools.	ShopMill default setting 1 = Do not disable adjacent location or 2 = Disable half of adjacent location to left			
\$TC_TP4[x]	Number of adjacent half locations on the right to be blocked for oversized tools.	ShopMill default setting 1 = Do not disable adjacent location or 2 = Disable half of adjacent location to right			
\$TC_TP5[x]	Number of adjacent half locations above to be blocked for oversized tools.	ShopMill default setting 1 = Do not disable adjacent location			
\$TC_TP6[x]	Number of adjacent half locations be- low to be blocked for oversized tools.	ShopMill default setting 1 = Do not disable adjacent location			
\$TC_TP7[x]	Magazine location type	Number			

8.11 Reading in tool data

Variable	Description	Value			
\$TC_TP8[x]	Tool status	Bit 1 = 1: Tool enabled Bit 2 = 1: Tool disabled Bit 4 = 1: Prewarning limit reached Bit 6 = 1: Tool fixed–location–coded			
\$TC_TP9[x]	Tool monitoring	Bit 0 = 1: Tool life monitoring active Bit 1 = 1: Workpiece count monitoring active Bit 2 = 1: Wear monitoring active			
\$TC_TPC1[x]	User-defined parameter 1				
\$TC_TPC2[x]	User-defined parameter 2				
\$TC_TPC3[x]	User-defined parameter 3				
\$TC_TPC4[x]	User-defined parameter 4				
\$TC_TPC5[x]	User-defined parameter 5				
\$TC_TPC6[x]	User-defined parameter 6				
\$TC_TPC7[x]	User-defined parameter 7				
\$TC_TPC8[x]	User-defined parameter 8				
\$TC_TPC9[x]	User-defined parameter 9				
\$TC_TPC10[x]	User-defined parameter 10				
\$TC_DP1[x,y]	Tool type	 110: Cylindrical die mill 111: Ball end mill 120: End mill 121: End mill with corner rounding 130: Angle head mill 140: Facing tool 155: Bevel cutter 156: Bevel cutter with corner rounding 157: Tapered die-sinking cutter 200: Twist drill 220: Centering tool 240: Tap 710: 3D probe 711: Edge probe 			
\$TC_DP3[x,y]	Length or Length Z	Number [mm] Number [mm]			
\$TC_DP4[x,y]	Length 2	Number [mm]			
	or Length Y	Number [mm]			
\$TC_DP5[x,y]	Length 3	Number [mm]			
	or Length X	Number [mm]			
\$TC_DP6[x,y]	Radius	Number [mm]			
	or internal radius (facing tool)	Number [mm]			
\$TC_DP7[x,y]	Rounding radius	Number [degrees]			
	or external radius (facing tool)	Number [degrees]			
\$TC_DP11[x,y]	Angle for tapered tools	Number [degrees]			
	or tool angle/bevel angle (facing tool)	Number [degrees]			
\$TC_DP12[x,y]	Wear length	Number [mm]			
	or Wear length Z	Number [mm]			

Table 8-12 Variable assignment

8 Tool Management

8.11 Reading in tool data

ariable assignment

Variable	Description	Value				
\$TC_DP13[x,y]	Wear length 2	Number [mm]				
	or Wear length Y	Number [mm]				
\$TC_DP14[x,y]	Wear length 3	Number [mm]				
	or Wear length X	Number [mm]				
\$TC_DP15[x,y]	Wear radius	Number [mm]				
\$TC_DP21[x,y]	Basis length 1	Number [mm]				
	or Basis length Z	Number [mm]				
\$TC_DP22[x,y]	Basis length 2	Number [mm]				
	or Basis length Y	Number [mm]				
\$TC DP23[x,y]	Basis length 3	Number [mm]				
	or Desite to set the X					
	Basis length X					
\$TC_DP24[X,1]	or	Number				
\$TC_DP24[x,y]	Angle tool point (drill)	Number [degrees]				
\$TC_DP25[x,1]	Direction of spindle rotation Coolant M function	Bit 8 and bit 9 = 0: Spindle stop Bit 8 = 1: Spindle rotates clockwise Bit 9 = 1: Spindle rotates counter-clockwise Bit 10 = 1: Cooling water 1 ON Bit 11 = 1: Cooling water 2 ON Bit 0 = 1: M function 1 Bit 1 = 1: M function 2 Bit 2 = 1: M function 3 Bit 3 = 1: M function 4				
\$TC_DPH[x,y]	H number of an ISO dialect program	Number				
\$TC_DPV[x,y]	Tool orientation +X, $-X$, +Y, $-Y$, +Z, $-Z$					
\$TC_DPV3[x,y]	Tool orientation vector 1	Number				
	or Tool orientation vector Z	Number				
\$TC_DPV4[x,y]	Tool orientation vector 2	Number				
	or Tool orientation vector Y	Number				
\$TC_DPV5[x,y]	Tool orientation vector 3	Number				
	or Tool orientation vector X	Number				
\$TC_MOP1[x,y]	Tool life warning limit	Number [min]				
\$TC_MOP2[x,y]	Tool life	Number [min]				
\$TC_MOP3[x,y]	Pre-warning limit for count	Number				
\$TC_MOP4[x,y]	Quantity	Number				
\$TC_MOP5[x,y]	Prewarning limit for wear	Number [mm]				
\$TC_MOP15[x,y]	Maximum wear	Number [mm]				
\$TC_MPP6[n,m]	Magazine location number	Number n: Magazine number m: Magazine location number				

For bit-coded parameters you must specify a hexadecimal value.

 $\hfill {\fill Communication}$ $\hfill {\fill Communication}$ Simular AG 2008 All Rights Reserved SINUMERIK 840D sl Commissioning CNC: ShopMill - 01/2008 Edition

8.11 Reading in tool data

The H number for ISO dialect programs is only analyzed if ShopMill is configured for ISO dialects (see chapter 11.2 "ISO dialects").

If you do not define parameters, tool management will subsequently set them to zero.

You must program the command "M30" at the end of the file.

Notes about loading the tool data into the tool management can be found in: **References:** /BASsI/, Operating/Programming ShopMill

Example

;TOOL MAGAZIN ZEROPOINT,TOOL=2,MAGAZIN=0,NPV=0,BNPV=0 \$TC TP1[1]=1 ;Duplo number \$TC TP2[1]=FRAESER ;Tool "mill" \$TC TP3[1]=1 ;Left adjacent location free \$TC TP4[1]=1 ;Right adjacent location free \$TC TP5[1]=1 ;Upper adjacent location free \$TC_TP6[1]=1 ;Lower adjacent location free \$TC_TP7[1]=1 ;Magazine location type ;Enable tool \$TC_TP8[1]=2 ;Tool life monitoring \$TC_TP9[1]=1 \$TC_DP1[1,1]=120 ;Tool type end mill \$TC_DP3[1,1]=120.41 ;Length \$TC DP6[1,1]=5 ;Radius \$TC_DP24[1,1]=3 ;Number of teeth . . . M30 ;End of program

8.11 Reading in tool data

Space for your notes

Additional Functions

9.1 Measuring cycles

9.1.1 Product brief

Overview	You can use measuring cycles for automatic measuring on vertical machining centers and universal milling machines with ShopMill.					
	This is achieved simply by connecting a touch trigger probe to the control.					
	References:	/FB2/, Function Manual on Expansion Functions, Measuring (M5); /GDsl/, Device Manual NCU, SINUMERIK 840D sl /IDsl/, Commissioning CNC: NCK, PLC, drive, SINUMERIK 840D sl				
Measuring cycles	The measuring c	cycles are supplied with ShopMill.				
	You have to adap machine.	pt the measuring cycle data to the specific characteristics of the				
Function test	The measuring p The functional te References:	ing probe operates internally with the command MEAS. nal test of the measuring probe is carried out by a part program. :: /PGA/, Programming Manual on Production Planning; /BNM/, Programming Manual on Measuring Cycles				

9.1 Measuring cycles

9.1.2 Display machine data measuring cycles

9747	CMM_ENABLE_MEAS_AUTO					
MD number	Enable auton	Enable automatic workpiece measurement				
Default setting: 1		Min. input limit: 0 Max. input limit: 1				
Changes effective as from	NOW	NOW Protection level: 3/4 Units: –				
Data type: BYTE	Valid as of software version: ShopMill 6.4					
Significance:	This MD enables the "Automatic workpiece measurement" function on the user interface. 0 = "Automatic workpiece measurement" function is not displayed 1 = "Automatic workpiece measurement" function is displayed.					

9749	CMM_ENAB	CMM ENABLE MEAS T AUTO				
MD number	Enable auton	natic tool measur	rement			
Default setting: 1	•	Min. input limit:	0		Max. input lim	nit: 1
Changes effective as from	NOW	Protection level: 3/4				Units: –
Data type: WORD	Valid as of software version: ShopMill 6.3					
Significance:	This MD enables the "Automatic tool measurement" function on the user interface. 0 = "Automatic tool measurement" function is not displayed 1 = "Automatic tool measurement" function is displayed					

9750	CMM MEAS PROBE INPUT					
MD number	Measuring inp	Measuring input for workpiece probe				
Default setting: 0		Min. input limit: 0 Max. input limit: 1				
Changes effective as from	NOW	OW Protection level: 3/4			Units: –	
Data type: BOOL	Valid as of software version:					
	ShopMill 4.3					
Significance:	This MD defines the measuring input for a workpiece measuring probe.					
	0 = measuring input 1 is activated					
	1 = measuring input 2 is activated					

9751	CMM_MEAS	CMM_MEAS_T_PROBE_INPUT					
MD number	Measuring in	Measuring input for tool probe					
Default setting: 1		Min. input limit: 0 Max. input limit: 1					
Changes effective as from	NOW	Protection level: 3/4			Units: –		
Data type: BOOL	Valid as of software version: ShopMill 4.3						
Significance:	This MD define	nes the measuring input for a	tool measuring	g probe.			
	0 = measurin) = measuring input 1 is activated					
	1 = measurin	g input 2 is activated					

9752	CMM_MEASURING_DISTANCE					
MD number	Max. measur	Max. measurement distance for workpiece measurement in the program				
Default setting: 5	Min. input limit: 0.01 Max. input limit: 1000				nit: 1000	
Changes effective as from	NOW	F	Protection level: 3/4			Units: mm
Data type: DOUBLE		Valid as of software version: ShopMill 4.3				
Significance:	This MD defin position (wor output within	nes the maximun kpiece edge) for this range the er	n measurem measuring th rror message	ent path before ne workpiece in "Probe does r	e and after the n the program. not switch" is o	expected switching If no switching signal is output.

9 Additional Functions

9753	CMM_MEAS_DIST_MAN					
MD number	Max. measur	Max. measurement distance of the workpiece measurement in manual mode				
Default setting: 10		Min. input limit: 0.01 Max. input limit: 1000				
Changes effective as from	NOW	Protection level: 3/	4 Units: mm			
Data type: DOUBLE	Valid as of software version: ShopMill 4.3					
Significance:	This MD defin position (wor output within	This MD defines the maximum measurement path before and after the expected switching position (workpiece edge) for measuring the workpiece in manual mode. If no switching signal is output within this range the error message "Probe does not switch" is output.				

9754	CMM_MEAS_DIST_TOOL_LENGTH					
MD number	Maximum me	Maximum measurement distance for tool length for rotating Spindle				
Default setting: 2		Min. input limit: 0.001		Max. input lim	nit: 1000	
Changes effective as from	NOW	Protection level: 3/4			Units: mm	
Data type: DOUBLE	Valid as of software version: ShopMill 4.3					
Significance:	This MD stipulates the maximum measurement distance before and after the expected switching position (tool length) for measuring the tool length with rotating spindle. If no switching signal is output within this range the error message "Probe does not switch" is output.					

9755	CMM_MEAS_DIST_TOOL_RADIUS						
MD number	Max. measur	Max. measurement distance for tool radius for rotating. Spindle					
Default setting: 1		Min. input limit: 0.001 Max. input limit: 1000					
Changes effective as from	NOW	Protection level: 3/4			Units: mm		
Data type: DOUBLE		Valid as of software version: ShopMill 4.3					
Significance:	This MD defir position (tool output within	This MD defines the maximum measurement path before and after the expected switching position (tool radius) for measuring the tool radius with rotating spindle. If no switching signal is output within this range the error message "Probe does not switch" is output.					

9756	CMM_MEAS	CMM_MEASURING_FEED					
MD number	Measuring fe	Measuring feed rate for workpiece measurement					
Default setting: 300		Min. input limit: 10 Max. input limit: 5000			nit: 5000		
Changes effective as from	NOW		Protection lev	vel: 3/4		Units: mm/min	
Data type: DOUBLE				Valid as of so	oftware version	:	
				ShopMill 4.3			
Significance:	With this MD	, you specify th	ne measuring f	eed for "Measu	ure workpiece"		

9757	CMM_FEED	CMM_FEED_WITH_COLL_CTRL					
MD number	Plane feed w	Plane feed with collision monitoring					
Default setting: 1000		Min. input limit: 10 Max. input limit: 5000					
Changes effective as from	NOW	Protection leve	el: 3/4		Units: mm/min		
Data type: DOUBLE	Valid as of software version: ShopMill 4.3						
Significance:	To protect the measuring bl deflection of t	To protect the probe, intermediate positions are approached with this feed in the plane as measuring blocks to monitor for collisions. This feed must be selected such that the maximum deflection of the probe is not exceeded should a collision occur.					

9 Additional Functions

9758	CMM_POS_FEED_WITH_COLL_CTRL					
MD number	Infeed with co	Infeed with collision monitoring				
Default setting: 1000		Min. input limit: 10 Max. input limit: 5000				
Changes effective as from	NOW	Prote	Protection level: 3/4		Units: mm/min	
Data type: DOUBLE	Valid as of software version: ShopMill 4.3					
Significance:	To protect the measuring block deflection of the deflection of the	e probe, intermediate ocks to monitor for c he probe is not exce	positions are ollisions. This f eded should a	approached with this fe eed must be selected s collision occur.	eed in the tool axis as such that the maximum	

9759	CMM_MAX_	CMM_MAX_CIRC_SPEED_ROT_SP				
MD number	Maximum cire	Maximum circumferential speed for tool measurement for rotating Spindle				
Default setting: 100	Min. input limit: 1 Max. input limit: 200					
Changes effective as from	NOW	Protection leve	l: 3/4	Units: m/min		
Data type: DOUBLE		N N	/alid as of software ve	ersion:		
		5	ShopMill 4.3			
Significance:	This MD is used to stipulate the maximum permissible circumferential speed of the tools to be measured for tool measurement with rotating spindle. The permissible spindle speed for carrying					
	out tool meas	surement is calculated accordin	ng to this MD.			

9760	CMM_MAX_	CMM_MAX_SPIND_SPEED_ROT_SP					
MD number	Maximum spe	eed for tool me	asurement for	rotating Spind	le		
Default setting: 1000		Min. input limit: 100 Max. input limit: 25000				nit: 25000	
Changes effective as from	NOW	Protection level: 3/4			Units: rev/min		
Data type: DOUBLE				Valid as of so	oftware version	:	
				ShopMill 4.3			
Significance:	This MD is us	This MD is used to stipulate the maximum permissible rotational speed of the tools to be					
	measured for	tool measurer	ment with rotat	ing spindle.			

9761	CMM_MIN_F	CMM_MIN_FEED_ROT_SP				
MD number	Min. feed rate	e for workpiece	measurement	for rotating Sp	pindle	
Default setting: 10		Min. input limit: 0.01 Max. input limit: 1000				nit: 1000
Changes effective as from	NOW		Protection level: 3/4			Units: mm/min
Data type: DOUBLE				Valid as of so	ftware version	:
				ShopMill 4.3		
Significance:	This MD defin	This MD defines the minimum feed rate for tool measurement with a rotating spindle. Tools which				
	have a very la	arge radius and	d require high	precision would	d otherwise ha	ve a very small feed.

9762	CMM_MEAS_TOL_ROT_SP					
MD number	Measuring ac	ccuracy. of tool measureme	nt for rotating. S	Spindle		
Default setting: 0.01	- -	Min. input limit: 0		Max. input limit: 1		
Changes effective as from	NOW	Protection I	evel: 3/4	Units: mm		
Data type: DOUBLE			Valid as of so	oftware version:		
	ShopMill 4.3					
Significance:	This MD defin	nes the desired measuring	accuracy for too	ol measurement with a rotating spindle.		

9763	CMM_TOOL_PROBE_TYPE				
MD number	Tool probe typ	pe			
Default setting: 0		Min. input limit: 0		Max. input lim	iit: 999
Changes effective as from	NOW	Protection lev	/el: 3/4		Units: –
Data type: WORD			Valid as of so ShopMill 4.3	ftware version:	
Significance:	This MD is us 0 = measurin 101 = zero di 201 = zero di 301 = zero di	sed to define the type of tool i g cube sk in XY (1st and 2nd geome sk in ZX (3rd and 1st geome sk in YZ (2nd and 3rd geome	measuring prot etry axis) try axis) etry axis)	De.	

9764	CMM TOOL PROBE ALLOW AXIS						
MD number	Permissible axis directions of tool probe						
Default setting: 133	Min. input lim	iit: O		Max. input lin	nit: 333		
Changes effective as from	NOW	Protection lev	vel: 3/4	•	Units: –		
Data type: WORD		<u>.</u>	Valid as of so ShopMill 4.3	oftware versior	1:		
Significance:	With this MD, you specify the measure. The number to be specified axis: 0 = not possible 1 = only in negative direction 2 = only in positive direction 3 = in both directions	ne permissible is made up of n	axes and axes	s directions in t	which the tool probe can s can be specified for each		
Application example:	Default setting 133 means, 1st number (1): Measureme 2nd number (3): Measurem 3rd number (3): Measuring	ent in Z only po ent in Y possit in X possible i	ossible in minus ble in both direc n both directior	s direction ctions าร			

9765	CMM_T_PROBE	CMM_T_PROBE_DIAM_LENGTH_MEA				
MD number	Diameter tool prol	Diameter tool probe length measurement				
Default setting: 0	Min	i. input limit: 0		Max. input lin	nit: 100000	
Changes effective as from	NOW	NOW Protection level: 3/4			Units: mm	
Data type: DOUBLE		Valid as of software version: ShopMill 4.3				
Significance:	With this MD, you length measurem	With this MD, you specify the effective diameter or the effective edge of the tool probe for the tool length measurement.				

9766	CMM_T_PR	CMM_T_PROBE_DIAM_RAD_MEAS				
MD number	Diameter too	Diameter tool probe radius measurement				
Default setting: 0	-	Min. input lim	it: 0		Max. input lin	nit: 100000
Changes effective as from	NOW	Protection level: 3/4		/el: 3/4		Units: mm
Data type: DOUBLE		Valid as of software version: ShopMill 4.3				
Significance:	With this MD radius measu	, you specify th urement.	ne effective dia	meter or the e	ffective edge o	f the tool probe for the

9 Additional Functions

9767	CMM_T_PRO	CMM_T_PROBE_DIST_RAD_MEAS				
MD number	Infeed tool pr	Infeed tool probe upper edge for radius measurement				
Default setting: 0		Min. input lim	it: 0		Max. input lin	nit: 100000
Changes effective as from	NOW	Protection level: 3/4			Units: mm	
Data type: DOUBLE		Valid as of software version: ShopMill 4.3				
Significance:	With this MD, for the radius	you specify th measurement	e distance bet	ween the tool p	probe upper eo	dge and the tool lower edge

9768	CMM_T_PROBE_APPROACH_DIR					
MD number	Plane approa	Plane approach direction for tool probe				
Default setting: -1		Min. input lim	it: –2		Max. input lin	nit: 2
Changes effective as from	NOW		Protection lev	/el: 3/4		Units: –
Data type: BYTE				Valid as of so ShopMill 4.3	oftware version	:
Significance:	This is MD is the tool meas -1 = 1st plan +1 = 1st plan -2 = 2nd plar +2 = 2nd plar	used to specif suring probe. e axis in negat e axis in positi ne axis in nega ne axis in posit	y the approach ive direction ve direction tive direction ive direction	n direction on t	the plane on wł	nich the tool approaches

9769 MD number	CMM_FEED_FACTOR_1_ROT_SP						
Default setting: 10	Feeu fale lac	Min. input limit: 0	olaling. sp.	Max. input lim	nit: 100		
Changes effective as from	NOW	Protection le	vel: 3/4	· ·	Units: –		
Data type: DOUBLE		Valid as of software version: ShopMill 6.3					
Significance:	This MD spec rotating spind 0: Only on	This MD specifies the feed factor for the 1st measuring operation for tool measurement with rotating spindle.					
	>0: 1st mea 2nd me	asuring operation with meas asuring operation with meas	uring feed mult uring feed	iplied by feed fa	actor 1		

9770	CMM_FEED_FACTOR_2_ROT_SP						
MD number	Feed rate factor 2 tool mea	Feed rate factor 2 tool measurement for rotating. sp.					
Default setting: 0	Min. input lim	nit: O		Max. input lim	nit: 50		
Changes effective as from	NOW	Protection lev	/el: 3/4		Units: –		
Data type: DOUBLE	Valid as of software version: ShopMill 6.3						
Significance:	This MD specifies the feed rotating spindle. This factor The feed factor should be lo CMM_FEED_FACTOR_1_	factor for the 2 is only active i ess than the fe ROT_SP.	nd measuring f MD 9769 CN ed factor in ME	operation for to IM_FEED_FAC) 9769	ool measurement with CTOR_1_ROT_SP > 0.		
	 Only two measurements are taken 1st measuring operation with measuring feed multiplied by feed factor 1 2nd measuring operation with measuring feed multiplied by feed factor 2 3rd measuring operation with measuring feed 						

9771	CMM_MAX_	CMM_MAX_FEED_ROT_SP					
MD number	Maximum fee	Maximum feed for tool measurement for rotating Spindle					
Default setting: 20	•	Min. input limit: 1 Max. inpu			nit: 1000		
Changes effective as from	NOW	Protection level: 3/4			Units: mm/min		
Data type: DOUBLE		Valid as of software version: ShopMill 6.3					
Significance:	This MD defin	nes the maximum feed	rate for tool measu	rement with a ro	otating spindle.		

9772	CMM_T_PR	CMM_T_PROBE_MEASURING_DIST				
MD number	Measuremen	leasurement distance for tool measurement with stationary spindle				
Default setting: 5	- -	Min. input lim	it: 1		Max. input lin	nit: 1000
Changes effective as from	NOW	Protection level: 3/4			Units: mm	
Data type: DOUBLE				Valid as of so	oftware version	
				ShopMill 6.3		
Significance:	This MD is us	This MD is used to stipulate the measurement distance for tool measurement with stationary				
	spindle and d	uring probe ca	libration.			

9773	CMM_T_PR	CMM_T_PROBE_MEASURING_FEED				
MD number	Feed rate for	Feed rate for tool measurement with stationary spindle				
Default setting: 300	-	Min. input lim	it: 10		Max. input lin	nit: 5000
Changes effective as from	NOW	Protection level: 3/4			Units: mm/min	
Data type: DOUBLE			·	Valid as of so	oftware version	
				ShopMill 6.3		
Significance:	This MD is us	This MD is used to stipulate the feed for tool measurement with stationary spindle and during				
	probe calibra	tion.				

9774	CMM_T_PROBE_MANUFACTURER						
MD number	Tool probe typ	Tool probe type (manufacturer)					
Default setting: 0		Min. input lim	it: 0		Max. input lin	nit: 2	
Changes effective as from	NOW		Protection lev	/el: 3/4		Units: –	
Data type: WORD		Valid as of software version: ShopMill 6.3					
Significance:	This MD defir measuring pr 0 = no data 1 = TT130 He 2 = TS27R R	nes the tool me obe models ca eidenhain enishaw	easuring probe in be used for t	type so that tool measurer	predefined offse ment with rotatir	et tables of some tool ng spindle.	

9775	CMM_T_PROBE_OFFSET				
MD number	Measurement result correction for tool measurement for rotating sp.				
Default setting: 0	Min. input limit: 0		Max. input limit: 2		
Changes effective as from	NOW	Protection level: 3/4			Units: –
Data type: WORD	Valid as of software version:			:	
	ShopMill 6.3				
Significance:	With this MD, you can act	ivate a measurir	ng result correct	ction. Such an	offset may be necessary if
	the tool measuring probe switches differently for different rotational speeds of the tool to be				
	measured.				
	0 = no offset				
	1 = offset by means of predefined offset tables (for TT130 Heidenhain or TS27R Renishaw)				
	2 = offset via user-defined offset tables (see /BNM/, User's Guide Measuring Cycles,				
	_MT_EC_R[] and _MT_EC_L[])				
	(The user-defined offset is also carried out if MD 9774 CMM_T_PROBE_MANUFACTURER = 1				
	or 2)				

9 Additional Functions

9776	CMM MEAS	SETTINGS				
MD number	Settings for measuring cycles					
Default setting: 0	Min. input limit: –			Max. input limit: –		
Changes effective as from	NOW		Protection lev	/el: 3/4		Units: –
Data type: WORD	Valid as of software version: ShopMill 6.3			:		
Significance:	Bit 0 = 0: During workpiece measurement and calibration of the workpiece probe, the spindle is automatically rotated to a defined starting position. (The starting position results automatically from the rotation of the workpiece coordinate system about the tool axis so that the same point always points to the measuring probe ball in the positive direction of the 1st axis of the plane of this coordinate system (for G17 in X)). Bit 0 = 1: During workpiece measurement and calibration of the workpiece probe, the current spindle position is taken as the starting position for the measuring cycles. Bit 1 = 0: Calibration of the workpiece probe in a boring with unknown center. Bit 1 = 1: Calibration of the workpiece probe in a boring with known center. For this, the measuring probe workpiece measurement					

9778	CMM_MEAS_PROBE_SOUTH_POLE			
MD number	Measuring probe length referenced to lower edge			
Default setting: 1	Min. input limit: 0 Max. input limit: 1			
Changes effective as from	NOW	Protection leve	el: 3/4	Units: –
Data type: BYTE	Valid as of software version:			
	ShopMill 6.4			
Significance:	This machine data defines the reference point for the workpiece measuring probe length.			
	0: The ball center is defined as reference point.			
	1: The lower edge of the ball (south pole) is defined as reference point.			

9779	CMM_MEAS_PROBE_IS_MONO					
MD number	Workpiece measuring probe is mono probe					
Default setting: 0	Min. input limit: 0 Max			Max. input lin	ax. input limit: 1	
Changes effective as from	NOW		Protection lev	/el: 3/4	-	Units: –
Data type: BYTE	Valid as of software version:			1:		
	ShopMill 7.1					
Significance:	This machine data defines the workpiece measuring probe as mono probe. A mono probe can be					
	turned to an angle using SPOS. It is positioned so that it always uses the same edge at the					
	workpiece for measurements.					
	0: Workpiece measuring probe is not a mono probe					
	1: Workpiece measuring probe is mono probe					

9.2 Network link

9.2.1 General description

Option The function "Managing network drives" is an option with Order No. 6FC5 800–0AP01–0YB0.

For installing the network, please refer to

References: /IHE/, Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl; /IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840D/840Di 9.3 Cylinder surface transformation

9.3 Cylinder surface transformation

9.3.1 **Function**

Option The function "Cylinder surface transformation" can only be used if the function "Tracyl" (option) is used in the standard. The Order No. is: 6FC5 800-0AM27-0YB0.

General The cylinder surface transformation is required in order to machine the following:

- Longitudinal grooves on cylindrical bodies,
- Transverse grooves on cylindrical objects,
- Grooves with any path on cylindrical bodies.

The groove contour is programmed in relation to the developed, plane surface of the cylinder. The program can include line/circle, drilling or milling cycles or profiling (free contour programming).

There are two variants of cylinder surface transformation, i.e.

- with groove wall offset (ON)
- without groove wall offset (OFF)



Fig. 9-1 Grooves with and without groove wall offset

Enable cylinder The function "Cylinder surface transformation" is displayed on the ShopMill opsurface erator interface if the display MD 9721 \$MM CMM ENABLE TRACYL=1 is used. The rotary axis involved in the cylinder surface transformatransformation tion is displayed and programmed via display MD 9653

\$MM CMM ENABLE A AXIS or 9720 \$MM CMM ENABLE B AXIS.

The cylinder surface transformation function is selected and deselected via "Miscellaneous", "Transformations", "Cylinder surface" softkey on the ShopMill Operator interface and is described in:

/BASsl/, Operation/Programming ShopMill **References:**

9.3.2 Example of how to set an axis configuration

 Legend:

 X
 Axis parallel to rotary axis

 X
 Supplementary axis

 Z
 Feed axis perpendicular to rotary axis

 Z
 Feed axis perpendicular to rotary axis

 Z
 Rotary axis

 Z
 Main spindle

Fig. 9-2 Machining grooves on a cylinder surface with X-C-Z kinematics

You must configure 2 data blocks with the following machine data for the machine illustrated above:

20070	\$MC_AXCONF_MACHAX_USED[4]=5
	Number of channel axes
20080	\$MC_AXCONF_CHANAX_NAME_TAB[0]="XC"
	Channel axis XC
20080	\$MC AXCONF CHANAX NAME TAB[1]="YC"
	Channel axis YC
20080	\$MC_AXCONF_CHANAX_NAME_TAB[2]="ZC"
	Channel axis ZC
20080	\$MC AXCONF CHANAX NAME TAB[3]="A"
	Channel axis A
20080	\$MC AXCONF CHANAX NAME TAB[4]="C"
	Channel axis C

Example

The following example illustrates how to set the axis configuration on a machine.

9.3

9.3 Cylinder surface transformation

General setti 10602	ings for the transformations: \$MN FRAME GEOAX CHANGE MODE=1
Data block fo	pr the 1st transformation in the channel:
24100	\$MC TRAFO TYPE 1= 512
	Transformer type $(512 = Cylinder surface transformation without)$
	groove side compensation)
24110	\$MC TRAFO AXES IN 1[0]=3
	Channel axis: Feed axis vertical to rotary axis (Z)
24110	\$MC TRAFO AXES IN 1[1]=4
	Channel axis: Rotary axis (A)
24110	\$MC TRAFO AXES IN 1[2]=1
	Channel axis: Axis parallel to rotary axis (X)
24110	\$MC_TRAFO_AXES_IN_1[3]=2
	Channel axis: Supplementary axis (Y)
24120	\$MC_TRAFO_GEOAX_ASSIGN_TAB_1[0]=1
	Channel axis: 1. Geometry axis (X)
24120	\$MC_TRAFO_GEOAX_ASSIGN_TAB_1[1]=4
	Channel axis: 2. Geometry axis (A)
24120	\$MC_TRAFO_GEOAX_ASSIGN_TAB_1[2]=3
	Channel axis: 3. Geometry axis (Z)
24800	\$MC_TRACYL_ROT_AX_OFFSET_1=0
	Offset of the rotary axis for the 1st TRACYL transformation
24805	\$MC_TRACYL_ROT_AX_FRAME_1=1
	Axial offset of the rotary axis for the 1st TRACYL
	transformation
24810	\$MC_IRACYL_ROT_SIGN_IS_PLUS_1=1
0.4000	Sign for the rotary axis for the 1st TRACYL transformation
24820	\$MC_IRACYL_BASE_IOOL_1[n]=0
	vector of the basic tool for the 1st IRACYL transformation
Data block for	or the 2nd transformation in the channel:
24200	\$MC_TRAFO_TYPE_2= 513
	Transformer type (513 = Cylinder surface transformer with
	groove side compensation)
24210	\$MC_TRAFO_AXES_IN_2[0]=3
	Channel axis: Feed axis vertical to rotary axis (Z)
24210	\$MC_TRAFO_AXES_IN_2[1]=4
	Channel axis: Rotary axis (A)
24210	\$MC_TRAFO_AXES_IN_2[2]=1
	Channel axis: Axis parallel to rotary axis (X)
24210	\$MC_TRAFO_AXES_IN_2[3]=2
0.4000	
24220	\$MC_TRAFO_GEOAX_ASSIGN_TAB_2[0]=1
04000	
24220	SMC_TRAFO_GEOAX_ASSIGN_TAB_2[1]=4
04000	
24220	SMU_TRAFU_GEUAX_ASSIGN_TAD_2[2]=3
24850	MC TRACVI ROT AY OFFSET 2-0
24000	Offset of the rotary axis for the 2nd TBACVL transformation
24855	SMC TRACYL BOT AX FRAME 2-1
27000	Axial offset for the 2nd TRACYI
	transformation
24860	SMC TRACYL BOT SIGN IS PLUS 2=1
1,000	Sign for the rotary axis for the 2nd TRACYL transformation
24870	\$MC_TRACYL_BASE_TOOL[n]=0

Vector of the basic tool for the 2nd TRACYL transformation

Note

For both data blocks, you can use any transformations from all available transformations (24100 \$MC_TRAFO_TYPE_1, 24200 \$MC_TRAFO_TYPE_2 etc.). The two data blocks need not be directly next to each other. However, the 1st data block must always be used for "Cylinder surface transformation without groove side offset" (= 512) and the 2nd data block for "Cylinder surface transformation with groove side offset" (=513).

9.3

9.4 Swivel heads and tables

9.4 Swivel heads and tables

Swivel heads and tables are used to create or process slanted planes. Display MD 9723 \$MM CMM ENABLE SWIVELLING HEAD is set to enable the swiveling function. You must set up a swivel data record for every swivel head, swivel table or combination of both. You can define swivel data sets using the "Swivel cycle" softkey in the "Commissioning" operating area on the CNC-ISO operator interface. User-specific customizations of the swivel function can be performed in the TOOLCARR swivel cycle. A detailed description of the commissioning process (defining swivel data records and adapting swivel cycle TOOLCARR) can be found in: References: /PGZ/, Programming Manual on Cycles Interrupts During the manual setting of the swivel head/table, alarms are issued that indicate the required angles: 62180 manually setting both axes manually setting one axis 62181 With a Hirth tooth system, the corresponding rotary axes can only assume certain positions (angle grid > 0). If the programming requires a position that deviates from the angle grid, the machine automatically sets the adjacent position and issues an alarm. 112328 Angle adapted to angle grid The swivel cycle TOOLCARR allows for defining how the alarm must be acknowledged. If the processing of the workpiece requires an angle of the swivel head/table that falls outside the valid angle area, an alarm is issued: 61184 No solution possible with current angle values The programmed processing cannot be performed using the existing swivel head/table. For manual loading/unloading or replacing of swivel heads, ShopMill issues one of the following alarms: 112323 Unload swivel head 112324 Load swivel head 112325 Replace swivel head In addition, the swivel cycle TOOLCARR is called for loading/unloading or replacing swivel heads.

9.5 Multiple clamping

The "Multiple clamping" function optimizes tool changes over several workpiece clampings. On the one hand, this reduces downtimes and, on the other, eliminates tool change times because a tool performs as many machining operations as possible in all clampings before the next tool change is initiated.

You can either process the same program multiple times on the clampings or you can select different programs.

The function "Multiple clamping with different programs" is a software option with the Order No. 6FC5 800–0AP14–0YB0.

If you are using large–area fixture plates on your machine, you do not have to set up anything else. In the case of rotating clamping devices, on the other hand, you must adapt a cycle to match the features of the clamping device so as to ensure that the next workpiece can be turned to the machining position after machining of the previous one (or for multiple clamping devices even while the current workpiece is being machined).

Please proceed as follows:

- Change the cycle CLAMP.SPF which is stored in the directory CYCLES\SC\PROG\TEMPLATES_DEU or \TEMPLATES_ENG.
- Copy the cycle into the user or manufacturer cycles directory.



Example

Fig. 9-3 Rotating clamping device (reversible clamping device)

9 Additional Functions

In the example, a rotating clamping device (reversible clamping device) is used with 4 clampings. The clampings can be processed by positioning rotary axis A. Clamping 1: $A = 0^{\circ}$

Clamping 1: $A = 0^{\circ}$ Clamping 2: $A = 90^{\circ}$ Clamping 3: $A = 180^{\circ}$ Clamping 4: $A = 270^{\circ}$

The cycle CLAMP.SPF must be adapted as follows:

 DEF INT _NV	; Auxiliary variable
;	
; IF_ACT==1 G0 A=DC(0) ENDIF ; IF_ACT==2	
G0 A=DC(90) ENDIF	
; IF _ACT==3 G0 A=DC(180) ENDIF	
; IF _ACT==4 G0 A=DC(270) ENDIF	
; NV=_NPV+_ACT N10 G[8]=_NV RET	; Calculate current zero offset ; No calculation permitted here

9.6 Measuring cycle support in the G code editor

In ShopMill you can integrate screen forms which provide support for programming measuring cycles into the G code editor. These cycles can then be recompiled automatically.

The "measuring cycles" function is a software option with Order No. 6FC5 800–0AP28–0YB0.

For more information on measuring cycle support please refer to:

References: /BNM/, Programming Manual on Measuring Cycles

For commissioning, proceed as follows:

ShopMill	on	NC	U
(HMI Em	bed	ded	sl)

 Remove the semicolon ";" preceding the following line in the file STAN-DARD_CYCLES\COMMON.COM:

;sc8407=aeditor.com ;Milling measuring cycles (horizontal softkey 7 ;on the expanded softkey bar in the ;G-code editor)

This creates the link between the softkey, with which you call the measuring cycle support, and the configuration file of this support mask.

- Remove the semicolon ";" preceding the following line in file STANDARD_CYCLES\COMMON.COM:
 ; sc617=startup.com
 ;Commissioning operating area (horizontal ;softkey 7 on the expanded softkey bar)
 You can modify the characteristics of the measuring cycle support in the commissioning operating area.
- Restart the machine.
- If required, modify the characteristics for the measuring cycle support in the "Commissioning" → ">" → "Measuring cycles" menu.

9.6 Measuring cycle support in the G code editor

PCU 50.3 Prereauisite: During commissioning of HMI Advanced, the files AEDITOR.COM and STAR-TUP.COM were automatically created in the STANDARD CYCLES directory (CST.DIR). During commissioning of ShopMill, the archive SM CYC.ARC was loaded from the PCU 50.3 into the NC. The COMMON.COM file was automatically copied to the STANDARD CYCLES directory (CST.DIR). Copy the archive MCSUPP from the ARCHIVES\CYCLE AR-CHIVES\MCYC. If you want to use the measurement result displays, you need to copy the MCRESULT archive from the ARCHIVES\CYCLE_ARCHIVES\MCYC directory. If the versions of the standard measuring cycles supplied with ShopMill (see the file SIEMENSD.RTF or SIEMENSE.RTF on the software CD) deviate from the measuring cycles of HMI Advanced (see ARCHIVES) CYCLE ARCHIVES\MCYC\VERSION.ARC) in the first four digits (e.g. 06.02), you must import the archive MCYCMILL from the directory AR-CHIVES\CYCLE ARCHIVES\MCYC. In the file STANDARD CYCLES\COMMON.COM, remove the semicolon ";" preceding the following line: ;sc8407=aeditor.com ;Milling measuring cycles (horizontal softkey 7 ;on the expanded softkey bar in the ;G-code editor) In the file STANDARD CYCLES\AEDITOR.COM, remove the semicolon ";" preceding the following lines: ;HS15=(\$83531,,se1) ; PRESS(HS15) ; LS("F mess", "MZ SKL.COM", 1) ;END PRESS This creates the link between the softkey, with which you call the measuring cycle support, and the configuration file of this support mask. In the file STANDARD CYCLES\STARTUP.COM remove the semicolon ";" preceding the following lines: ;HS15=(\$83070,,se1)

; PRESS (HS15) ; LS("Messz") ; END_PRESS This allows you to modify the characteristics of the measuring cycle support in the Commissioning operating area.

- Restart the PCU 50.3.
- If required, modify the characteristics for the measuring cycle support in the "Commissioning" → ">" → "Measuring cycles" menu.

Customer–Specific Operator Interface 10

10.1 Configuring the customized boot screen

For the ShopMill variant with PCU 50.3, you can create your own customer image (company logo, etc.) which appears while loading the control. For this purpose, you create an image in 256–color mode. The maximum size of the image is 224x224 pixels for OP010/OP010C/OP010S/OP012 and 352x352 pixels for OP015 352x352.

Details on how to proceed during configuration and when exchanging the startup image can be found in:

References:

/IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840D/840Di

10.2 Configuring the custom screen

Screen form

properties

10.2 Configuring the custom screen

You can use the "operator interface extension" software to build your own custom screens with specific functional expansions (e.g. custom cycles and measuring cycles) or just create your own screen layout (static screens).

References: /IAM/, Commissioning Base Software and HMI Advanced, Operator Interface Extension, SINUMERIK 840D sl/840D/840Di; /IHE/, Commissioning Base Software and HMI Embedded sl, Operator Interface Extension, SINUMERIK 840D sl

In ShopMill, you cannot specify any dimensions for configuration of the main part of the screen form. The position and size of the various main parts of the screen are fixed according to the operating area and mode. This only applies for screens that can be accessed via entry softkeys.

> Exit screen Softkey Size Dimensions X-pos. = 0 Manual operating Vertical softkey 1 Y-pos. = 272 mode - Zero point height = 158 pixels workpiece/Measure Vertical softkey 7 width = 556 pixels workpiece Large X-pos. = 0Manual operating Horizontal softkey 8 Y-pos. = 34 mode height = 396 pixels width = 556 pixels Manual operating Horizontal softkey 8 Medium X-pos. = 0Y-pos. = 78 mode height = 352 pixels width = 556 pixels Manual operating Horizontal softkev 8 Small X-pos. = 0Y-pos. = 254 mode height = 176 pixels width = 556 pixels X-pos. = 0 Automatic mode Horizontal softkey 6 Large Y-pos. = 34 height = 396 pixels width = 556 pixels Automatic mode X-pos. = 0 Horizontal softkey 6 Medium Y-pos. = 78 height = 352 pixels width = 556 pixels Automatic mode Small X-pos. = 0 Horizontal softkey 6 Y-pos. = 254 height = 176 pixels width = 556 pixels **Operating Area** X-pos. = 33 Vertical softkey 6 Y-pos. = 52 Program height = 378 pixels Drilling/Milling width = 523 pixels

Table 10-1 Specified dimensions of the forms in ShopMill
Exit screen	Softkey	Size	Dimensions
Program operating area – Miscellaneous	Vertical softkey 4		X–pos. = 33 Y–pos. = 52 height = 378 pixels width = 523 pixels
Operating Area Program – G–Code Editor	Horizontal softkey 2 Horizontal softkey 6		X–pos. = 0 Y–pos. = 34 height = 396 pixels width = 556 pixels
Alarms operating area	Horizontal softkey 7 Horizontal softkey 8		X–pos. = 0 Y–pos. = 34 height = 396 pixels width = 556 pixels
Operating area – Tools/ Zero offsets	Horizontal softkey 7		X–pos. = 0 Y–pos. = 34 height = 396 pixels width = 556 pixels

Table 10-1	Specified dimensions of the forms in ShopMill
------------	-----------------------------------------------

Generate code	Do not enter a target directory for the program operating area and the manual
	mode. ShopMill defines the target file.

Entry softkeys The customized static screens can be displayed with the following entry softkeys, the SC number being the link between the entry softkey and the configuration file of the screen.

In manual and automatic modes you have the choice between different sized screens that fill the following window areas:

- Large: Status area, position display, or program display and input window
- Medium: Position display or program display and input window
- Small: Input window

Table 10-2Entry softkeys for screens

Exit screen	Softkey	Size	SCxxxx
Manual operating mode	Horizontal softkey 8	Large	SC818
	Horizontal softkey 8	Medium	SC8181
	Horizontal softkey 8	Small	SC8182
Automatic mode	Horizontal softkey 6	Small	SC826
	Horizontal softkey 6	Medium	SC8261
	Horizontal softkey 6	Large	SC8262
Messages/Alarms oper- ating area	Horizontal softkey 7		SC857
Messages/Alarms oper- ating area	Horizontal softkey 8		SC858
Operating area – Tools/ Zero offsets	Horizontal softkey 7		SC867

10.2 Configuring the custom screen

Note

The form size is fixed in ShopMill (see above "Form Properties"). Take note of this in case you would like to program background images, for example, for screens you configured yourself.

Note

Open a user-configured screen before calling a softkey bar.

You can call your own cycles by means of the following access softkeys:

Table 10-3 Entry softkeys for cycles

Exit screen	Softkey	SCxxxx
Program operating area – Drilling	Vertical softkey 6	SC8426
Program operating area – Milling	Vertical softkey 6	SC8436
Program operating area – Miscellaneous	Vertical softkey 4	SC8454

Note

In manual mode you can also assign your own user cycle to horizontal softkey 8. The NC code generated is then collected and you can then start the cycle with "Cycle Start".

You can use the following entry softkeys to reveal your own measuring cycles, which are to replace the ShopMill measuring cycles:

Table 10-4Entry softkeys for measuring cycles

Exit screen	Softkey	SCxxxx
Manual operating mode – Zero point work- piece	Vertical softkey 1	SC8131
Manual operating mode – Zero point work- piece	Vertical softkey 2	SC8132
Manual operating mode – Zero point work- piece	Vertical softkey 3	SC8133
Manual operating mode – Zero point work- piece	Vertical softkey 4	SC8134
Manual operating mode – Zero point work- piece	Vertical softkey 5	SC8135
Manual operating mode – Zero point work- piece	Vertical softkey 6	SC8136
Manual operating mode – Zero point work- piece	Vertical softkey 7	SC8137

Exit screen	Softkey	SCxxxx
Manual operating mode – Tool measure- ment	Vertical softkey 1	SC8141
Manual operating mode – Tool measure- ment	Vertical softkey 2	SC8142
Manual operating mode – Tool measure- ment	Vertical softkey 3	SC8143
Manual operating mode – Tool measure- ment	Vertical softkey 4	SC8144
Manual operating mode – Tool measure- ment	Vertical softkey 5	SC8145
Manual operating mode – Tool measure- ment	Vertical softkey 6	SC8146
Manual operating mode – Tool measure- ment	Vertical softkey 7	SC8147
Operating area program – Miscellaneous – Zero point workpiece	Vertical softkey 1	SC8951
Operating area program – Miscellaneous – Zero point workpiece	Vertical softkey 2	SC8952
Operating area program – Miscellaneous – Zero point workpiece	Vertical softkey 3	SC8953
Operating area program – Miscellaneous – Zero point workpiece	Vertical softkey 4	SC8954
Operating area program – Miscellaneous – Zero point workpiece	Vertical softkey 5	SC8955
Operating area program – Miscellaneous – Zero point workpiece	Vertical softkey 6	SC8956
Operating area program – Miscellaneous – Zero point workpiece	Vertical softkey 7	SC8957
Operating area program – Miscellaneous – Tool measurement	Vertical softkey 1	SC8961
Operating area program – Miscellaneous – Tool measurement	Vertical softkey 2	SC8962
Operating area program – Miscellaneous – Tool measurement	Vertical softkey 3	SC8963
Operating area program – Miscellaneous – Tool measurement	Vertical softkey 4	SC8964
Operating area program – Miscellaneous – Tool measurement	Vertical softkey 5	SC8965
Operating area program – Miscellaneous – Tool measurement	Vertical softkey 6	SC8966
Operating area program – Miscellaneous – Tool measurement	Vertical softkey 7	SC8967

Table 10-4 Entry softkeys for measuring cycles

10.2 Configuring the custom screen

10.2.1 Transferring cycles to the machining plan

You can transfer all user cycles that you have inserted in the operating area program (including measuring cycles) to the machining plan and edit them there. However, the cycles will not be displayed as programming graphics.

Use the "operator interface extension" software to define the cycle. Note that the cycle must contain the function Generate Code (GC) and an OUTPUT method so that NC code is generated and sent to NCK for processing.

If you call up and take over the cycle on the ShopMill operator interface, the cycle will automatically appear in the machining plan. The screen form name of the cycle will appear in the machining plan as plain text.

10.2.2 Linking cycles into the machining plan

You can link user cycles into the machining plan with the ShopMill "Positions" cycles.

Name	The name of the cycles to be linked in the work plan is mandatory and must not be changed: E_DR_Ox with x = 1 to 8	
Variables	The following variables must be configured within the cycles:	
	You must first define three variables which are not assigned until the program step is inserted in the ShopMill machining plan, i.e. the attribute must be assigned invisibly (wr0) to the input field of each variable. The variable sequence is as follows:	
	1. Variable for the next tool, data type String (S)	
	2. Variable for the position identifier in objects, data type Integer	
	 Variable for the sequencer text that is to be displayed in the ShopMill work schedule, data type character string (S) The easiest way to assign a value to this variable is in a LOAD method. 	
	Two variables for cycles processing must also be defined as well as one vari- able for each toggle field which has a different display content on the interface (e.g. mm/rev) than the internally transferred quantity (e.g. 1). You need to assign the attribute invisible (wr0) to these variables too as they do not have their own input field. You can place the variables in any order.	
Note		
	When an OUTPUT method is used, all variables described above must be configured within this method so that they can all be interpreted on recompilation.	
Once–only machining	If an operating step should not be performed at all positions but, instead, only once, the user variable E_ONETIME = 1 must be set in the corresponding cycle. This allows for implementing modal changes for the subsequent technologies. Application example: Toggle between the parallel axes W and Z for a boring mill.	

10.2 Configuring the custom screen

Example

The directory CYCLES\SC\PROG\TEMPLATES_DEU or CYCLES\SC\PROG\TEMPLATES_ENG contains a sample cycle E_DR_O1.SPF. The associated operator interface is configured in the E_DR_O1.COM file. The German and English texts are stored in the E_DR_TXD.COM and E_DR_TXE.COM files respectively. A number of help displays are also included with the sample cycle.

Please see the README.TXT file for information on how to install the cycle.

10.2 Configuring the custom screen

10.2.3 Integrating measuring cycles

Manual operating
modeIf you wish to integrate your own measuring cycles in Manual mode, vertical
softkey 8 (VS8) in the new cycles screen acquires a special meaning. All ac-
tions that the new measuring cycle is supposed to perform after the "cycle start"
key has been pressed must be defined in a PRESS method for VSK8. If you
press the "cycle start" button, NC code is generated that is written and executed
in a program, i.e. the Generate Code (GC) function must be programmed in the
PRESS method for VSK8. This in turn means that an OUTPUT method must be
defined.NoteThe user does not have to press VSK8; it is triggered internally when the "cycle
start" key is pressed. The VSK8 should therefore not be labeled.

Example The directory CYCLES\SC\PROG\TEMPLATES DEU or CYCLES\SC\PROG\TEMPLATES ENG contains the archive file E_MS_O1.ARC which contains the sample measuring cycle E_MS_O1.SPF. The associated operator interface is configured in the E DR O1.COM file. The files E MS TXD.COM and E MS TXE.COM contain the German and English texts, and file EDGE Z.BMP contains a help display. Please see the README.TXT file for information on how to install the cycle. "Program" If you want to link user measuring cycles into the operating area program, prooperating area ceed as described in Section 10.2.1 "Transferring Cycles to the Machining Plan". A vertical softkey menu will then be created behind the entry softkey "Miscellaneous" \rightarrow "Zero point workpiece", via which you can call up your measuring cycles. Such a vertical softkey menu already exists behind the "Miscellaneous" \rightarrow "Measure tool" entry softkey.

10.3 ShopMill Open (PCU 50.3)

10.3 ShopMill Open (PCU 50.3)

For ShopMill Open, the HMI advanced operating areas "Parameter" (without tool management and work offsets), "Services", "Diagnostics" and "Commissioning" are located on the expanded horizontal softkey bar.

The extended horizontal softkey bar also includes the "Machine Service" and "Exit" softkeys for commissioning/diagnosis. These two softkeys are visible only when protection level 1 is selected.

In ShopMill Open you can also integrate Windows applications in the standard menu bar via softkeys. You must also install the Windows applications in the OEM directory and define them in the REGIE.INI file. This does not apply to Siemens additional products. You must install those in the ADD_ON directory. Refer to the ShopMill DVD for details.

References: User's Guide HMI Programming Package Part 1 (BN)

10.3.1 Basic menu bar

Jump into application	There are various methods by which you can integrate Windows applications into the basic menu bar:		
	Horizontal softkey 4, i.e. the Messages/Alarms operating area is replaced		
	User-assignable softkeys 7 and 8		
	User–assignable softkeys 1 to 8 in the extended horizontal softkey menu		
Return jump	There are 3 methods by which you can jump from the Windows application to another operating area:		
	 Using the "Menu Select" key on the operator panel, you can return to the basic menu bar and then select another operating area via a softkey. 		
	 You can configure the keys "Position", "Program", "Offset", "Program Man- ager", "Alarm" and "Custom" on the operator panel to branch directly into another operating area or sub-menu. 		
	 You can configure so-called "PLC keys" to branch into another operating area or sub-menu. 		
	References: /IHA/, Commissioning Base Software and HMI Advanced, Operator Interface Extension, SINUMERIK 840D sl/840D/840Di; /IHE/, Commissioning Base Software and HMI Embedded sl, Operator Interface Extension, SINUMERIK 840D sl; keyword "OP Hotkeys" and "PLC Keys"		

10.4 User status display

You can display machine states controlled via the PLC as custom user icons in the program status line.

M AUTO				
			/	
			Program	status line
Fig. 10-1 F	Program status	line		
You need to SHOW_CH The prograr together wit	activate the ANNEL_SPA n path of the h the progra	display of user i ANNING_STATE. currently selecte m name.	cons in th ed prograr	e display MD 9052 n is shown in the line below
16 display p	oositions are	defined in the pr	ogram sta	tus bar.
The custom	user icons r	nust meet the fol	llowing rea	quirements:
Colors:	Colors: 16–color mode			
• Size:	OP010/OP0 [.] OP012: 20 x OP015: 27 x	10C/OP010S: 16 20 pixels 26 pixel (height	6 x 16 pixe x width)	ls
File nam	ne: 8 charact	ers		
• Format:	BMP			
For ShopMi the director	ll on PCU 50 y F:\DH\CUS).3 (HMI Advance 5.DIR∖HLP.DIR.	ed), you sl	nould store user symbols in
For ShopMi following fol	ll on NCU (H ders:	IMI Embedded sl), you shc	uld place the icons in the
Table 10-5	Table 10-5 Directory for saving user-specific icons			
Storag	e folder	OP/res	olution	Size of icons (height x width)
			-	
ico640		UP 010 (640 x 48	80)	16 x 16 pixels

OP 012 (800 x 600)

OP 015 (1024 x 768)

ico800

ico1024

20 x 20 pixels

27 x 26 pixels

10.4 User status display

The user–specific icons are stored in folders (icoxxx) in the following three subdirectories:

- Manufacturer: \oem\sinumerik\hmi\ico/\coxxx
- User: \oem\sinumerik\hmi\ico\icoxxx

10.4.1 Configuring the user status display

The cross–channel status display is allocated and configured with user symbols in the HEADER.INI file.

ShopMill on PCU 50.3 The HEADER.INI file is located in the directory F:\HMI_ADV and must be copied either to the directory F:\OEM or F:\USER.

In the section UserIcons of the HEADER.INI file, enter the names of the user symbols and the signal for the control of the symbol selection.

Note

If you have already made these entries for HMI Advanced, you do not have to repeat the entries for ShopMill.

[User icons] UI_0= <Icons_00.bmp>, <Position> UI_0: Identifier Icons_00.bmp: Name of the user icon Position: Position for display (1 to 16) ... UI_31= <Icons_31.bmp>, <Position> USER_ICON_BASE = DBx.DBBy DBx.DBBy: Signal defined by user for controlling icon selection

You will find the HEADER.INI file in the F:\HMI_ADV directory and must copy them either to the F:\OEM or the F:\USER directory.

The user icons are addressed bit by bit, i.e. if bit **n** is set in signal DBx.DBBy, then the user icon with identifier UI_**n** is displayed. If the bit is reset by the PLC, the associated user icon is deleted in the program status display.

If several user symbols are assigned to the same position, the user symbol with the highest identifier number is displayed. You do not need to specify blank positions.

References: /IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sI/840D/840Di

ShopMill	
on NCU (HMI	
Embedded sl)	

The CompactFlash card contains the HEADER.INI file in the directory siemens\sinumerik\hmi\cfg\

Copy the HEADER.INI file to the directory oem\sinumerik\hmi\cfg. Open the file using the editor and assign the desired positions to the user symbols.

References: /IHE/, Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl

10.5 OP hotkeys, PLC keys

10.5 OP hotkeys, PLC keys

OP hotkeys	You can configure the keys "Position", "Program", "Offset", "Program Manager", "Alarm" and "Custom" on the operator panel to branch to an operating area of your choice.	
PLC keys	You can configure so-called "PLC keys" to branch to particular operating areas.	
Configuration	You can switch to the following operating areas with the OP hotkeys or PLC keys:	
	 ShopMill on NCU (HMI Embedded sl) From ShopMill to any operating area of ShopMill. 	
	 PCU 50.3 From ShopMill to any other operating area in ShopMill. From ShopMill to any other operating area in HMI Advanced and vice versa. 	
	Information about the configuration can be found in: References: /IHA/, Commissioning Base Software and HMI Advanced, Operator Interface Extension, SINUMERIK 840D sl/840D/840Di; /IHE/, Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl; keyword "OP Hotkeys" and "PLC Keys"	
Note		

The configuration of the "PLC Keys" in ShopMill is carried out in the file KEYS.INI, not via DB 19 interface. The file KEYS.INI must feature the following entry in the section [HMI_INI_FILES]: Task6 = shopmill.ini

11

Miscellaneous

11.1 Access protection via password and keyswitch

11.1.1 General

Access rights

Access to programs, data and functions is protected on a user basis via 8 hierarchical protection levels. These are divided into (see table 11-1):

- 4 password levels for Siemens, machine manufacturer and end user
- 4 key switch positions for end user

This provides a multilevel safety concept for controlling access rights.

Protection level	Туре	User	Access to (examples)	
0	Pass- word	Siemens	All functions, programs, and data	1
1	Pass- word	Machine manufacturer: Development	Defined functions, programs and data; for example: Enter options	
2	Pass– word	Machine manufacturer: Commissioning engineer	Defined functions, programs, and data; for example: Majority of machine data	
3	Pass– word	End user: Service	Assigned functions, programs, and data	
4	Key– switch Pos. 3	End user: Programmer machine setter	Lower than protection level 0 to 3; Defined by machine manufacturer or End user	
5	Key– switch Pos. 2	End user: qualified user, who does not program	Lower than protection level 0 to 3; Defined by end user	ecreasing
6	Key– switch Pos. 1	End user: Trained user, who does not program	Example: Program selection only, Tool wear input and input of zero offset	
7	Key– switch Pos. 0	End user: Semi–skilled operator	Example: No inputs or program selection possible, only machine control panel can be operated	¥

Table 11-1 Access protection

11.1 Access protection via password and keyswitch

Access protection system	•	Protection level 0 provides the greatest number of access rights, protection level 7 the least.
	•	If certain access rights are granted to a protection level, these protection rights automatically apply to any higher protection levels.
	•	Conversely, protection rights for a certain protection level can only be altered from a higher protection level.
	•	Access rights for protection levels 0 to 3 are permanently assigned by Siemens and cannot be altered (default).

- Access authorization is set through scanning of the current keyswitch position and a comparison of password entries. When a password is entered it overwrites the access rights of the keyswitch position.
- Options can be protected on each protection level. However, option data can only be entered in protection levels 0 and 1.
- Access rights for protection levels 4 to 7 are merely suggested settings and can be altered by the machine tool manufacturer or end user.

11.1 Access protection via password and keyswitch

11.1.2 Password

Setting the password	The passwords for the 4 available password levels with their respective access authorization can be entered in the DIAGNOSTICS operating area through selection of softkey SET PASSWORD. References: /BEMsl/, Operating Manual HMI Embedded sl or /BAD/, Operating Manual HMI Advanced
Resetting the password	Please note that a password remains valid until the access authorization is directly reset with the "Delete password" softkey. Access authorization is therefore not automatically deleted during POWER ON!
Possible characters	Up to 8 characters can be used in the password. We recommend that you re- strict yourself to the character set of the operator panel in selecting a password. Where a password consists of less than eight characters, the additional charac- ters are interpreted as blanks.
Default passwords	The following password levels are defined for protection levels 1 to 3: Protection level 1 SUNRISE Protection level 2 EVENING Protection level 3 CUSTOMER
	Note
	These passwords are entered as the defaults on system power–up in commissioning mode (NCK commissioning switch in position 1).
	The default passwords should be changed in order to guarantee reliable access protection.

11.1.3 Keyswitch settings

Keyswitch	The keyswitch has four positions to which protection levels 4 to 7 are assigned. The keyswitch is operated by 3 colored keys that can be removed from the lock in different positions (see Table 11-2). The key positions can be assigned to functions by the machine tool manufacturer or end user. Access to programs, data and functions can be set in the machine data for each user (see Section 11.1.4 "Machine Data for Protection Levels").
	The keyswitch positions are transferred to the PLC interface (interface signals "Keyswitch positions 0 to 3" (DB10, DBX56.4 to 7) and can be evaluated by the PLC user program. Keyswitch position 0 has access rights of the lowest priority and position 3 ac- cess rights of the highest priority. For example, all data that can be changed in keyswitch positions 0, 1 or 2 can also be changed in position 3.
Keyswitch applications	Access to certain data areas can be disabled with the keyswitch. Unintentional changes to geometry data (e.g. zero offsets) or activation of program control functions (e.g. selecting dry run feed rate) by the operator are therefore ruled out.

Switch setting	Retraction pos.	DB10, DBB56	Protection level
Position 0	_	Bit 4	7
Position 1	0 or 1 Black key	Bit 5	6
Position 2	0 or 1 or 2 Green key	Bit6	5
Position 3	0 or 1 or 2 or 3 Red key	Bit 7	4

Table 11-2 Keyswitch setting 0 to 3

Influencing the PLC user program

The PLC interface signals "Keyswitch positions 0 to 3" can be input either directly via the keyswitch on the machine control panel or from the PLC user program. Only one interface signal must be set. If several interface signals are set simultaneously, keyswitch position 3 is activated internally in the control.

11.1.4 Machine data for protection levels

Lockable data areas	The machine manufacturer or end user can set operator panel machine data to assign the appropriate protection levels for individual functions and data areas For a number of data types, it is possible to input different protection levels for read and write access authority. The machine data which can be "locked" by means of protection levels in Shop- Mill are listed below:		
	Operator panel machine data	Access to	
	9182 USER_CLASS_INCH_METRIC	Switch over between Inch/metric	
	9200 USER_CLASS_READ_TOA	Read tool offsets	
	9201 USER_CLASS_WRITE_TOA_GEO	Write tool geometry (including type and cutting edge)	
	9202 USER_CLASS_WRITE_TOA_WEAR	Write tool wear (without limit value)	
	9203 USER_CLASS_WRITE_FINE	Write fine tool wear and fine offsets	
	9206 USER_CLASS_WRITE_TOA_SUPVIS	Change limit values for tool monitoring	
	9210 USER_CLASS_WRITE_ZOA	Write rough offsets	
	9215 USER_CLASS_WRITE_SEA	Write setting data	
	9216 USER_CLASS_READ_PROGRAM (protection level must be \leq 6)	Read program	
	9217 USER_CLASS_WRITE_PROGRAM (protection level must be \leq 5)	Write/edit program	
	9218 USER_CLASS_SELECT_PROGRAM (protection level must be \leq 7)	Enable program selection	
	9222 USER_CLASS_WRITE_RPA	Write R parameters	
	9252 USER_CLASS_TM_SKTOOLLOAD	Enable loading of a tool	
	9253 USER_CLASS_TM_SKTOOLUNLOAE	Enable unloading of a tool	
	9254 USER_CLASS_TM_SKTOOLMOVE	Enable relocation of a tool	
	9258 USER_CLASS_TM_SKNCNEWTOOL	E Enable setting up of new cutting edges	
	9259 USER_CLASS_TM_SKNCDELTOOL	Enable deleting of a tool	
	9264 USER_CLASS_TM_SKTLNEWTOOL	Enable setting up of a new tool	
	9272 USER_CLASS_APPLICATION1 (for ShopMill on NCU (Emb.); protection leve	Release machine operating area I 1)	

11.1 Access protection via password and keyswitch

9272 USER_CLASS_APPLICATION2 Release parameter operating area (for ShopMill on NCU (Emb.); protection level 1)

9272 USER_CLASS_APPLICATION3 Release program operating area (for ShopMill on NCU (Emb.); protection level 1)

DefaultThese machine data are assigned protection level 7 by default during the stan-
dard commissioning procedure. All these data areas and functions can thus be
accessed and altered in keyswitch position 0.
The protection level defaults may need to be changed by the machine manufac-
turer or end user. Protection levels 0 to 3 can also be entered.

11.1.5 Operator interface for ShopMill on the NCU (HMI Embedded sl)

Default setting	The operating areas "Machine" and "Program" are by default hidden without manufacturer password. In the operating area "Parameter" only the set- ting data and the zero offsets can be seen without manufacture password.
	You can change the display by means of the following machine data
	9272 MM_USER_CLASS_APPLICATION [1] = 1 Machine area
	9272 MM_USER_CLASS_APPLICATION [3] = 1 Program area
	9273 MM_USER_CLASS_APP_PARAMETER [1] = 1 Tool list
	9273 MM_USER_CLASS_APP_PARAMETER [2] = 1 Tool wear
	9273 MM_USER_CLASS_APP_PARAMETER [3] = 1 OEM tool data
	9273 MM_USER_CLASS_APP_PARAMETER [4] = 1 Magazine
	9273 MM_USER_CLASS_APP_PARAMETER [6] = 1 R parameters
	9273 MM_USER_CLASS_APP_PARAMETER [10] = 1 User data
	9414 MM_TM_KIND_OF_TOOLMANAGEMENT = 1 Graphical representation of the tool management

11.2 ISO dialects

11.2 ISO dialects

You can also create and run ISO dialect programs under ShopMill. For more information on how to set up ISO dialects please refer to the following documentation:

References: /FBFA/, Function Manual on ISO Dialects for SINUMERIK

11.3 Spindle control

The ShopMill spindle control features special properties.

To configure the spindle, see

References: /FB1/, Function Manual on the Basic Machine: Spindles (S1)

End of program ShopMill distinguishes between M2/M30 (program end of a ShopMill program) and the M function (program end of a program created in the operating mode "Manual" or "MDA") defined in the MD 10714 \$MN_M_NO_FCT_EOP. MD 35040 \$MA_SPIND_ACTIVE_AFTER_RESET=2 causes the NCK to switch off the spindle for M2/M30, while it does not do so for the M function defined in MD 10714 \$MN_M_NO_FCT_EOP.

This functionality is required, among other things, to be able to start the spindle in manual operation (e.g. for scraping).

ShopMill uses the following M functions for end of program:

- M function from MD 10714 \$MN_M_NO_FCT_EOP: End of main program, spindle continues
- M2, M30: End of main program and return jump to beginning of program, spindle stops
- M17: End of subprogram and return jump to main program, spindle continues operating

Keys

If a manual spindle control must be implemented using the keys of the machine control panel, it can be accomplished using the following interface signals in the spindle data block: DB3x.DBX30.0 spindle stop DB3x.DBX30.1 spindle start CW rotation DB3x.DBX30.2 spindle start CCW rotation The spindle can be started and stopped if the channel status is reset (DB21.DBX35.7=1) or the channel status is "interrupted" (DB21.DBX35.6=1) and the program status is "interrupted" (DB21.DBX35.3=1).

Note

If the spindle must be stopped when the program is running, then the "Feed Stop/Spindle Stop" interface signal must be set in the user PLC (DB3x.DBX4.3).

11.4 Analog spindles

11.4 Analog spindles

ShopMill supports analog spindles with transmitter during thread tapping. Analog spindles must be used together with a compensation chuck. The machine axis index of the analog spindle must be entered in MD 9426 \$MM_MA_AX_DRIVELOAD_FROM_PLC1 or

MD 9427 \$MM_MA_AX_DRIVELOAD_FROM_PLC2.

The channel index of the spindle is located in the display machine data 9705 \$MM_CMM_INDEX_SPINDLE. If the respective machine axis index corresponds to one of the two machine data 9426 or 9427, ShopMill recognizes the spindle as an analog spindle. Whether the analog spindle features a transmitter can be determined by means of MD 30200 \$MA_NUM_ENCS (0 = no transmitter).

11.5 Automatically generated programs

ShopMill creates several programs automatically during operation.

Directory of part programs:

- **CMM_SINGLE** The program is created when a function is executed in "Manual" mode. The program is started via an asynchronous subroutine.
- **INPUT_DATA_MM INPUT_DATA_IN** The last parameter values entered in a screen are saved in these programs, depending on the unit of measurement. (INPUT_DATA_MM = values with the unit "mm"; INPUT_DATA_IN = values with the unit "Inch")

Directory commissioning:

REM_DATA.TRC Data which needs to remain stored when the machine is next switched off (e.g. the last selected program) is saved in this program.

11.6 Version display

11.6 Version display

The boot screen displays the ShopMill version.

The version data of the installed system software are output in a version display.

- For this purpose switch to the CNC ISO operator interface.
- Select the menu "Diagnostics" ---> "Service displays" ---> "Version".

More detailed information about the version display can be found in the following documentation: **References:** /IHA/, Commissioning Base Software and HMI Advanced,

/IHA/,	Commissioning Base Software and HMI Advanced,
	SINUMERIK 840D sl/840D/840Di;
/BAD/	Operating Manual HMI Advanced,
	SINUMERIK 840D sl/840D/840Di
BEMsl/	Operating Manual HMI Embedded sl,
	SINUMERIK 840D sl

11.7 Action log

You can log sequences of operations in ShopMill in the action log to obtain a history of events for later examination.

More detailed information about the action log can be found in: **References:** /IHE/, Commissioning Base Software and HMI–Embedded sl, SINUMERIK 840D sl/840D/840Di/810D

Please refer to the DOCUMENTATION\WINDOWLISTS directory on the Shop-Mill CD ROM for the assignment between ID numbers listed in the log and the corresponding ShopMill windows.

Note

If you use a PCU 50.3 with HMI Advanced and would like to log the ShopMill operating processes, you must configure the settings for the trip recorder directly in MD 9012 \$MM_ACTION_LOG_MODE. The log is stored in the F:\MMCOW32\TMP_AC_LOG.BIN file. No support for display or readout of this file is provided.

11.8 Mold making

ShopMill can also process mold making programs in addition to programs for the 2 1/2D machining. The mold making programs can be run not only on special mold–making machines, but also on conventional milling machines for the 2 1/2D machining.

The milling machines must, however, be optimized for processing mold-making programs to achieve the best possible velocity control.

11.8.1 Commissioning

You must perform the following steps to achieve the best possible velocity control:

- Setting NCK machine data
- Optimizing the drive
- Preconfiguring and, if necessary, adapting the cycle "High Speed Settings"

NCK machineThe NCK machine data are set in the "Machine data" mask (see chapter 7.1data"NCK machine data for ShopMill").

Note

Please note that the settings of some machine data values depend on the CNC control or are axis–specific; i.e. you must set these machine data values yourself.

Drive optimization	To adapt the drive for processing of mold making programs, you must optimize all controllers (current controller, speed controller, position controller), the jerk values and the feed forward control using machine–specific machine data, then check these settings based on a circular mold test and contour precision (cor- ners, radii).
	The optimization of controllers, jerk values and feed–forward control should be performed with active compressor function so that the compressor function can later be activated without additional re–optimization. The compressor function is already taken into account for the settings of the machine data in the "Machine data" mask. The compressor function is integrated in the option "Spline interpolation for 3–axis processing" (Order No. 6FC5 800–0AM16–0YB0) or "Spline interpolation for 5–axis processing" (Order No. 6FC5 800–0AM17–0YB0).
	The most important machine-specific machine data items are listed below. This

The most important machine–specific machine data items are listed below. This list is not necessarily complete.

Channel–specific MD/SD	
20600 \$MC_MAX_PATH_JERK	
20602 \$MC_CURV_EFFECT_ON_PATH_ACC	EL
20603 \$MC_CURV_EFFECT_ON_PATH_JER	K
Axis- and drive-specific MD/SD	
32200 \$MA_POSCTRL_GAIN[n]	
32300 \$MA_MAX_AX_ACCEL	
32431 \$MA_MAX_AX_JERK	
32432 \$MA_PATH_TRANS_JERK_LIM	
32433 \$MA_SOFT_ACCEL_FACTOR	
32434 \$MA_G00_ACCEL_FACTOR	
32435 \$MA_G00_JERK_FACTOR	
32810 \$MA_EQUIV_SPEEDCTRL_TIME[n]	
1004 \$MD_CTRL_CONFIG = 1000	
1407 \$MD_SPEEDCTRL_GAIN_1[n]	
1409 \$MD_SPEEDCTRL_INTEGRATOR_TIME	E_1[n]
1414 \$MD_SPEEDCTRL_REF_MODEL_FREC	۲ ۲
1500 \$MD_NUM_SPEED_FILTERS[n]	
1501 \$MD_SPEED_FILTER_TYPE[n]	
1503 \$MD_SPEED_FILTER_2_TIME[n]	

Table 11-3 Machine-specific machine data

"High Speed Settings" cycle

The optimal velocity control for machining is configured within the mold making program with the "High Speed Settings" cycle (CYCLE 832). The cycle is supplied with ShopMill.

You must preconfigure the cycle; in other words, you must set the parameters in advance depending on the machining type (roughing, rough finishing, finishing).

In addition, you can also undertake machine–specific adaptation of the "High Speed Settings" cycle in order to further optimize the processing of the mold making program. The "CYC_832T" cycle is available for this.

Note

The "High Speed Settings" cycle is merely used for setting the NCK functions for the velocity control, i.e. the optimization of drives described above is a requirement for it.

The "High Speed Settings" cycle can be called via the cycle support in the G–code editor of ShopMill. More detailed information about the cycles "High Speed Settings" and

"CYC_832T" can be found in: **References:** /PGZ/, Programming Manual on Cycles 11.8 Mold making

11.8.2 Data storage, data transfer

Data storage	For the optimization of the velocity control through the "High Speed Settings" cycle to become effective, it is recommended to divide mold–making programs into a technology program and a geometry program. The technology program contains fundamental settings such as zero offset, tool, feed, spindle speed, etc., while the geometry program exclusively contains geometry values of the freeform surface to be processed. Depending upon the application, the size of geometry programs can reach from 500 KB up to 100 MB. Programs of this size can no longer be processed directly in the NCK RAM; instead, they must be processed externally via EXTCALL.		
	 Save the geometry programs for the PCU 50.3 (HMI Advanced) either directly on the hard disk or on a network drive; 		
	 for ShopMill on NCU (HMI Embedded sl) either on the CompactFlash card or on a network drive. 		
Options	Saving to network drives requires the option "Managing network drives".		
	Saving to the user memory of the CompactFlash card requires the option "256 MB User Memory".		
	You can find further information in References: /IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840D/840Di; /IHE/, Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl		
Data transfer	A mold–making program can be copied directly to the control from a network drive or a USB drive.		
	 PCU 50.3 (HMI Advanced) The programs are copied to the hard disk. 		
	 ShopMill on NCU (HMI Embedded sl) The programs are copied to the user memory of the CompactFlash card. 		

Α

Abbreviations

ASUB	Asynchronous subroutine
BAG	Mode group
BUFF	Buffer
CNC	Computerized Numerical Control
СОМ	Communication Component of NC control that performs and coordinates communication.
DB	Data Block
DBB	Data Block Byte
DBD	Data Block Double Word
DBW	Data Block Word
DBX	Data Block Bit
FB	Function Block
GUD	Global User Data
HPU	Handheld Programming Unit
IBN	Commissioning
МСР	Machine Control Panel
MD	Machine data
MDA	Manual Data Automatic
MPF	Main program file: Part program (main program)
MPI	Multi-Port Interface
NC	Numerical Control The NC control comprises the components NCK, PLC, PCU and COM.

NCK	Numerical Control Kernel Component of NC control that executes programs and basically coordinates movements for the machine tool.
NCU	Numerical Control Unit: NC module
ОВ	Organization block in the PLC
ОР	Operator Panel
PC	Personal computer
PCU	Personal Computer Unit Component of NC control allowing communication between operator and machine.
PG	Programming device
PLC	Programmable Logic Control Component of NC control for processing machine tool control logic
RAM	Random Access Memory, i.e. program memory that can be read and written to
SD	Setting Data
SK	Softkey
SPF	Sub Program File
STL	Statement List
SW	Software
тм	Tool management
T No.	Tool number
ΤΟΑ	Tool Offset Active: Identifier for tool offsets
wz	Tool

Index

Α

Abbreviations, A-173 Acceptance report, 4-24 Access authorizations, 11-157 Access features, 11-158 Access protection, 11-157 Action log, 11-169 Additional functions, 9-125

В

Basic components, 1-11 Boot screen, 10-143

С

CLAMP.SPF, 9-139 Commissioning First, 4-18 NCK, 4-22 PLC, 4-21 Process, 4-18 Requirements, 4-17 ShopMill for PCU 50.3, 4-20 ShopMill on NCU (HMI Embedded sl), 4-20 Commissioning requirements, 4-17 Configuration file, 8-79 Examples, 8-79 Variables, 8-82 Coolant, 8-101 Custom screen, 10-144 Customer-specific operator interface, 10-143 Customized boot screen, 10-143 Cycles Linking to machining plan, 10-149 Transfer, 10-148 User-configured, 10-144 Cylinder surface transformation, 9-134 Axis configuration, 9-135 Slot side compensation, 9-134

B

D

DB71, 8-90 DB72, 8-91 Default passwords, 11-159 Direction of spindle rotation, 8-101 Display machine data, 7-40

Ε

End of program, 11-165 Example source files, 5-25

F

FB110, 8-87 FC 100, 8-87

Η

Hardware, 1-11 Basic components, 1-11 Operator components, 1-11 System structure, 1-11

I

Input signals, 6-31 Interface DB 19, 6-27 Interface signals, 6-27 for ShopMill, 5-26 Interpolator, 7-38 ISO dialects, 11-164

Κ

Keyswitch, 11-160

L

Lockable data areas, 11-161

Μ

Machine data, 7-37 Display, 7-40 NCK, 7-37 Manual tools, 8-100 Measuring cycles Display machine data, 9-126 Integrate, 10-151 Multiple clamping, 9-139

Ν

NCK machine data, 7-37 NCU load, 7-38 Network connection, 9-133

0

OP hotkeys, 10-156 Operator components, 1-11 Output signals, 6-33

Ρ

Password, 11-159 Reset, 11-159 Set, 11-159 PLC Former ShopMill interface, 6-31 Interface signals, 6-27 Program, 5-25 Program structure, 5-25 PLC keys, 10-156 Programs, generated automatically, 11-167 Protection levels, 11-161

R

Reserved functions, 3-15

S

Screen form, User-configured, 10-144

ShopMill for PCU 50.3, Commissioning, 4-20
ShopMill on NCU (HMI Embedded), Commissioning, 4-20
ShopMill Open, 10-152
Software commissioning

Data transfer, 4-17
ShopMill, 4-17

Spindle control, 11-165
Spindles, analog, 11-166
Start softkey, 10-144, 10-145
Status display, 10-153
Supplementary conditions, 2-13
Support, Measuring cycles, 9-141
Swivel heads, 9-138

Т

Texts, tool–specific, 8-103 to_mill.ini, 8-109 Tool change cycle, 8-97 Tool management, 8-67 Commissioning, 8-70 Configuring the operator interface, 8-107 Display machine data, 8-96 NCK commissioning, 8-71 NCK machine data, 8-71 Overview of functions, 8-67 PLC commissioning, 8-85 Tool–specific functions, 8-101 TRACYL, 9-134

U

User status display, 10-153

V

Version display, 11-168

W

Window ID, 11-169

То	Suggestions	
SIEMENS AG	Corrections	
A&D MC MS1 Postfach 3180	For Publication/Manual:	
D 01050 Erlangen	SINUMERIK 840D sl	
D-91050 Enangen Phone: +49 (0) 180 5050 – 222 [Hotline]	ShopMill	
Fax: +49 (0) 9131 98 – 63315 [Documentation] mailto:docu.motioncontrol@siemens.com	Manufacturer/Service Documentation	
From	Commissioning Manual	
Name	Order No.: 6FC5397–4AP10–2BA0 Edition: 01/2008	
Address of your company/department	Should you come across any printing errors when reading this publication, please notify us on this sheet. Suggestions for improvement are also welcome.	
Address		
Zip code: City:		
Phone: /		
Fax: /		

Suggestions and/or corrections

Overview



DOCONCD *) DOCONWEB

*) Recommended minimum scope of documentation