SIEMENS

SINUMERIK 840D sl

CNC: ShopTurn

Commissioning Manual

Valid for

Control SINUMERIK 840D sl/840DE sl

Software	Version
NCU system software for	
SINUMERIK 840D sl/840DE sl	1.5
with ShopTurn	7.5

01/2008 Edition

Hardware	1
Supplementary Conditions	2
Reserved Functions	3
Commissioning	4
PLC Program	5
Signal Description	6
Machine Data	7
Tool Management	8
Additional Functions	9
Customized User Interface	10
Miscellaneous	11
Abbreviations	Α
Index	В

SINUMERIK[®] documentation

Printing history

Brief details of this edition and previous editions are listed below.

The status of each edition is shown by the code in the "Remarks" column.

Status code in the "Remarks" column:

- A New documentation.
- **B**..... Unrevised reprint with new Order No.
- **C**.... Revised edition with new status.

Edition	Order No.	Remarks
03/2001	6FC5 297–6AD70–0BP0	Α
01/2002	6FC5 297–6AD70–0BP1	С
03/2004	6FC5 297–6AD70–0BP2	С
08/2005	6FC5 397–5AP10–0BA0	С
11/2006	6FC5 397–5AP10–1BA0	С
01/2008	6FC5 397–5AP10–2BA0	С

Trademarks

All names identified by [®] are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of liability We have checked that the contents of this document correspond to the hardware and software described. Since deviations cannot be precluded entirely, we cannot guarantee full agreement. The information given in this publication is reviewed at regular intervals and any corrections that might be necessary are made in the subsequent editions.

Further information is available in the Internet under: http://www.siemens.com/motioncontrol

This publication was produced with Interleaf V 7

© Siemens AG 2008

Other functions not described in this documentation might be executable in the control. However, no claim can be made regarding the availability of these functions when the equipment is first supplied or in the event of servicing.

We have checked that the contents of this document correspond to the hardware and software described. Nevertheless, differences might exist and therefore we cannot guarantee that they are completely identical. The data in this document is regularly checked and the necessary corrections are included in subsequent editions. Suggestions for improvement are also welcome.

Subject to change without prior notice.

Siemens-Aktiengesellschaft

Order No. 6FC5 397-5AP10-2BA0 Printed in the Federal Republic of Germany

Preface

SINUMERIK	The SINUMERIK documentation is organized in three parts:
documentation	General documentation
	User documentation
	Manufacturer/Service documentation
	A documentation overview with the available languages, updated monthly, can be found on the Internet under: http://www.siemens.com/motioncontrol Follow the menu items —> "Support" —> "Technical Documentation" —> "Documentation Overview".
	The Internet edition of the DOConCD, the DOCon Web, can be found under: http://www.automation.siemens.com/doconweb
	You can find information about training courses on offer and about the FAQs (frequently asked questions) on the Internet under: http://www.siemens.com/motioncontrol under "Support".
Target group	This documentation is intended for manufacturers of single–carriage turning machines using SINUMERIK 840D sl. It provides information needed for configuring and commissioning ShopTurn.
Standard scope	This document provides information about the control system design and the interfaces of the individual components. It also describes the commissioning procedure for ShopTurn with SINUMERIK 840D sl.
	For detailed information about individual functions, function assignment and perfor- mance data of individual components, please refer to the appropriate document for the subject concerned (e.g. manuals, description of functions etc.).
	User-oriented activities such as the creation of parts programs and control operating procedures are described in details in separate documents.
	Further descriptions of tasks to be performed by the machine tool manufacturer are also available for the standard SINUMERIK 840D sl. We may refer to them in this documentation if appropriate.
	This documentation only describes the functionality of the standard version. Additions or revisions made by the machine manufacturer are documented by the machine manufacturer.
	Other functions not described in this documentation might be executable in the control. However, no claim can be made regarding the availability of these functions when the equipment is first supplied or in the event of servicing.
	Further, for the sake of simplicity, this documentation does not contain all detailed information about all types of the product and cannot cover every conceivable case of installation, operation or maintenance.

Technical Support	If you have any technical questions, please contact our hotline:		
	Europe/Africa		
	Tel.: +49 (0) 180 Fax: +49 (0) 180 Internet: http://wv	5050–222 5050–223 vw.siemens.com/automation/support–request	
	America		
	Tel.: +1 (0) 423 2 Fax: +1 (0) 423 2 E–mail: mailto:tee	62 2522 262 2200 chsupport.sea@siemens.com	
	Asia/Pacific regio	n	
	Tel.: +86 (0) 1064 Fax: +86 (0) 1064 E–mail: mailto:te	4 719 990 4 747 474 chsupport.asia@siemens.com	
	Note		
	Country–specific Internet at: http://www.sieme	telephone numbers for technical support are provided on the ns.com/automation/service&support	
Questions aboutFor questionthisfax or e-mai		the documentation (suggestions, corrections), please send a he following address:	
documentation	Fax: +49 (0) 913 E–mail: mailto:do	1–98 63315 ocu.motioncontrol@siemens.com	
	You can find a fa	x template in the appendix to this document.	
SINUMERIK Internet address	http://www.siemens.com/sinumerik		
Search guides	The alarms of SI	NUMERIK 840D sl can be found in	
	References:	/DAsl/ Diagnostics Manual	
	For further useful	information on startup and troubleshooting, please refer to	
	References:	/FB/, D1, "Diagnostics Tools"	

Notes

The following symbols with special significance are used in the documentation:

Note

This symbol always appears in the document where further information is provided.

Safety information

This manual contains information which you must observe in order to ensure your own personal safety, as well as to avoid material damage. Notes relating to your safety are highlighted in the manual by means of a warning triangle; no warning triangle appears in conjunction with notes relating to material damage. Depending on the hazard level, warnings are indicated in a descending order as follows:



Danger

indicates that death or serious injury **will** result if proper precautions are not taken.



Warning

indicates that death or serious injury **may** result if proper precautions are not taken.



Caution

with a safety alert symbol, indicates that minor personal injury **may** result if proper precautions are not taken.

Caution

without a safety alert symbol, indicates that property damage **can** result if proper precautions are not taken.

Notice

indicates that an undesirable outcome or state **may** arise if the relevant notes are not observed.

Qualified
personnelThe device/system may only be set up and used in conjunction with this docu-
mentation. Only qualified personnel should be allowed to commission and
operate the device/system. For the purpose of the safety information in this
documentation, a "qualified person" is someone who is authorized to energize,
ground, and tag equipment, systems, and circuits in accordance with estab-
lished safety procedures.Intended usePlease note the following:



Warning

This equipment is only allowed to be used for the applications described in the catalog and in the technical description, and only in conjunction with non–Siemens equipment and components recommended by Siemens. Correct, reliable operation of the product required proper transport, storage, positioning and assembly, as well as careful operation and maintenance.

Unit of measurement

In this manual, the units of the parameters are always indicated as metric values. The equivalent imperial units are shown in the table below.

Metric	Inch
mm	in
mm/tooth	in/tooth
mm/min	in/min
mm/rev	in/rev
m/min	ft/min

Contents

1	Hardware 1				
2	Supplementary Conditions				
3	Reserved Functions				
4	Commissioning				
	4.1 Prerequisites				
	4.2 4.2.1 4.2.2 4.2.3 4.2.4 4.2.5 4.2.6 4.2.7	First commissioning Sequence Installation of ShopTurn on NCU (HMI Embedded sl) Installing ShopTurn on the PCU 50.3 PLC commissioning NCK commissioning Display machine data Acceptance report	4-18 4-20 4-20 4-21 4-22 4-24 4-24		
5	PLC Pro	gram	5-25		
	5.1	Structure of the PLC program	5-25		
	5.2	Sample source files	5-25		
	5.3	' Standard interface signals for/from ShopTurn	5-27		
6	Signal D	escription	6-29		
	6.1	· HMI interface DB19	6-29		
	6.2	HMI interface DB21	6-33		
	6.3 6.3.1 6.3.2	Overview of former ShopTurn interface Signals to ShopTurn (input signals) Signals from ShopTurn (output signals)	6-34 6-34 6-36		
7	Machine	Data	7-39		
	7.1	NCK machine data for ShopTurn	7-39		
	7.2 7.2.1 7.2.2	Display machine data for ShopTurn Overview of display machine data Description of display machine data	7-41 7-41 7-45		
8	Tool Mar	nagement	8-75		
	8.1	Overview of functions	8-75		
	8.2	Commissioning sequence	8-77		
	8.3 8.3.1 8.3.2 8.3.3	Commissioning in NCK Enter the NCK machine data Description of NCK machine data Creating and loading the configuration file	8-78 8-78 8-80 8-86		

	8.4 8.4.1 8.4.2	Commissioning in the PLC Example for FC 100 and FB 110 Signal description	8-92 8-93 8-95
	8.5	Display machine data	8-103
	8.6	Enable spindle and coolant	8-104
	8.7	Moving the turret manually	8-105
	8.8 8.8.1 8.8.2 8.8.3 8.8.4 8.8.5 8.8.6	Configuring the operator interface Integrating additional list Configuring lists Creating the configuration file Adapting individual parameters Defining texts for the magazine locations on the intermediate buffer Designating a load magazine in the tool list sorted according to magazines	8-108 8-108 8-109 8-110 8-115 8-117 8-118
	8.8.7	Define texts	8-118
	8.9	Reading in tool data	8-121
9	Addition	al Functions	9-125
	9.1 9.1.1 9.1.2	Measuring cycle Brief description Display machine data for measuring cycle	9-125 9-125 9-126
	9.2	Network link	9-128
	9.3 9.3.1 9.3.2 9.3.3 9.3.4	Cylinder surface transformation, end face machining General Example: X axis and Z axis, main spindle and tool spindle Example: X axis and Z axis, main spindle and tool spindle, Y axis Example: X axis and Z axis, main spindle, tool spindle and counter–spindle	9-129 9-129 9-130 9-132 9-132
	9.3.5	Example: X axis and Z axis, main spindle, tool spindle, and counter-spindle, Y axis	9-136
	9.4	Inclined Y axis	9-138
	9.5	Measuring cycle support in the G code editor	9-141
	9.6	Counter-spindle	9-143
	9.7	Turning machines with a B axis	9-146
	9.8	Working with two tool carriers	9-147
10	Customiz	zed User Interface	10-151
	10.1	Configuring the custom boot screen	10-151
	10.2 10.2.1 10.2.2 10.2.3	Configuring the custom screen Transferring cycles to the machining plan Linking cycles into the machining plan Integrating measuring cycles	10-152 10-156 10-157 10-158
	10.3 10.3.1	ShopTurn Open (PCU 50.3)	10-159 10-159
	10.4	Operator interface for ShopTurn on the NCU (HMI Embedded sl) .	10-160

	10.5 10.5.1	User status display	10-161 10-162
	10.6	OP hotkeys, PLC keys	10-164
11	Miscella	ineous	11-165
	11.1	Machine data for protection levels	11-165
	11.2	Machine manufacturer cycle	11-167
	11.3	Spindle control	11-168
	11.4	ISO dialects	11-171
	11.5	Automatically generated programs	11-172
	11.6	Manual machine	11-173
	11.7	Action log	11-175
	11.8	Version display	11-176
Α	Abbrevi	ations	A-177
в	Index .		Index-179

Space for your notes

Hardware

1

System structure	The hardware configuration for ShopTurn is as standard for SINUMERIK 840D sl	
	References:	/IDsl/, Commissioning CNC: NCK, PLC, drive, SINUMERIK 840D sl;
		/GDsl/, Device Manual NCU, SINUMERIK 840D sl

Table 1-1 Basic components

Basic components	Order No.	Comment
TCU	6FC5312-0DA00-0AA0	
NCU 710.1	6FC5371-0AA10-0AA0	CNC: 3 MB; PLC: 128 KB
NCU 710.2	6FC5371-0AA10-0AA1	CNC: 3 MB; PLC: 512 KB
NCU 720.1	6FC5372-0AA00-0AA0	CNC: 3 MB; PLC: 128 KB
NCU 720.2	6FC5372-0AA00-0AA1	CNC: 3 MB; PLC: 512 KB
NCU 720.2PN	6FC5372-0AA01-0AA1	CNC: 3 MB; PLC: 512 KB
NCU 730.1	6FC5373-0AA00-0AA0	CNC: 3 MB; PLC: 128 KB
NCU 730.2	6FC5374-0AA01-0AA0	CNC: 3 MB; PLC: 128 KB
NCU 730.2 PN	6FC5373-0AA01-0AA1	CNC: 3 MB; PLC: 512 KB

Table 1-2 Operator components

Operator Components	Order No.	Comment
OP010 operator panel	6FC5203-0AF00-0AA0	
OP010C operator panel	6FC5203-0AF01-0AA0	
OP010S operator panel	6FC5203-0AF04-0AA0	
OP012 operator panel	6FC5203-0AF02-0AA0	
OP015 operator panel	6FC5203-0AF03-0AA0	
OP015A operator panel	6FC5203-0AF05-0AB0	
OP015AT operator panel	6FC5203-0AF05-1AB0	
TP015A operator panel	6FC5203-0AF08-0AB0	
TP015AT operator panel	6FC5203-0AF08-1AB0	
PROFIBUS DP direct key module	6FC5247-0AF11-0AA0	
Direct key module mounting kit	6FC5247-0AF30-0AA0	
	1	

Table 1-2Operator components

PCU 50.3 – C	6FC5210-0DF31-2AA0	1.5 GHz, 512 MB, Windows XP
PCU 50.3 – P	6FC5210-0DF33-2AA0	2.0 GHz, 1024 MB, Windows XP

Table 1-2Operator components

Operator Components	Order No.	Comment
MCP 310	6FC5203-0AF23-1AA0	
MCP 310 IE	6FC5303-0AF23-1AA0	
MCP 483	6FC5203-0AF22-1AA2	
MCP 483C IE	6FC5303-0AF22-0AA0	
MCP 483 IE	6FC5303-0AF22-1AA0	
CNC full keyboard KB 310C	6FC5203-0AF21-0AA0	
CNC Full Keyboard KB 483C	6FC5203-0AF20-0AA1	
PC keyboard, standard	6FC5203-0AC01-3AA0	

2

Supplementary Conditions

When using ShopTurn, please observe the following supplementary conditions:

- ShopTurn only runs in channel 1, mode group 1.
- ShopTurn has been designed for use with universal turning machines with four axes (X, Z, Y, and auxiliary axis for counterspindle) and 3 spindles (main, tool, and counterspindle).
- ShopTurn only runs with tool management.
- If you wish to use rotating tools, you need the software option "cylinder surface transformation" (Tracyl) and "end face machining" (Transmit). Order No. 6FC5 800–0AM27–0YB0
- If you wish to use a counterspindle on your machine, you need the software options "travel to fixed stop" (Order No. 6FC5 800–0AM01–0YB0) and "synchronous spindle" (Order No. 6FC5 800–0AM14–0YB0).
- With ShopTurn Open, you must not change the position of the following softkeys in the basic menu bar; i.e. in the REGIE.INI file these functions must always have been assigned a specific task.
 Task 0 (horizontal softkey 1): Operating area – Machine
 Task 1 (horizontal softkey 2): Operating area – Program manager
 Task 2 (horizontal softkey 3): Operating area – Program
 Task 4 (horizontal softkey 5): Operating area – Tools/Zero offsets
- With ShopTurn it is possible via TCU to use several operator panels.
- The HMI and Windows screen savers must not be used together.
 References: /IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840Di/840D;
 /IHE/ Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl

Space for your notes

3

Reserved Functions

The following functions are utilized by ShopTurn and must not be assigned for other purposes.

 PROG_EVENT
 The system cycle PROG_EVENT.SPF is used by the standard cycles and by ShopTurn.

 If you wish to use the cycle PROG_EVENT.SPF for user functions as well, it is necessary to implement these user functions in the cycles CYCPE_US.SPF and CYCPE1US.SPF. Save these cycles in the directory for user cycles or manufacturer cycles.

Space for your notes

4

Commissioning

4.1 Prerequisites

Data transfer

For data transfer you require:

Hardware

- Programming device with Windows XP or a PC with Ethernet
- Memory stick, if required (Order No.: 6ES7 648-0DC20-0AA0)
- Software
 - SIMATIC Step7, version 5.3 SP2 or higher (for Order No., see SIMATIC catalog)

ShopTurn software

• ShopTurn on NCU (HMI Embedded sl)

With the ShopTurn variant on NCU (HMI Embedded sl), the software is already pre–installed on the CompactFlash Card:

- Drive software (Sinamics)
- PLC software
- NCK software
- ShopTurn
- Cycles

The software is provided in 6 languages (German, English, French, Italian, Spanish, and Chinese).

• ShopTurn for PCU 50.3

The necessary software is located on the "NCU–SysSW and ShopTurn–HMI" CD–ROM. The software is provided in 6 languages (German, English, French, Italian, Spanish, and Chinese).

The procedure for installing the software on PCU and NCK/PLC is described in the following sections.

Note

The NCU software components are located in file SIEMENSD.RTF (German)/SIEMENSE.RTF (English). A compatibility list can be found in file 840D_sl_compatibility_list.xls.

4.2.1 Sequence

Before you begin commissioning, please read the general conditions and reserved functions.

Proceed as follows when commissioning:

- For installation of ShopTurn on PCU from CD (only for ShopTurn on PCU 50.3).
 For ShopTurn on NCU (HMI Embedded sl) the ShopTurn software is already preinstalled.
- PLC commissioning
- NCK commissioning
- Installing additional functions (optional)
- Adapting display machine data
- Customizing the operator interface (optional)
- Testing using the acceptance certificate

You can commission tool management either together with NCK and PLC commissioning or afterwards. If tool management is already set up on the machine, you only need to adapt the display machine data for tool management; (see Section 8.2 "Commissioning sequence").

A detailed description of commissioning is provided in the following documents:

References: /IDsl/, Commissioning CNC: NCK, PLC, drive, SINUMERIK 840D sl; /IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840Di/840D; /IHE/, Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl



Fig. 4-1 General sequence of first commissioning

General sequence of first commissioning (1) The first step when commissioning is to configure the control system, i.e. to set up communication between all involved components. PLC, drive and NCK are commissioned **References:** /IDsl/, Commissioning CNC: NCK, PLC, drive, SINUMERIK 840D sl

(2) In a second step, the individual functions are commissioned in several runs. The commissioning sequence for these functions is described in the following sections.

4.2.2 Installation of ShopTurn on NCU (HMI Embedded sl)

For the purposes of operating ShopTurn on NCU (HMI Embedded sl) the whole software is pre-installed on the CompactFlash Card. Just a few adaptations of the NCK and PLC are needed.

Note

ShopTurn uses the alarm texts and PLC messages of the CNC ISO user interface. You can find detailed information on this subject as well as the the software installation in the following document:

References: /IHE/, Commissioning Base Software and HMI Embedded sI, SINUMERIK 840D sI

4.2.3 Installing ShopTurn on the PCU 50.3

The HMI Advanced software must be installed on the PCU 50.3 before you install ShopTurn.

Following installation, the internal HMI Embedded on the NCU must be deactivated. Deactivation and activation can be carried out with the aid of the WinSCP service program. Start WinSCP and select "Open Terminal" under Commands. The "sc disable hmi" action deactivates the internal HMI Embedded. The "sc enable hmi" action activates the internal HMI Embedded.

References: /IDsl/, Commissioning Manual CNC: NCK, PLC, drive, SINUMERIK 840D sl;

/IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840Di/840D

You can install ShopTurn on the PCU 50.3 in one of three different ways:

- Installation via a network link
- Installation from a data carrier (e.g. DVD)
- Installation via USB interface

Note

ShopTurn uses the alarm texts and PLC messages of the CNC ISO user interface. You can find detailed information on this subject as well as the the software installation in the following document:

References: /IHE/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840Di/840D

4.2.4 PLC commissioning

To commission the PLC, you must first create and then load a PLC user project.

To commission the PLC, proceed as follows:



Fig. 4-2 PLC commissioning

4.2.5 NCK commissioning

NCK commissioning comprises the following points:

- Set up axes and spindle(s)
- Load ShopTurn machine data, definitions, and cycles
- Set up tool management

You only need to set up the axes and spindles if you have not yet done so on the machine. When setting up the axes and spindles, please observe the general conditions; (see Section 2 "General conditions").

Similarly, you only need to set up tool management in the NCK if this does not yet exist.

Note:

Example files are located in the directories CYCLES\SC\PROG\TEMPLATES_DEU and CYCLES\SC\PROG\ TEMPLATES_ENG.

SINUMERIK 840D sl



Fig. 4-3 NCK SINUMERIK 840D sl commissioning



Fig. 4-4 NCK SINUMERIK 840D sl commissioning



Fig. 4-5 NCK SINUMERIK 840D sl commissioning

4.2.6 Display machine data

Once you have completed installation of ShopTurn on the PCU and commissioning of NCK and PLC, you must adapt the display machine data. The display machine data is listed in Section 7.2 "Display machine data for ShopTurn".

4.2.7 Acceptance report

The acceptance report can be used to test the installed ShopTurn functions once ShopTurn commissioning has been completed. The acceptance report is included on the ShopTurn CD–ROM.

PLC Program

5.1 Structure of the PLC program

In the OBs 1, 40, and 100, the tool management and basic PLC program (FB 1, FC 2, ...) must be activated.

For a description of the function blocks and the basic PLC program please refer to:

References: /FB1/, Description of Functions, basic machine, P3 sl, "Basic PLC program"

5.2 Sample source files

ShopTurn includes a variety of source files for sample blocks. You can adapt and compile these source files or you can use your own blocks.

Table 5-1	Sample source files

Source	Mnemonics	Note	Block	Comment
TM_REV_GR. AWL	German	The indicated block numbers are pro- grammed in absolute terms.	FC 100	Sample block for config- uring tool management The block is called in OB100.
			FB 110 DB 110	Sample block for data transfer of tool manage- ment. The block is called in OB1. Instance data block for FB 110
TM_REV_UK. AWL	English	like TM_REV_G	R.AWL	·

5.2 Sample source files

		-		
Source	Mnemonics	Note	Block	Comment
TM_REV_M_GR. AWL	German	The block de- signation is symbolic. For example, the following block numbers can be as- signed.		
		TM_REV_M	FC55, Data type FC55	Sample block for track- ing the turret position.
		DB_TM_REV_ M	DB 55 Data type DB55	Data block
		FB4_INST_DB	DB56 Data type FB4	Instance data block for FB4
TM_REV_M_UK. AWL	English	like TM_REV_M	_GR.AWL	·

Table 5-1Sample source files

The sample blocks are located in the toolbox under \ShopMill_Turn .

5.3 Standard interface signals for/from ShopTurn

The following table lists the standard interface signals that are affected by the ShopTurn interface (DB19).

Byte	Designation
DB19	Signals from operator panel (HMI——>PLC)
DBB21	Active MMC operating area see section 6.1 "HMI interface DB19"
DBX20 Bit6	Simulation active see section 6.1 "HMI interface DB19"
DBW24	Current screen number in ShopTurn see section 6.1 "HMI interface DB19"
DB21	Signals to NCK channel (PLC—>NCK)
DBX7.5	Deactivate global start lock see section 6.2 "HMI interface DB21"

Table 5-2	Standard interface	signals for/fron	n ShopTurn
	olunduru mitoridoo	olghalo iol/liol	n onop i uni

Note

• Feed disable must not be activated in the PLC user program while the spindle is stationary, because with "Hole thread cutting with positioning on circle" the axes are positioned on the next hole as per the federate even with a stationary spindle.

Space for your notes

6

Signal Description

DB19	E_SimActiv		
DBX20.6	Simulation	active	
Data block	Signal(s) fro	m ShopTurn	
Edge evaluation: No		Signal(s) updated: Cyclically	Signal(s) valid from software version: ShopTurn 6.1
Significance of signal	0: Exit simul 1: Start simu	ation Ilation	

DB19	E_AcitivWA		
DBB21	Active MMC	Coperating area	
Data block	Signal(s) fro	m ShopTurn	
Edge evaluation: No		Signal(s) updated: Cyclically	Signal(s) valid from software version: ShopTurn 7.1
Significance of signal	OPEN (HMI SK number Classic (HM 201: ST mac 202: ST dire 203: ST pro 204: ST alar 205: ST tool	Advanced) (as predefined in the control (Task+1)) I Embedded) chine actory gram ms/messages	

6 Signal Description

DB19	Mask number
DBW24	Current screen number in ShopTurn
Data block	Signal(s) from ShopTurn
Edge evaluation: No	Signal(s) updated: Cyclically Signal(s) valid from software version:
	ShopTurn 7.5
Significance of signal	The signal outputs the screen number of the current ShopTurn screen.
	The following screen numbers can be output:
	No. ShopTurn screen
	Machine Manual mode
	(without "Manual machine" option)
	21 Set 70*
	30 Workpiece zero
	31 Workpiece zero – User screenform*
	34 Workpiece zero – User screenform*
	35 Workpiece zero – User screenform*
	36 Workpiece zero – User screenform*
	37 Workpiece zero – User screenform*
	38 Workpiece zero – User screenform*
	40 Workpiece zero – User screenform*
	5 Workpiece zero – Measure edge Z
	50 Measure tool
	51 Measure tool – Manual Z/User screeniorm*
	52 Measure tool – Manitud – 2/05er screenform*
	50 Measure tool – User screenform*
	55 Measure tool – User screenform*
	56 Measure tool – Calibration probe*/User screenform*
	57 Measure tool – User screenform*
	58 Measure tool – Autom. – Z*
	59 Measure tool – Autom. – X*
	4 Position
	18 Face milling*
	80 Stock removal*
	81 Cycle start screen (stock removal/facemilling) – Accept with OK*
	90 Tallstock user screenform
	1 ShonTurn softings
	1 Shop full settings
	Machine Manual mode
	(with "Manual machine" option):
	19 Basic screen
	50 Measure tool
	51 Measure tool – Manual– X/User screenform*
	52 Measure tool – Manual – Z/User screenform*
	53 Measure tool – Magnifying glass*/User screenform*
	54 Measure tool – User screenform*
	55 Measure tool – User screenform*
	50 Measure tool – Calibration probe^/User screenform*
	57 Measure tool Autom 7*
	50 Measure tool – Autom – X*
	21 Set ZO*
	1300 Straight line
	, v

DB19	Mask number
DBW24	Current screen number in ShopTurn
Data block	Signal(s) from ShopTurn
Significance of signal	1400 Drilling
5	1410 Drilling – Center
	1420 Drilling – Thread center
	1433 Drilling – Centering*
	1434 Drilling – Drilling*
	1435 Drilling – Reaming*
	1440 Drilling – Deep–hole drilling*
	1453 Drilling – Tapping*
	1454 Drilling– Thread milling*
	1500 Turning
	1513 Turning – Stock removal 1
	1514 Turning – Stock removal 2
	1513 Turning – Stock Ternoval 3
	1524 Turning Groove 2
	1525 Turning = Groove 3
	1533 Turning – Undercut form F
	1534 Turning – Undercut form F
	1535 Turning – Undercut thread DIN
	1536 Turning – Undercut thread
	1543 Turning – Thread longitudinal
	1544 Turning – Thread taper
	1545 Turning – Thread face
	1550 Turning – Cut–off
	1600 Milling*
	1613 Milling – Rectangular pocket*
	1614 Milling – Circular pocket*
	1623 Milling – Rectangular spigot*
	1624 Milling – Circular spigot^
	1634 Milling — Circumforontial groove*
	1640 Milling Multi edge*
	1670 Milling – Engraving*
	1730 Simulation – 3–window view*
	1740 Simulation – Side view*
	1750 Simulation – Front view*
	1760 Simulation – Volume model*
	1731 Simultaneous recording – 3-window view*
	1741 Simultaneous recording – Side view*
	1751 Simultaneous recording – Front view*
	1761 Simultaneous recording – Volume model*
	1777 Simulation settings
	81 Cycle start screen (drilling/turning/milling) – Accept with UK*
	90 Tailstock user screenform ²
	1 ShonTurn settings
	i onopium seungs
	MDA mode:
	20 MDA
	Machine Auto mode:
	200 Basic screen
	210 Program control
	220 Block search
	230 User screenform*
	241 Simultaneous recording – Settings*
	242 Simultaneous recording – 3–window view*
	243 Simultaneous recording – Side View^
	244 Simultaneous recording - Front view" 245 Simultaneous recording Volume model*
	240 Simulateous recording – volume model" 250 Extended softkey menu Setting
	200 Extended Solikey Hend – Setting

6 Signal Description

01/2008

DB10	Mask numb	or		
DBN94	Current screen number in ShonTurn			
Data black	Signal(s) from ShonTurn			
Edge evoluction: No	Signal(s) in	Simple) undeted. Cu		Cignal(a) valid from coffuerro version
Euge evaluation. No		Signal(s) upualeu. Cy	Silcally	Signal(s) valid from software version. ShonTurn 7.5
Significance of signal	Onerating a	rea program manager:		chop full 7.0
olgrinioarioo or olgriai	First softkey	/ menu		
	300 Direct	ory NC		
	310 Part p	rogram*		
	320 Subp	ogram*		
	330 User	directory 1*		
	340 User (directory 2*		
	350 User (directory 3*		
	360 User (360 User directory 4*		
	Second sof	tkey menu		
	380 Stand	ard cycles*		
	381 Manu	facturer cycles*		
	382 User	cycles*		
	383 User (directory 5*		
	384 User (directory 6*		
	385 User (directory 7*		
	386 User (directory 8*		
	Operating a	rea program:		
	400 Mach	ning plan/G code editor		
	411 Simul	ation – Settings*		
	412 Simul	ation – 3–window view*		
	413 Simul	ation – Side view*		
	414 Simul	ation – Front view*		
	415 Simul	ation – Volume model*		
	Operating a	rea messages/alarms:		
	500 Mess	ages		
	510 User s	screenform*		
	520 User :	screenform*		
	Operating a	rea tools/zero offsets:		
	600 Tool li	st		
	610 Tool w	/ear		
	620 User t	ool list*		
	630 Maga	zine		
	640 Zero (offset		
	650 R para	ameters		
	660 User :	screenform*		
	670 Spind	les		
	600 Mach	uala no doto		
	USU WACH			
	Run screen			
	910 Run s	creen in operating area N	Achine Manual	*
	920 Run s	creen in operating area N	/lachine MDA*	
	930 Run s	creen in operating area N	/lachine Auto*	
	* = If screer	n is available		

6.2

6.2 HMI interface DB21

In ShopTurn a program can only be started by default in the machine area. Starting a program in any of the other areas (e.g. tools) is prevented by a global start lock.

Note

You can specify, via MD 9719, bit 9, that it should be possible to start a program from all masks.

In automated sequences, e.g. a start from the PLC as used on a machine with a pallet change system, this global start lock can be deactivated by means of interface signal DB21.DBX7.5.

This prevents a program start of this nature being locked by the operator interface.

DB21	suppressStartLock		
DBX7.5	Deactivate global start lock		
Data block	PLC> NCK		
Edge evaluation: No		Signal(s) updated: Cyclically	Signal(s) valid from software version: ShopTurn 7.1
Significance of signal	0: Do not cancel global start lock 1: Deactivate global start lock		

So that an alarm is output in the event of a start being attempted while the global start lock is activated, bit 6 in the machine data 16956 \$MN_ENABLE_ALARM_MASK must be set. 6.3 Overview of former ShopTurn interface

6.3 Overview of former ShopTurn interface

With the new software version of ShopTurn the ShopTurn PLC program and the associated ShopTurn interface DB 82 are no longer used. The following tables show where you can find the old DB82 interface signals.

6.3.1 Signals to ShopTurn (input signals)

Address DB82 DBX	Name Comments	Spares
0.0 - 0.7	CMM_IN.transfer_base_sig Transfer mode for MTTS signal	Omitted because ShopTurn PLC no longer exists
2.0	CMM_IN.base_sig.main_mode_mill.manual ShopTurn operating mode – manual	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX0.2 JOG.
2.1	CMM_IN.base_sig.main_mode_mill.automatic ShopTurn operating mode – automatic	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX0.0 AUTO.
4.0	CMM_IN.base_sig.reset Reset for ShopTurn	Transfer is via FC19/FC24 to the standard inter- face DB21.DBX7.7 Reset.
4.1	CMM_IN.base_sig.nc_cycle_start Cycle start	Transfer is via FC19/FC24 to the standard inter- face DB21.DBX7.1 NC–Start.
4.2	CMM_IN.base_sig.nc_cycle_stop Cycle stop	Transfer is via FC19/FC24 to the standard inter- face DB21.DBX7.3 NC–Stop.
6.0	CMM_IN.sub_mode_mill.tool Operating area – tool	Omitted. Use the appropriate key on the operator panel; (see section 10.6 OP hotkeys, PLC keys).
6.1	CMM_IN.sub_mode_mill.directory Operating area – Directory	Omitted. Use the appropriate key on the operator panel; (see section 10.6 OP hotkeys, PLC keys).
6.2	CMM_IN.sub_mode_mill.messages Operating area – Alarms/messages	Omitted. Use the appropriate key on the operator panel; (see section 10.6 OP hotkeys, PLC keys).
6.3	CMM_IN.sub_mode_mill.program Operating area – program	Omitted. Use the appropriate key on the operator panel; (see section 10.6 OP hotkeys, PLC keys).
6.4	CMM_IN.sub_mode_mill.oem1 Operating area – OEM1	n.a.
6.5	CMM_IN.sub_mode_mill.oem2 Operating area – OEM2	n.a.
6.6	CMM_IN.sub_mode_mill.customer Operating area – Customer	n.a.
6.7	CMM_IN.sub_mode_mill.mda Operating area – MDA	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX0.1 MDA.
9.5	CMM_IN.program_extern_selected Program is selected in the PLC.	This is no longer required because the logic in the ShopTurn interface has been modified.

 Table 6-1
 Signals to ShopTurn (input signals)

6.3 Overview of former ShopTurn interface

Address DB82	Name Comments	Spares
DBX		
9.6	CMM_IN.disable_cnc_standard Lock the switchover to CNC–ISO operator interface	ShopTurn Open (PCU 50.3): not available, ShopTurn on NCU (HMI Embedded) Assign protective levels to lock the remaining op- erator areas
9.7	CMM_IN.cmm_activ_in_cnc_mode ShopTurn PLC active during CNC-ISO oper- ation	Omitted because ShopTurn PLC no longer exists.
10.0	CMM_IN.program_test_request Select function for program test	MMC -> PLC DB21.DBX25.7 PLC -> NCK DB21.DBX1.7 Connect as in the PLC user program.
10.1	CMM_IN.dry_run_request Select the function DryRun	MMC -> PLC DB21.DBX24.6 PLC -> NCK DB21.DBX0.6 Connect as in the PLC user program.
10.2	CMM_IN.m01_request Select function M01	MMC -> PLC DB21.DBX24.5 PLC -> NCK DB21.DBX0.5 Connect as in the PLC user program.
10.3	CMM_IN.skip_block_request Select function for skipping record	MMC -> PLC DB21.DBX26.0 ff PLC -> NCK DB21.DBX2.0 ff Connect as in the PLC user program
10.4	CMM_IN.boot_standard System boot in CNC-ISO operator interface	ShopTurn Open (PCU 50.3): Modify Power on task in the schedule, or remove the ShopTurn operating area from the schedule, or assign a protective level to the ShopTurn oper- ating area in the schedule. ShopTurn on NCU (HMI Embedded): Assign a protective level to the ShopTurn oper- ating area.
10.5	CMM_IN.nck_auto_req Prepare record search PLC	Omitted because operating areas Jog, Automatic, and MDA are now identical with the NCK oper- ating modes
10.7	CMM_IN.ignore_nck_alarm Ignore NCK alarm in the event of cycle start	Omitted because the NCK start is no longer ma- nipulated by ShopTurn
11.1	CMM_IN.get_tool_data Update tools data	Omitted because the data is automatically updated with the NCK function "Extended tool counter"
11.2	CMM_IN.c_axis_feed_drive Separate feed drive as C axis drive	DB31ff.DBX56.0
11.3	CMM_IN.select_spindle_readout_0 Select spindle speed display, bit 0	DB31ff.DBX56.1 All bits 0: The main spindle rule applies More than 1 bit active: The following sequence applies: 1. Main spindle 2. Rotating tool spindle 3. Counterspindle

Table 6-1 Signals to ShopTurn (input signals)

6.3 Overview of former ShopTurn interface

Address DB82 DBX	Name Comments	Spares
11.4	CMM_IN.select_spindle_readout_1 Select spindle speed display, bit 1	DB31ff.DBX56.1 All bits 0: The main spindle rule applies More than 1 bit active: The following sequence applies: 1. Main spindle 2. Rotating tool spindle 3. Counterspindle
11.5	CMM_IN.drf_request Select the function DRF	MMC -> PLC DB21.DBX24.3 PLC -> NCK DB21.DBX0.3 Connect as in the PLC user program.

Table 6-1 Signals to ShopTurn (input signals)

6.3.2 Signals from ShopTurn (output signals)

Address DB82 DBX	Name Comments	Spares
30.0	CMM_OUT.base_sig.main_mode_mill.manual ShopTurn operating mode - manual	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX6.2 JOG
30.1	CMM_OUT.base_sig.main_mode_mill.auto matic ShopTurn operating mode – automatic	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX6.0 AUTO
32.0	CMM_OUT.base_sig.reset Reset performed	Can be simulated with the interface signal DB21.DBX35.7 channel status reset
32.1	CMM_OUT.base_sig.nc_cycle_activ Cycle active	Transfer is via FC19/FC24 to the standard inter- face DB21.DBX
32.2	CMM_OUT.base_sig.nc_cycle_activ Cycle interrupted	Transfer is via FC19/FC24 to the standard inter- face DB21.DBX
34.0	CMM_OUT.sub_mode_mill.tool Operating area – Tool is selected	Standard interface signal DB19.DBB21 = 205
34.1	CMM_OUT.sub_mode_mill.directory Operating area – Directory is selected	Standard interface signal DB19.DBB21 = 202
34.2	CMM_OUT.sub_mode_mill.messages Operating area – Alarms/Messages is se- lected	Standard interface signal DB19.DBB21 = 204
34.3	CMM_OUT.sub_mode_mill.program Operating area – Program is selected	Standard interface signal DB19.DBB21 = 203
34.7	CMM_OUT.sub_mode_mill.mda Operating area – MDA is selected	Transfer is via FC19/FC24 to the standard inter- face DB11.DBX6.1 MDA
36.0	CMM_OUT.cmm_plc_activ ShopTurn PLC active	Omitted because ShopTurn PLC no longer exists
36.1	CMM_OUT.cmm_mmc_activ ShopTurn operator interface active	ShopTurn Open (PCU 50.3): is not evaluated ShopTurn on NCU (HMI Embedded): DB19.DBB21
36.7	CMM_OUT.ext_prog_sel External processing program is selected	n.a.

 Table 6-2
 Signals from ShopTurn (output signals)
6.3 Overview of former ShopTurn interface

Address DB82 DBX	Name Comments	Spares
37.0	CMM_OUT.program_selection_done Acknowledgment from HMI that a program has been selected	Omitted because of the new start lock logic of the NCK. The program can be selected and started directly.
37.1	CMM_OUT.program_test_activ Function for program test is active	Standard interface signal DB21.DBX33.7
37.2	CMM_OUT.dry_run_activ Function for DryRun is active	Standard interface signal DB21.DBX318.6
37.3	CMM_OUT.m01_activ Function M01 is active	Standard interface signal DB21. DBX32.5
37.4	CMM_OUT.skip_block_activ Function for skipping record is active	Standard interface signal DB21. DBX26.0ff
37.7	CMM_OUT.start_up_activ ShopTurn boot active	n.a.
38.1	CMM_OUT.tool_un_load_internal Load/unload tool without moving magazine	Standard interface signal DB71.DBX32.0 for the1st loading point
38.2	CMM_OUT.drf_activ Function DRF is active	Standard interface signal DB21.DBX24.3
38.3	CMM_OUT.nc_start_ineffective NC start has no effect	Global start lock can be deactivated. Standard interface signal DB21.DBX7.5
44	CMM_OUT.mask_number Current screen number in ShopTurn	Standard interface signal DB19.DBW24

Table 6-2	Signals from	ShopTurn	(output signa	ıls)
	Signals IIUIII	ShopTum	(output signe	13)

 \circledcirc Siemens AG 2008 All Rights Reserved SINUMERIK 840D sI Commissioning CNC: ShopTurn – 01/2008 Edition

Space for your notes

7

Machine Data

7.1 NCK machine data for ShopTurn

When commissioning the NCK, all relevant NCK machine data (including tool management data) must be set with the ShopTurn-specific values.

In the operating area "Tools – zero" open the mask "Machine data" by pressing the softkey "Machine data" in the extended softkey bar. Here all the machine data needed for ShopTurn is displayed with information regarding setpoint and actual values.

Correctly set machine data is marked with a tick. Machine data marked with an exclamation point must be corrected accordingly. A red exclamation point in the header (No., MD, Set, Actual) will indicate when it is necessary to correct machine data.

The following symbols indicate the rule for setpoint to actual value:

- =: must be exact
- ≤: must be at least
- &: certain bits must be exact

If no rule is indicated for setpoint to actual value, it is only a suggestion.

NCK machine data with exact values must be set as specified. NCK machine data with minimum values can be adapted to the specific features of your machine.

The activation mode for each item of machine data is indicated in the column after the actual value display.

- po: Power On (softkey "NCK reset")
- cf: Configuration (softkey "Set MD effective")
- so: Immediately (no action required)
- re: Reset ("Reset" key on machine control panel)

Note

Files SIEMENSD.RTF and SIEMENSE.RTF list the necessary settings for the ShopTurn machine data. You are advised to print these out. You can then check and if necessary correct the specific values more conveniently.

Setup feed rate

7.1 NCK machine data for ShopTurn

"Use the "Actual = Set" softkey to adjust incorrect values so that they meet the minimum ShopTurn requirements. These are confirmed when you click "OK" to acknowledge the query that follows.

If, for instance, the actual value is too low, the value of the machine data will be set to the lowest setpoint. For bit masks only the missing bits are set.

Caution

The tool length corrections are set in ShopTurn (setting data 42940 \$SC_TOOL_LENGTH_CONST and 42950 \$SC_TOOL_LENGTH_TYPE); length 1 always refers to the X direction and length 2 always refers to the Z direction irrespective of machining layer and cutting position.

Note

Please note that the machine data record also contains machine data for configuring the memory.

For an exact description of all NCK machine data please refer to: **References:** /LIS1sI/, lists (book 1); /LIS2sI/, lists (book 2); /IDsI/, Commissioning CNC: NCK, PLC, drive, SINUMERIK 840D sI; /FB/, Description of Functions

Use the SD 42600 JOG_FEED_PER_REV_SOURCE and SD 43300 \$SA_ASSIGN_FEED_PER_REV_SOURCE setting data of the relevant axes to specify which setup feedrate will be evaluated in manual mode.

- SD 42600 JOG_FEED_PER_REV_SOURCE = -3 and SD \$SA_ASSIGN_FEED_PER_REV_SOURCE = -3: When the main spindle is rotating, the JOG function uses the revolutional feedrate. When the spindle is stationary, the feedrate for each minute is used.
- SD 42600 JOG_FEED_PER_REV_SOURCE = 0 and SD \$SA_ASSIGN_FEED_PER_REV_SOURCE = 0: The feedrate used depends on the setting data SD 41100 JOG_REV_IS_ACTIVE: Bit 0 = 0 setup feedrate in mm/min (with rotating and stationary spindle) Bit 0 = 1 setup feedrate in mm/rev

The setup feed rates can be entered in the mask "Machine – manual" \rightarrow ">" \rightarrow "ShopTurn settings".

Use the option "Manual machine", enter the feed in the basic mask "Manual". **References:** /BATsl/, Operation/Programming ShopTurn

Once ShopTurn has been installed on the PCU and commissioning of the NCK and PLC is complete, you still need to adapt the display machine data. In any case, you must check the settings of the display machine data that are identified in table 7-1 by means of "*".

7.2

7.2.1 Overview of display machine data

Table 7-1	Display	machine data	for	ShopTurn

MD	MD identifier	Comment	Preset
num-			default
ber			
9014	\$MM_USE_CHANNEL_DISPLAY_DATA	Use channel-specific display machine	0
9020	\$MM_TECHNOLOGY	Basic configuration turning/milling	1
9422	\$MM_MA_PRESET_MODE	Preset/basic offset in JOG	1
9428	\$MM_MA_SPIND_MAX_POWER	Factor for display of spindle utilization	100
9429	\$MM_MA_SPIND_POWER_RANGE	Display area for spindle utilization	200
9450	\$MM_WRITE_TOA_FINE_LIMIT	Limit value for wear fine	0.999
9451	\$MM_WRITE_ZOA_FINE_LIMIT	Limit value for fine adjustment	0.999
9460	\$MM_PROGRAM_SETTINGS	Settings in the Program area	HD
9478*	\$MM_TO_OPTION_MASK	Settings for ShopTurn	1
9550*	\$MM_CTM_CYC_ROUGH_RELEASE_DIST	Retraction distance for stock removal at a contour	1
9551*	\$MM_CTM_CYC_ROUGH_RELEASE_ANGLE	Retraction angle for stock removal at a contour	45
9552*	\$MM_CTM_CYC_ROUGH_BLANC_OFFS	Blank offset for stock removal at a contour	1
9553*	\$MM_CTM_CYC_ROUGH_TRACE_ANGLE	Starting angle for tracing a contour	5
9554	\$MM_CTM_CYC_ROUGH_MIN_REST_MAT_1	Starting thickness, with reference to the final machining allowance, for machining residual material (axis 1)	50
9555	\$MM_CTM_CYC_ROUGH_MIN_REST_MAT_2	N_REST_MAT_2 Starting thickness, with reference to the final machining allowance, for machining residual material (axis 2)	
9556	\$MM_CTM_CYC_ROUGH_VAR_DEPTH	Percentage for variable cutting depth when turning a contour	20
9557	\$MM_CTM_CYC_ROUGH_FEED_INT_TIME	Feed interruption time when turning a con- tour	-1
9558	\$MM_CTM_CYC_ROUGH_INT_REL_DIST	Retraction path feed interruption Contour turning	0
9560	\$MM_CTM_TURN_GROOV_TOOL_BEND	Retraction due to tool bending when plunge-turning a groove	0.1
9561	\$MM_CTM_TURN_GROOV_FREE_CUT_VAL	Retraction depth before turning operation when plunge-turning a groove	0.1
9606	\$MM_CTM_SIMULATION_TIME_NEW_POS	Simulation updating rate of actual value	350
9611	\$MM_CTM_CROSS_AX_DIAMETER_ON	Diameter display for active transverse axes	1
9619	\$MM_CTM_G91_DIAMETER_ON	Incremental infeed	0
9621	\$MM_CTM_CYCLE_DWELL_TIME	Dwell time for cycles	-1
9626	\$MM_CTM_TRACE	Settings for ShopTurn	1
9630	\$MM_CTM_FIN_FEED_PERCENT	Finishing feed in percent	100
9639	\$MM_CTM_MAX_TOOL_WEAR	Upper input limit for tool wear	1
9640	\$MM CTM ENABLE CALC THREAD PITCH	Calculation of thread depth if pitch entered	0

MD	MD identifier	Comment	Preset
num- ber			default
9646	\$MM_CTM_FACTOR_O_CALC_THR_PITCH	Factor for calculating the external thread depth if pitch entered	0.6134
9647	\$MM_CTM_FACTOR_I_CALC_THR_PITCH	Factor for calculating the internal thread depth if pitch entered	0.5413
9648	\$MM_CTM_ROUGH_O_RELEASE_DIST	Retraction distance for stock removal/cut- ting by external machining	1.0
9649	\$MM_CTM_ROUGH_I_RELEASE_DIST	Retraction distance for stock removal/cut- ting by internal machining	0.5
9650*	\$MM_CMM_POS_COORDINATE_SYSTEM	Position of coordinate system	34
9651*	\$MM_CMM_TOOL_MANAGEMENT	Tool management variant	4
9652*	\$MM_CMM_TOOL_LIFE_CONTROL	Tool monitoring	1
9654	\$MM_CMM_SPEED_FIELD_DISPLAY_RES	Number of decimal places in the speed input field	0
9657	\$MM_CMM_CYC_MIN_CONT_PO_TO_RAD	Variation of smallest possible cutter radius in percent	5
9658	\$MM_CMM_CYC_MAX_CONT_PO_TO_RAD	Variation of largest possible cutter radius	0.01
9663	\$MM_CMM_TOOL_DISPLAY_IN_DIAM	Display radius/diameter for tool	1
9664	\$MM_CMM_MAX_INP_FEED_P_MIN	Maximum feed in mm/min	10000.0
9665	\$MM_CMM_MAX_INP_FEED_P_ROT	Maximum feed in mm/rev	1.0
9666	\$MM_CMM_MAX_INP_FEED_P_TOOTH	Maximum feed in mm/tooth	1.0
9667*	\$MM_CMM_FOLLOW_ON_TOOL_ACTIVE	Tool preselection active	0
9668*	\$MM_CMM_M_CODE_COOLANT_I_AND_II	M function coolant I and II	-1
9669	\$MM_CMM_FACE_MILL_EFF_TOOL_DIAM	Effective cutter diameter for face milling	85.0
9670	\$MM_CMM_START_RAD_CONTOUR_POCKE	Radius of approach circle for finishing con-	-1.0
		tour pockets plus half the final machining allowance (-1 = safety clearance)	
9671	\$MM_CMM_TOOL_LOAD_DEFAULT_MAG	Load tool in default magazine	0
9672*	\$MM_CMM_FIXED_TOOL_PLACE	Fixed location coding	1
9673*	\$MM_CMM_TOOL_LOAD_STATION	Number of loading point	1
9674	\$MM_CMM_ENABLE_TOOL_MAGAZINE	Display of magazine list	1
9675	\$MM CMM CUSTOMER START PICTURE	Customized boot screen	0
9676*	\$MM_CMM_DIRECTORY_SOFTKEY_PATH1	Path for drive names in directory manage- ment	-
9677*	\$MM_CMM_DIRECTORY_SOFTKEY_PATH2	Path for drive names in directory manage- ment	_
9678*	\$MM_CMM_DIRECTORY_SOFTKEY_PATH3	Path for drive names in directory manage- ment	-
9679*	\$MM_CMM_DIRECTORY_SOFTKEY_PATH4	Path for drive names in directory manage- ment	-
9680*	\$MM_CMM_M_CODE_COOLANT_I	M function coolant I	8
9681*	\$MM_CMM_M_CODE_COOLANT_II	M function coolant II	7
9686*	\$MM_CMM_M_CODE_COOLANT_OFF	M function for coolant OFF	9
9687	\$MM_CMM_TOOL_MOVE_DEFAULT_MAG	Reload tool in default magazine	0
9718*	\$MM_CMM_OPTION_MASK_2	Settings for ShopTurn	2
9719*	\$MM_CMM_OPTION_MASK	Settings for ShopTurn	H5
9724	SMM_CMM_CIRCLE_RAPID_FEED	Rapid feed for positioning on circular path	5000
9725	SMM_CMM_ENABLE_QUICK_M_CODES	Enable fast M functions	U
9729	\$MIM_CMIM_G_CODE_IOOL_CHANGE_PROG	code	-
9749*	\$MM_CMM_ENABLE_MEAS_T_AUTO	Enable automatic tool measurement	1
9751*	\$MM_CMM_MEAS_T_PROBE_INPUT	Measuring input for tool probe	0
9754	\$MM_CMM_MEAS_DIST_TOOL_LENGTH	Maximum measurement distance for tool length for rotating spindle	10
9759	\$MM_CMM_MAX_CIRC_SPEED_ROT_SP	Maximum circumferential speed for tool measurement for rotating spindle	100

MD num- ber	MD identifier	Comment	Preset default
9760	\$MM_CMM_MAX_SPIND_SPEED_ROT_SP	Maximum speed for tool measurement for rotating spindle	1000
9771	\$MM_CMM_MAX_FEED_ROT_SP	Maximum feed for tool measurement for rotating spindle	20
9772	\$MM_CMM_T_PROBE_MEASURING_DIST	Measurement distance for tool measure- ment with stationary spindle	10
9773	\$MM_CMM_T_PROBE_MEASURING_FEED	Feed rate for tool measurement with sta- tionary spindle	300
9777	\$MM_CMM_ENABLE_TIME_DISPLAY	Control for time display	0x7F
9802	\$MM_ST_INDEX_AXIS_C_SUB	Axis index for separate C axis of counter- spindle	0
9803*	\$MM_ST_INDEX_AXIS_4	Axis index for 4th axis	5
9804*	\$MM_ST_INDEX_SPINDLE_MAIN	Axis index for main spindle	3
9805*	\$MM_ST_INDEX_SPINDLE_TOOL	Axis index for tool spindle	4
9806*	\$MM_ST_INDEX_SPINDLE_SUB	Axis index for counter-spindle	6
9807*	\$MM_ST_INDEX_AXIS_C	Axis index for C axis	3
9000"	\$MIN_ST_INDEX_AXIS_D \$MM_ST_GEAR_STERS_SPINDLE_MAIN	Number of gears on main spindle	0
9811*	\$MM_ST_GEAR_STEPS_SPINDLE_MAIN	Number of gears on tool spindle	0
9812*	\$MM_ST_GEAR_STEPS_SPINDLE_SUB	Number of gears on counter-spindle	0
9820	\$MM_ST_MAGN_GLASS_POS_1	Im_ST_ALAN_OTEL S_STINDEL_SOB Number of gears on counter-spinale IM_ST_MAGN_GLASS_POS_1 Position of magnifying glass for measuring tool. 1st axis	
9821	\$MM_ST_MAGN_GLASS_POS_2 Position of magnifying glass for measuring tool, 2nd axis		0
9822*	\$MM_ST_DISPL_DIR_MAIN_SPIND_M3 Displayed direction of rotation for main spindle with M3		0
9823*	\$MM_ST_DISPL_DIR_SUB_SPIND_M3	M3 Displayed direction of rotation for counter- spindle with M3	
9824*	\$MM_ST_DISPL_DIR_MAIN_C_AX_INV	Displayed direction of rotation for C axis main spindle with M3	0
9825*	\$MM_ST_DISPL_DIR_SUB_C_AX_INV	Displayed direction of rotation for C axis counter-spindle with M3	0
9826*	\$MM_ST_DEFAULT_DIR_TURN_TOOLS	Main direction of rotation for all turning tools	3
9827*	\$MM_ST_DEFAULT_MACHINING_SENSE	Basic settings for machining direction – milling	0
9828*	\$MM_ST_MEAS_T_PROBE_INPUT_SUB	Input number for tool probe for counter- spindle	1
9829	\$MM_ST_SPINDLE_CHUCK_TYPES	Type of spindle chuck	0
9830	\$MM_ST_SPINDLE_PARA_ZL0	Chuck dimension for main spindle	0
9831	\$MM_ST_SPINDLE_PARA_ZL1	Chuck dimension for counter-spindle	0
9832	\$MM_ST_SPINDLE_PARA_ZL2	Stop almension for counter-spinale	0
9833	\$MIM_ST_SPINDLE_FARA_ZL3	Tailataak diamatar	0
9837	\$MM_ST_TAILSTOCK_LENGTH		0
9838	\$MM_ST_BORDER_TOOL LEN X BEV 2	Limit value of tool length X for the 2nd tur-	0
		ret	•
9840*	\$MM_ST_ENABLE_MAGN_GLASS	Magnifying glass function in manual: Mea- suring a tool	0
9841*	\$MM_ST_ENABLE_PART_OFF_RECEPT	Enable receptacle function for cut-off	0
9842*	\$MM_ST_ENABLE_TAILSTOCK	Enable tail stock	0
9843*	\$MM_ST_ENABLE_SPINDLE_CLAMPING	Enable spindle clamping (C axis)	0
9849	\$MM_ST_CYCLE_SUB_SP_FARK_POS_Y	Parking position of Y axis with counter- spindle	0

MD num- ber	MD identifier	Comment	Preset default
9850	\$MM_ST_CYCLE_THREAD_RETURN_DIST	Return distance for thread turning	2
9851*	\$MM_ST_CYCLE_SUB_SP_WORK_POS	Retraction position Z for counter-spindle	0
9852	\$MM_ST_CYCLE_SUB_SP_DIST	Distance as of which feed rate is used when approaching fixed stop with counter- spindle	10
9853	\$MM_ST_CYCLE_SUB_SP_FEED	Feed rate for traveling to fixed stop with counter-spindle	0
9854	\$MM_ST_CYCLE_SUB_SP_FORCE	Force in percent for traveling to fixed stop with counter-spindle	10
9855	\$MM_ST_CYCLE_TAP_SETTINGS	Settings for thread tapping	0
9856	\$MM_ST_CYCLE_TAP_MID_SETTINGS	Settings for center tapping	0
9857	\$MM_ST_CYCLE_RET_DIST_FIXEDSTOP	Retraction distance before clamping after traveling to fixed stop	0
9858	\$MM_ST_CYCLE_RET_DIST_PART_OFF	Retraction distance before cut-off with counter-spindle	0
9859	\$MM_ST_CYCLE_PART_OFF_CTRL_DIST	Distance for cut-off check	0.1
9860	\$MM_ST_CYCLE_PART_OFF_CTRL_FEED	Feed for cut–off check	0
9861	\$MM_ST_CYCLE_PART_OFF_CTRL_FORC	Force in percent for cut–off check	10
9862	\$MM_ST_CYC_DRILL_MID_MAX_ECCENT	Maximum center offset for center drilling	0.5
9863	\$MM_ST_MAX_INP_AREA_GAMMA	Maximum input area for gamma alignment angle	5
9897	\$MM_ST_OPTION_MASK_MAN_FUNC	Settings for ShopTurn manual functions	0
9898*	\$MM_ST_OPTION_MASK	Settings for ShopTurn	H7000
9899*	\$MM_ST_TRACE	Settings for ShopTurn	0

7.2.2 Description of display machine data

9014	\$MM_USE_CHANNEL_DISPLAY_DATA				
MD number	Use channe	l-specific di	isplay machine data		
Default setting: 0		Min. input lir	nit: 0	Max. input li	mit: 1
Change becomes effective after: IMMEDIATELY Protection level: 3/4					Units: –
Data type: LONG				Valid as of software version:	
				Shop Turn 6.	4
Significance:	In this MD yo	ou stipulate w	/hether you want to use cha	annel–specific	display machine data.
	0 = No chan	nel–specific o	display machine data		
1 = Channel-specific display machine data					
Note: With ShopTurn this must be set to MD = 0.					

9020	\$MM_TECHNOLOGY				
MD number	Basic configuration tur	ning/milling			
Default setting: 1	Min. input li	mit: 0	Max. input li	mit: 2	
Change becomes effective	Change becomes effective after: POWER ON Protection level: 3/4 Units: -				
Data type: BYTE Valid as of software ve					
			ShopTurn 6	.1	
Significance:	In this MD you stipulate the basic configuration for simulation and free contour program- ming. 0 = No specific configuration 1 = Turning machine configuration 2 = Milling machine configuration				

9422	\$MM_MA_PRESET_MODE					
MD number	Preset/basic	offset in JO	DG			
Default setting: 1		Min. input lir	nit: 0	Max. input li	mit: 3	
Change becomes effective a	after: IMMEDIA	ATELY	Protection level: 3/4		Units: –	
Data type: BYTE				Valid as of software version ShopTurn 6.4		
Significance:	 ce: In this MD you stipulate the behavior of the function "Set zero offset" in "Machine – manual" mode. ≠ 2: Zero point is saved in the currently active zero offset, in other cases it is saved in the basic offset = 2: Zero point is saved in basic offset 					

9428	\$MM_MA_SPIND_MAX_POWER					
MD number	Maximum v	Maximum value of the spindle performance display				
Default setting: 100	Min. input limit: 100 Max. input limit: ***					
Change becomes effective	after: POWEF	N	Protection level: 3/4		Units: %	
Data type: WORD				Valid as of s	oftware version	
ShopTurn 7.1					.1	
Significance:	In this MD e	nter the facto	r by which the supplied sp	indle utilizatior	n will be multiplied.	

9429	\$MM_MA_SPIND_POWER_RANGE					
MD number	Display area	a for spindle	utilization			
Default setting: 200		Min. input lir	nit: 100	Max. input li	mit: ***	
Change becomes effective	after: POWER	N	Protection level: 3/4		Units: %	
Data type: WORD				Valid as of software version ShopTurn 7.1		
Significance:	In this MD you stipulate the display range of the bar displaying spindle utilization. Depend- ing upon the value entered, the displayed percentage values and the extension of the color areas change. Value entered = 100: Percentage values 0, 80, and 100% are displayed. The color display changes from green to red starting at 80%. Value entered = > 100, e.g. 200: Percentage values 0, 100, and 200% are displayed. The colored display changes from green to red as of 100%					

9450	\$MM_WRIT	\$MM_WRITE_TOA_FINE_LIMIT				
MD number	Limit value	Limit value for wear fine				
Default setting: 0.999		Min. input lir	nit: —	Max. input li	mit: –	
Change becomes effective after: IMMEDIATELY Protection level: 3/4					Units: mm	
Data type: DOUBLE				Valid as of software version		
				ShopTurn 6	.4	
Significance:	nificance: With this MD you define the upper incremental limit (limit value for wear fine) for tool wear (length, radius).					
	The incremental upper limit is only effective if the active protection level is greater than the protection level set in MD 9203 USER CLASS WRITE FINE.					
	The absolute	e upper limit i	s set in MD 9639 \$MM_CT	M_MAX_TOC	DL_WEAR.	

9451 MD number	\$MM_WRITE_ZOA_FINE_LIMIT				
Default setting: 0.999		Min. input limit: – Max. input limit: –			
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: mm					Units: mm
Data type: DOUBLE Valid as of software version ShopTurn 6.4 ShopTurn 6.4					oftware version .4
Significance:	When entering the fine adjustment the difference between the previous value and the new value must not exceed the value specified in this MD.				

9460	\$MM_PROGRAM_SETTINGS					
MD number	Settings in	Settings in the Program area				
Default setting: HD		Min. input limit: – Max. input limit: –			mit: –	
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: Hex					Units: Hex	
Data type: LONG Valid as of software version					oftware version	
	ShopTurn 6.4					
Significance:	Bit 0 to 4: Re	eserved				
	Bit 5: Display hidden lines (;*HD*) in the G code editor					
	Bit 6: Reserved					
	Bit7: Switch off G program checking during mold making					

9478	\$MM_TO_OPTION_MASK						
MD number	Settings fo	Settings for ShopTurn					
Default setting: 1		Min. inpu	ut limit: 0000	Max. input limit: FFFF			
Change becomes effe	ective after: POWER	RON	Protection level: 1	Units: Hex			
Data type: LONG			I	Valid as of software version ShopTurn 7.5			
Significance:	Bit 0: Displa agement. Bit 1: Reser Bit 2: Displa Bit 3: Disabl Bit 4 to bit 6 Bit7: Disabl Zine. Bit 8: Evalua Bit 9: Disabl Bit 10: Calcı Bit 11: Calcı Bit 11: Calcı Bit 11: Calcı Bit 11: Calcı Bit 12: Disabl Bit 13: Displ Bit 14: Rese Bit 15: Disabl Bit 15: Disabl Bit 16: Do n Bit 17: Hide Bit 18: Hide Bit 19: With Bit 20: Spinu Bit 22: 3D a Bit 23: Rese Bit 24: Maga Bit 25: Maga	y tool para ved y additiona e creation : Reserve e editing o ate file TO e loading/ ulate by ac it 12: Rese ay interme erved be loading ot delete to tool reloca magazine Multifix stu dle is load c length is nd edge p erved azine positi azine num	ameters "Number of teeth", al list in the tool manageme of new tools directly on a r d f tool parameters (tool type _TURN.INI for configuration unloading of tools if a progr dding tool wear entries. erved ediate memory (spindle and g/unloading of tools in/out o ool wear when entering a g ation positioning. eel holder, tool can be select ed directly. displayed in "Tool orientation robes not unloaded with "U tioning in the tool wear list. ber is always displayed in t	"Spindle" and "Coolant" in the tool man- ent. magazine location. , tool name) if the tools are in the maga- n of the tool management user interface. ram is being executed on the machine. I dual gripper). If spindles. eometric value. cted in tool list. cted in tool list. on" detail display. nload all" function.			

9550 MD number	\$MM_CTM_CYC_ROUGH_RELEASE_DIST Retraction distance for stock removal at a contour				
Default setting: 1		Min. input limit: 0 Max. input limit: 10			
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units:				Units: mm	
Data type: DOUBLE			Valid as of software version: ShopTurn 6.3		
Significance:	This MD is used to stipulate the distance by which both axes are lifted off the contour dur- ing rough cutting operations. This value also applies to stock removal, plunge–cutting, and groove turning.				

9551	\$MM CTM CYC ROUG	H RELEASE ANGLE			
MD number	Retraction angle for stock removal at a contour				
Default setting: 45	Min. input lir	nit: 0	Max. input lir	nit: 90	
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: Degrees	
Data type: DOUBLE			Valid as of se ShopTurn 6.	oftware version: 3	
Significance:	This MD is used to stipula cutting operations. This ve turning.	ate the angle at which axes alue also applies to stock re Angle	are lifted off the	ne contour during rough e-cutting, and groove	

9552	\$MM_CTM	\$MM_CTM_CYC_ROUGH_BLANC_OFFS				
MD number	Blank offse	Blank offset for stock removal at a contour				
Default setting: 1		Min. input limit: 0 Max. input limit: 100				
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: mm		
Data type: DOUBLE				Valid as of software version: ShopTurn 6.3		
Significance:	This MD is used to stipulate the distance from the blank at which G0 is switched over to G1 during stock removal at a contour to compensate for any blank allowances. This value also applies to stock removal, plunge–cutting, and groove turning.					

9553	\$MM_CTM_CYC_ROUGH_TRACE_ANGLE					
MD number	Starting angle for tracing a contour					
Default setting: 5	Min. input lir	mit: 0	Max. input limit: 90			
Change becomes effective	after: IMMEDIATELY	Protection level: 3/4	Units: Degrees			
Data type: DOUBLE			Valid as of software version: ShopTurn 6.3			
Significance:	This MD is used to stipulate the angle between the cutting edge and the contour as of which, when removing stock from an edge or a contour (rough cutting), rounding will automatically take place to remove any residual material. If the angle of the residual material is greater than that specified in the MD, the tool will round the contour.					
			Contour			
	Residual material	Angle	Current cutting depth D			

9554 MD number	\$MM_CTM_CYC_ROL Starting thickness, wi residual material (axis	\$MM_CTM_CYC_ROUGH_MIN_REST_MAT1 Starting thickness, with reference to the final machining allowance, for machining residual material (axis 1)				
Default setting: 50	Min. input	limit: 0	Max. input li	mit: 1000		
Change becomes effective	ve after: IMMEDIATELY	Protection level: 3/4		Units: %		
Data type: DOUBLE	DOUBLE Valid as of software version: ShopTurn 6.3					
Significance:	This MD is used to stipu axis 1 (Z axis). This valu ing.	This MD is used to stipulate the limit value for machining residual material in the direction of axis 1 (Z axis). This value also applies to stock removal, plunge–cutting, and groove turning.				
	Example: If the MD is set to 50% and the final machining allowance is 0.5mm, any residual material thinner than 0.25 mm is not machined in a separate machining step but is removed during finishing.					
Corresponding to	MD 9555; \$MM_CTM_0	CYC ROUGH MIN RESE	T MAT2			

9555 MD number	\$MM_CTM_CYC_ROUGH_MIN_REST_MAT2 Starting thickness, with reference to the final machining allowance, for machining residual material (axis 2)					
Default setting: 50		Min. input lir	mit: 0	Max. input li	mit: 1000	
Change becomes effective a	after: IMMED	IATELY	Protection level: 3/4		Units: %	
Data type: DOUBLE				Valid as of s ShopTurn 6	oftware version: .3	
Significance:	ShopTurn 6.3 This MD is used to stipulate the limit value for machining residual material in the direction of axis 2 (X axis). This value also applies to stock removal, plunge–cutting, and groove turning. Example: If the MD is set to 50% and the final machining allowance is 0.5mm, any residual material thinner than 0.25 mm is not machined in a separate machining step but is removed during					
Corresponding to	MD 9554: \$MM_CTM_CYC_ROUGH_MIN_RESET_MAT1					

9556	\$MM_CTM_CYC_ROUGH_VAR_DEPTH					
MD number	Percentage	Percentage for variable cutting depth when turning a contour				
Default setting: 20		Min. input limit: 0			Max. input limit: 50	
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: %				Units: %		
Data type: BYTE				Valid as of software version:		
	ShopTurn 6.3					
Significance:	Specify the percentage for changing the cutting depth when turning a contour. You can					
	select chang	select changing the cutting depth for stock removal and for removing residual material.				

9557	\$MM_CTM_CYC_ROUGH_FEED_INT_TIME				
MD number	Feed interre	uption time v	when turning a contour		
Default setting: -1		Min. input li	mit: –	Max. input li	mit: –
Change becomes effective a	after: IMMED	ATELY	Protection level: 3/4		Units: –
Data type: DOUBLE				Valid as of software version:	
				Shop Turn 6.	4
Significance:	This MD is upplunge-cutti	ised to stipula ng, plunge–ti	ate the feed interruption tim urning). The MD is only eva	e for contour t luated if MD 9	turning (removing stock, 1558
	MM_CTM_C	CYC_ROUGH	I_INT_REL_DIST = 0.		
	> 0: Interruption time in seconds				
	< 0: Interruption time in revolutions				
	0: No interru	iption			

9558	\$MM_CTM_CYC_ROUGH_INT_REL_DIST					
MD number	Retraction distance at	Retraction distance at feed interruption Contour turning				
Default setting: 0	Min. input li	imit: 0	Max. input li	imit: 10		
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: mm		
Data type: DOUBLE	Valid as of software version: ShopTurn 6.4					
Significance:	This MD is used to stipul ing (removing stock, plur > 0: Retraction distance MD 9557 \$MM_CTI = 0: No retraction distan	This MD is used to stipulate the retraction distance for feed interruption when contour turn- ing (removing stock, plunge–cutting, plunge–turning). > 0: Retraction distance for feed interruption MD 9557 \$MM_CTM_CYC_ROUGH_FEED_INT_TIME is not effective.				

9560	\$MM_CTM_TURN_GR	OOV_TOOL_BEND	
MD number	Retraction due to tool	bending when plunge-tur	ning a groove
Default setting: 0.1	Min. input	limit: 0.0	Max. input limit: 1.0
Change becomes effective	after: IMMEDIATELY	Protection level: 3/4	Units: mm
Data type: DOUBLE			Valid as of software version: ShopTurn 6.3
Significance:	In the stock removal cycright up to the contour. Twhich each subsequent	Cle, as the tool bends during This MD is used to stipulate tout is shortened.	plunge turning, the tool cannot travel the lateral distance to the last cut by

9561	\$MM_CTM	\$MM_CTM_TURN_GROOV_FREE_CUT_VAL				
MD number	Retraction	depth before	turning operation when	plunge-turni	ing a groove	
Default setting: 0.1		Min. input lir	nit: 0.0	Max. input li	mit: 1.0	
Change becomes effective a	ective after: IMMEDIATELY Protection level: 3/4 Units: mm				Units: mm	
Data type: DOUBLE				Valid as of software version:		
				ShopTurn 6.	.3	
Significance:	In the stock	removal cycle	e, as the tool bends during	plunge turning	g, the tool would make an	
	excessively deep cut. In this MD you define the tool retraction distance between grooving					
	and stock removal.					
	Diagram see	9650 \$N 9650	/IM_CIM_IURN_GROOV	_LOOF_REM	D	

9606	\$MM_CTM_SIMULATION_TIME_NEW_POS				
MD number	Simulation updating ra	Simulation updating rate of actual value			
Default setting: 350	Min. input limit: 0 Max. input limit: 4000				
Change becomes effective	Change becomes effective after: POWER ON Protection level: 3/4 Units: ms				
Data type: WORD			Valid as of software version: ShopTurn 6.1		
Significance:	This MD is used to stipulate the time intervals at which the simulation graphic must be up- dated to show the current machining process on the machine tool. Value = 0 means no update.				

9611 MD number	\$MM_CTM_CROS	SS_AX	_DIAMETER_ON tive transverse axes		
Default setting: 1	Min. i	input lir	nit: 0	Max. input li	mit: 1
Change becomes effective	after: IMMEDIATELY	ſ	Protection level: 3/4	•	Units: –
Data type: BYTE				Valid as of software version: ShopTurn 6.1	
Significance:	 Snop lurn 6.1 Absolute values input as radius value Zero offsets always specified as radius value 1: Position display as diameter Distance to go as diameter 				

9619	\$MM_CTM_G91_DIAMETER_ON				
MD number	Incremental infeed				
Default setting: 0	Min. input	limit: 0	Max. input li	imit: 1	
Change becomes effective a	hange becomes effective after: IMMEDIATELY Protection level: 3/4 Units: -				
Data type: BYTE			Valid as of software version:		
			ShopTurn 6.1		
Significance:	If the coordinates are entered as incremental dimensions, you can choose between radius and diameter programming. 0 = Entry as radius 1 = Entry as diameter				

9621	\$MM_CTM_CYCLE_DWELL_TIME				
MD number	Dwell time	for cycles			
Default setting: -1		Min. input lir	mit: –100	Max. input li	mit: +100
Change becomes effective	after: IMMEDI	ATELY	Protection level: 3/4		Units:
					See meaning
Data type: DOUBLE				Valid as of software version:	
				ShopTurn 6	.4
Significance:	This MD is u	ised to stipula	ate the dwell time between	plunge and re	traction for the plunge-
	cutting cycles ("Turning" \rightarrow "Plunge–cutting").				
	> 0 = Dwell time in seconds				
	< 0 = Dwell	time in spindl	e revolutions		

9626	\$MM_CTM_TRA	ACE			
MD number	Settings for She	opTurn			
Default setting: 1	Mir	n. input lir	nit: 0000	Max. input	limit: FFFF
Change becomes effective	after: IMMEDIATE	ELY	Protection level: 3/4		Units: Hex
Data type: WORD				Valid as of ShopTurn 7	software version: 7.1
Significance:	Bit 0: Free Bit 1: Display sys only). Bit 2 to bit 12: Re Bit 13: Display cy diagnostics purp Bit 14 to 16: Res	vstem mes leserved cyclical lea poses only served	ssages from ShopTurn in ad time of ShopTurn betw y).	the dialog line	(for diagnostics purposes

9630 MD number	\$MM_CTM_FIN_SPEED_PERCENT Finishing feed in percent				
Default setting: 100		Min. input lir	nit: 1	Max. input li	imit: 100
Change becomes effective a	tive after: IMMEDIATELY Protection level: 3/4 Units: %				
Data type: WORD				Valid as of s ShopTurn 6	oftware version: .1
Significance:	This MD is used to stipulate a feed rate for the finishing process when complete machining "Roughing and finishing" is selected; this feed rate is a percentage of the value entered for parameter F (feed rate).				

9639	\$MM_CTM_MAX_TOOL_WEAR			
MD number	Upper input limit for too	ol wear		
Default setting: 1	Min. input lir	nit: 0	Max. input li	mit: 10
Change becomes effective	after: IMMEDIATELY	Protection level: 3/4		Units: mm
Data type: DOUBLE			Valid as of s	oftware version:
			ShopTurn 6	.4
Significance:	With this MD you define t	he upper absolute limit for	tool wear (len	gth, radius). This means
	that the total value must not exceed the upper absolute limit when entering the wear value			
	in the tool wear list.			
	The incremental upper limit is defined in MD 9450 \$MM_WRITE_TOA_FINE_LIMIT.			

9640	\$MM_CTM_ENABLE_C	ALC_THREAD_PITCH			
MD number	Calculation of thread de	epth if pitch entered			
Default setting: 0	Min. input lir	mit: 0	Max. input li	mit: 1	
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: -					
Data type: BYTE			Valid as of software version:		
			ShopTurn 6.	.3	
Significance:	This MD is used to calculate thread depth K for a metric thread according to pitch P (mm/ rev) and thread type (internal/external thread). 0 = Thread depth K is not calculated 1 = Thread depth K is calculated				

9646	\$MM_CTM_FACTOR_O_CALC_THR_PITCH					
MD number	Factor for c	Factor for calculating the external thread depth if pitch entered				
Default setting: 0,6134		Min. input limit: – Max. input limit: –				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: –					Units: –	
Data type: DOUBLE			Valid as of software version:			
ShopTurn 6.3					3	
Significance:	gnificance: This MD is used to stipulate the factor for converting thread pitch to thread depth for metric external threads.				o thread depth for metric	

9647 MD number	\$MM_CTM Factor for c	\$MM_CTM_FACTOR_I_CALC_THR_PITCH Factor for calculating the internal thread depth if pitch entered				
Default setting: 0,5413	1	Min. input limit: – Max. input limit: –				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: –					Units: –	
Data type: DOUBLE			Valid as of s ShopTurn 6	oftware version: .3		
Significance: This MD is used to stipulate the factor for converting thread pitch to thread depth for metric internal threads.						

9648	\$MM_CTM_ROUGH_O_RELEASE_DIST					
MD number	Retraction distance	Retraction distance for stock removal/cutting by external machining				
Default setting: 1,0	Min. inp	Min. input limit: –1 Max. input limit: 100				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: mm					Units: mm	
Data type: DOUBLE				Valid as of software version:		
				ShopTurn 6.1		
Significance:	This MD is used to s	tipulate the	e distance by which	the tool is retra	acted	
	from the outside contour for cutting and stock removal by external machining. This does not					
	apply to stock removal of a contour.					
	-1 = Retraction by tv	vice the to	ol nose radius			

9649	\$MM_CTM_ROUGH_I_RELEASE_DIST					
MD number	Retraction d	Retraction distance for stock removal/cutting by internal machining				
Default setting: 0,5		Min. input limit: -1 Max. input limit: 100				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: mm					Units: mm	
Data type: DOUBLE			Valid as of software version: ShopTurn 6.1			
Significance:	This MD is used to stipulate the distance by which the tool is retracted from the inside contour for cutting and stock removal by internal machining. This does not apply to stock removal of a contour. -1 = Retraction by twice the tool nose radius					

9650	\$MM_CMM_POS_COORDINATE_SYSTEM						
MD number	Position of coordinate system						
Default setting: 34	Min. input limit: 0	Max. input limit: 47					
Change becomes effective a	after: IMMEDIATELY Protection level: 3/4	Units: –					
Data type: BYTE		Valid as of software version ShopTurn 6.1					
Significance:	This MD is used to adapt the coordinates system of the operator interface to that of the machine. Depending upon the selected position, all help displays, process graphics, simulation and entry fields with circle direction data automatically change on the ShopTurn user interface. The coordinate system can take on the positions listed below. Also note MD 9719 \$MM_CMM_OPTION_MASK, bit 31 (training coordinates system). Examples: 0: Vertical turning machine (vertical boring and turning mill) 19: Horizontal turning machine, processing in front of turning center 34: Horizontal turning machine, processing behind turning center						
	bed turning machine)						
+Z +Y	+Y +Z +Z	+Y +Z +Z					
(0) +X	(1) +Z ♥ (2) ▲ +Y	(3)					
+Z +Y +Y (4) +X	5 +Z 6 +X	+Z +X +X +X +Y +Z					
*X *Z 8 *Z	9 +X V 10 +Z	+Z +Z +X (11) +X					
+X +Z +Z	+Y +Z +Z +Y + 13 + +X 14 +Y +	++X +Y +Z +Z +X					
16 +Y +X +Z	+Y +Z (17) +Y (18) +X	+Z (19 +X +Z +Z +Y					
+Y +X +X	+Z +X +Z +Z +Z	+Y +Z +Z +X +Y					



9651 MD number	\$MM_CMM_TOOL_MANAGEMENT					
Default setting: 4	Min. input	Min. input limit: 1 Max. input limit: 4				
Change becomes effective	after: POWER ON		Units: –			
Data type: BYTE			Valid as of s ShopTurn 6	oftware version .1		
Significance:	Choice of two tool mana	agement variants:				
	2: Tool management wit	hout loading/unloading				
	4: Tool management with loading/unloading					

9652	\$MM_CMM_TOOL_LIFE_CONTROL					
MD number	Tool monitoring					
Default setting: 1	Min. input	Min. input limit: 0 Max. input limit: 1				
Change becomes effective	after: POWER ON		Units: –			
Data type: BYTE			Valid as of software version			
			ShopTurn 6	5.1		
Significance:	This MD is used to activ	ate tool monitoring.				
	0 = Tool monitoring is not displayed					
	1 = Tool monitoring is displayed					

9654	\$MM_CMM_SPEED_FIELD_DISPLAY_RES				
MD number	Number of	Number of decimal places in the speed input field			
Default setting: 0		Min. input limit: 0 Max. input limit: 4			
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –	
Data type: BYTE				Valid as of software version	
ShopTurn 6.1				1	
Significance:	This MD is u	This MD is used to stipulate the number of decimal places in parameter field S (speed).			

\$MM_CMM	CYC_MIN_C	CONT_PO_TO_RAD		
Variation of	Variation of smallest possible cutter radius in %			
	Min. input limit: 0 Max. input limit: 50			
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: %
Data type: WORD			Valid as of software version	
			ShopTurn 6	.1
This MD is required for milling contour pockets. This parameter is used to stipulate the percentage by which the radius of the cutter being used may be smaller than the one used for generation				
	\$MM_CMM Variation of after: IMMEDI This MD is ri percentage I for generation	\$MM_CMM_CYC_MIN_C Variation of smallest po Min. input lin after: IMMEDIATELY This MD is required for m percentage by which the in for generation.	\$MM_CMM_CYC_MIN_CONT_PO_TO_RAD Variation of smallest possible cutter radius in % Min. input limit: 0 after: IMMEDIATELY Protection level: 3/4 This MD is required for milling contour pockets. This percentage by which the radius of the cutter being u for generation.	\$MM_CMM_CYC_MIN_CONT_PO_TO_RAD Variation of smallest possible cutter radius in % Min. input limit: 0 Max. input limit: after: IMMEDIATELY Protection level: 3/4 Valid as of s ShopTurn 6. This MD is required for milling contour pockets. This parameter is percentage by which the radius of the cutter being used may be store for generation.

9658	\$MM_CMM_CYC_MAX	CONT_PO_TO_RAD			
MD number	Variation of largest po	ssible cutter radius			
Default setting: 0.01	Min. input limit: 0.0 Max. input limit: 10.0				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: mm					
Data type: DOUBLE			Valid as of software version ShopTurn 6.1		
Significance:	This MD is required for milling contour pockets. This parameter is used to stipulate the amount by which the radius of the cutter being used may be larger than the one used for generation.				

9663	\$MM_CMM_TOOL_DISPLAY_IN_DIAM					
MD number	Display radius/diame	Display radius/diameter for tool				
Default setting: 1	Min. inpu	Min. input limit: 0 Max. input limit: 1				
Change becomes effective a	after: POWER ON	Protection level: 3/4		Units: –		
Data type: BYTE			Valid as of software version ShopTurn 6.1			
Significance:	This MD is used to stip tools): 0 = Radius 1 = Diameter	ulate the display/input forma	at for the tool (c	only for milling and drilling		

9664	\$MM_CMM_MAX_INP_FEED_P_MIN					
MD number	Maximum fe	Maximum feed in mm/min				
Default setting: 10000.0		Min. input lir	nit: 0.0	Max. input limit: 100000.0		
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: mm/min	
Data type: DOUBLE				Valid as of s	oftware version	
ShopTurn 6.1				.1		
Significance:	This MD is u	This MD is used to enter the upper limit for the feed rate input in mm/min.				

9665 MD number	\$MM_CMM_MAX_INP_FEED_P_ROT Maximum feed in mm/rev				
Default setting: 1.0		Min. input limit: 0.0 Max. input limit: 10.0			
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: mm/rev
Data type: DOUBLE				Valid as of software version	
ShopTurn 6.1					.1
Significance:	This MD is u	This MD is used to enter the upper limit for the feed rate input in mm/rev.			

9666 MD number	\$MM_CMM_MAX_INP_FEED_P_TOOTH Maximum feed in mm/tooth				
Default setting: 1.0	Min. input limit: 0.0 Max. input limit: 5.0			mit: 5.0	
Change becomes effective a	Protection level: 3/4		Units: mm/tooth		
Data type: DOUBLE			Valid as of s	oftware version	
ShopTurn 6.1				.1	
Significance:	This MD is used to enter	This MD is used to enter the upper limit for the feed rate input in mm/tooth.			

9667 MD number	\$MM_CMM_FOLLOW_ON_TOOL_ACTIVE Tool preselection active			
Default setting: 0	Min. input li	mit: 0	Max. input I	imit: 1
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: –				
Data type: BYTE			Valid as of software version ShopTurn 6.1	
Significance:	This MD is used to activate tool preselection in a magazine (e.g. chain magazine); i.e. the following tool is already brought to the loading point for a pending tool change. 0 = Tool preselection is not active 1 = Tool preselection is active			
	Note: Tool preselection is	s not necessary for a turre	revolver; i.e. t	the MD must be set to "0".

9668 MD number	\$MM_CMM_M_CODE_COOLANT_I_AND_II M function coolant I and II				
Default setting: -1	Min. input li	mit: —1	Max. input li	mit: 32767	
Change becomes effective	Protection level: 3/4		Units: –		
Data type: WORD			Valid as of software version ShopTurn 6.1		
Significance:	This MD is used to stipula at the same time. Value: -1 = No M function xy = M function xy fi	ate the M function if in the t or coolant I and II	ools list coola	nts I and II are both active	

9669	\$MM_CMM_FACE_MILL_EFF_TOOL_DIAM					
MD number	Effective cutter diamet	Effective cutter diameter for face milling				
Default setting: 85.0	Min. input	limit: 50.0	Max. input li	mit: 100.0		
Change becomes effective	after: IMMEDIATELY	Protection level: 3/4		Units: %		
Data type: DOUBLE		-	Valid as of s ShopTurn 6	oftware version .3		
Significance:	This MD is used to stiputer diameter is derived findiameter.	late the effective cutter dia rom the ratio d/D, where d	d = 85 D = 100 Effective milling d/D = 85/100 = 0	milling. I he effective cut- and D = largest cutter diameter: 0.85 -> 85%		

9670 MD number	\$MM_CMM_START_RAD_CONTOUR_POCKE Radius of approach circle for finishing contour pockets plus half the final machining allowance (-1 = safety clearance)					
Default setting: -1.0		Min. input lin	nit: —1	Max. input li	mit: 100.0	
Change becomes effective a	nange becomes effective after: IMMEDIATELY Protection level: 3/4				Units: mm	
Data type: DOUBLE				Valid as of software version ShopTurn 6.1		
Significance:	This MD affects the radius of the approach circle when finishing contour pockets. -1 = The radius is selected such that the safety clearance for final machining is observed at the start point. >0 = The radius is selected such that the value of this MD for final machining allowance is observed at the start point.					

9671 MD number	\$MM_CMM_TOOL_LOAD_DEFAULT_MAG Load tool in default magazine				
Default setting: 0	Min. input limit: 0 Max. input limit: 30			mit: 30	
Change becomes effective	Protection level: 3/4		Units: –		
Data type: BYTE			Valid as of s ShopTurn 6	oftware version .4	
Significance:	This MD is used to stipulate the magazine in which ShopTurn first searches for an empty location when loading a tool.				

9672	\$MM_CMM_FIXED_TOOL_PLACE				
MD number	Fixed locati	Fixed location coding			
Default setting: 1		Min. input limit: 0 Max. input limit: 1			
Change becomes effective	after: POWEF	RON	Protection level: 3/4		Units: –
Data type: BYTE				Valid as of software version	
				ShopTurn 6	.1
Significance:	This MD is u	used to stipula	ate the state of the tools:		
	0 = Tool with	n variable loca	ation coding in the magazin	le	
	1 = Tools with fixed location coding in the magazine				
	Note: With a turret revolver the tools are always allocated to a fixed location; i.e. this MD				
	must be set	to "1".			

9673	\$MM_CMM_TOOL_LOAD_STATION				
MD number	Number of loading poin	nt			
Default setting: 1	Min. input li	mit: 1	Max. input li	mit: 2	
Change becomes effective	after: POWER ON	Protection level: 3/4		Units: –	
Data type: BYTE		Valid as of software version ShopTurn 6.1			
Significance:	This MD is used to stipulate the loading point at which the magazine and the spindle are loaded and unloaded. (The magazine and the spindle are always loaded/unloaded at the same loading point.) 1 = Loading point 1 2 = Loading point 2				

9674 MD number	\$MM_CMM Display of r	\$MM_CMM_ENABLE_TOOL_MAGAZINE Display of magazine list				
Default setting: 1		Min. input limit: 0 Max. input limit: 1				
Change becomes effective after: POWER ON Protection level: 3/4 Units: –					Units: –	
Data type: BYTE				Valid as of s ShopTurn 6.	oftware version 1	
Significance:	gnificance: 0 = Magazine list is not displayed 1 = Magazine list is displayed					

9675	\$MM_CMM	\$MM_CMM_CUSTOMER_START_PICTURE				
MD number	Customized	Customized boot screen				
Default setting: 0		Min. input limit: 0			mit: 1	
Change becomes effective after: IMMEDIATELY Protection level: 3/4					Units: –	
Data type: BYTE			Valid as of software version			
				ShopTurn 6.	1	
Significance:	The custom	zed boot scre	een is activated as follows:			
	0 = Siemens boot screen					
	1 = Custom	1 = Customized boot screen				

9676	\$MM_CMM_DIRECTORY_SOFTKEY_PATH1				
MD number	Path for dri	Path for drive names in directory management			
Default setting: -		Min. input limit: – Max. in			mit: –
Change becomes effective after: POWER ON Protection level: 3/4			Protection level: 3/4		Units: –
Data type: STRING (80 characters)				Valid as of software version	
				ShopTurn 6.	.1
Significance:	This MD is used to stipulate the path for the drive name of the 2nd softkey (horizontal bar)				
	in directory management with hard disk network link. If a blank string is entered in the dis-				
	play machin	play machine data this softkey is not displayed.			

9677	\$MM_CMM_DIRECTORY_SOFTKEY_PATH2				
MD number	Path for drive names	Path for drive names in directory management			
Default setting: -	Min. input limit: – Max. input limit: –			mit: –	
Change becomes effective	nge becomes effective after: POWER ON Protection level: 3/4			Units: –	
Data type: STRING (80 characters)			Valid as of software version		
			ShopTurn 6	.1	
Significance:	This MD is used to stip	ulate the path for the drive n	ame of the 3rd	softkey (horizontal bar) in	
	directory management with hard disk network link. If a blank string is entered in the display machine data this softkey is not displayed.				

9678	\$MM_CMM_DIRECTORY_SOFTKEY_PATH3					
MD number	Path for dri	Path for drive names in directory management				
Default setting: -		Min. input limit: –			mit: –	
Change becomes effective after: POWER ON		Protection level: 3/4		Units: –		
Data type: STRING (80 cha	racters)		•	Valid as of software version		
				ShopTurn 6.1		
Significance:	This MD is u	ised to stipula	ate the path for the drive na	me of the 4th	softkey (horizontal bar) in	
	directory management with hard disk network link. If a blank string is entered in the display					
	machine dat	machine data this softkey is not displayed.				

9679 MD number	\$MM_CMM_DIRECTORY_SOFTKEY_PATH4 Path for drive names in directory management					
Default setting: -		Min. input limit: –			mit: –	
Change becomes effective after: POWER ON P		Protection level: 3/4		Units: –		
Data type: STRING (80 characters)				Valid as of software version ShopTurn 6.1		
Significance:	This MD is used to stipulate the path for the drive name of the 5th softkey (horizontal bar) in directory management with hard disk network link. If a blank string is entered in the display machine data this softkey is not displayed.					

9680 MD number	\$MM_CMM_M_CODE_COOLANT_I M function coolant I					
Default setting: 8		Min. input limit: 0			mit: 32767	
Change becomes effective after: IMMEDIATELY Protection level: 3/4					Units: –	
Data type: WORD				Valid as of s ShopTurn 6.	oftware version 2	
Significance:	This MD is used to stipulate the M function for coolant I; this is output when the tool is changed.					

9681	\$MM_CMM	MM_CMM_M_CODE_COOLANT_II					
MD number	M function	coolant II					
Default setting: 7	Min. input limit: 0			Max. input limit: 32767			
Change becomes effective after: IMMEDIATELY Protection level: 3/4					Units: –		
Data type: WORD				Valid as of software version			
ShopTurn 6.2					.2		
Significance:	This MD is used to stipulate the M function for coolant II; this is output when the tool is						
	changed.						

9686 MD number	\$MM_CMM_M_CODE_COOLANT_OFF M function for coolant OFF					
Default setting: 9		Min. input limit: 0			Max. input limit: 32767	
Change becomes effective after: IMMEDIATELY Protection level: 3/4					Units: –	
Data type: LONG			1	Valid as of software version		
				ShopTurn 6.	3	
Significance:	This MD is used to stipulate the M function for switching the coolant OFF; this is output when the tool is changed.					

9687	\$MM_CMM_TOOL_MOVE_DEFAULT_MAG					
ND number	Reload tool	In default m	agazine			
Default setting: 0	t setting: 0 Min. input limit: 0			Max. input limit: 30		
Change becomes effective after: POWER ON P			Protection level: 3/4		Units: –	
Data type: BYTE				Valid as of software version		
Sh					4	
Significance:	This MD is used to stipulate the magazine in which ShopTurn first searches for an empty location when reloading a tool.					

9718 MD number	\$MM_CMM_OPTION_MASK_2 Settings for ShopTurn					
Default setting: 2	Min. input	imit: 0000	Max. input I	imit: FFFF		
Change becomes effective	after: IMMEDIATELY	Protection level: 1		Units: Hex		
Data type: LONG			Valid as of software version ShopTurn 7.1			
Significance:	Bit 0: Do not jump to Automatic mode when an external program (from the PLC) is selected for execution. Bit 1: Influence simulation speed by feed override Bit 2: Do not display the basic offset in the measuring and program mask and cannot be entered. Bit 3 to bit 6: Reserved Bit7: Deactivate the function approaching and departing along the software limit switches for the swivel heads. Bits 8 to 12: Reserved					

1								
9719	\$MM_CMM_	\$MM_CMM_OPTION_MASK						
MD number	Settings for ShopTurn							
Default setting: H5		Min. input lir	nit: 0000	Max. input limit: FFFF				
Change becomes effective	after: IMMEDIA	ATELY	Protection level: 1	Units: Hex				
Data type: LONG				Valid as of software version ShopTurn 7.1				
Significance:	Bit 0 to bit 8: Bit 9: Start pr Bit 10 to bit 1 Bit 18: When ShopTurn use Bit 19: Instea Bit 20: Displa Bit 21: Enable Bit 22 to bit 2: Bit 26: Enable Bit 27: Enable Bit 28 to bit 3: Bit 31: Alway handed coord	Reserved ogram exect 7: Reserved switching fro er interface. d of "MCS" a y work offse e basic recon 5: Reserved e directory "F e directory "S 0: Reserved s display coo dinates syste	ution in all screens. om manual/MDI/Auto, cha and "WCS" display texts "I ts not as "ZO1", but as "G rd display. Part programs" in program Subroutines" in program m ordinates system for G17 em) or down (left–handed	nge the operating mode but not the Machine" and "Workpiece". 54" (except in the work offset list). manager. anager. as follows: X to right, Y up (right– coordinates system).				

9724 MD number	\$MM_CMM_CIRCLE_RAPID_FEED Rapid feed for positioning on circular path				
Default setting: 5000	Min. input li	mit: 0	Max. input limit: 100000		
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: mm/min	
Data type: DOUBLE				Valid as of software version ShopTurn 6.1	
Significance:	This MD is used to stipulate the rapid feed rate in mm/min for positioning on a circular path. This applies for the functions "full circle"/"pitch circle" ("Drilling" menu \rightarrow "Positions") and "circumferential groove" ("Milling" menu \rightarrow "Groove").				

9725 MD number	\$MM_CMM_ENABLE_QUICK_M_CODES Enable fast M functions					
Default setting: 0		Min. input lir	nit: –	Max. input lii	mit: —	
Change becomes effective a	after: IMMEDI	ATELY	Protection level: 3/4		Units: –	
Data type: BYTE		Valid as of software version ShopTurn 6.4				
Significance:	This MD is u by the PLC v Bit 0: Coolar Bit 1: Coolar Bit 2: Coolar Bit 3: Coolar	ised to enable without confirm ht 1 ON ht 2 ON ht 1 and 2 ON ht OFF	e fast M functions. This mea mation. I	ans that the M	I functions are executed	

9729 MD number	\$MM_CMM_G_CODE_TOOL_CHANGE_PROG Program name for tool change in the G code					
Default setting: -	Min. inpu	Min. input limit: – Max. input limit: –				
Change becomes effective a	Change becomes effective after: IMMEDIATELY Protection level: 3/4			Units: –		
Data type: STRING (24)			Valid as of software version ShopTurn 7.1			
Significance:	This MD is used to stipulate the program name for the tool change program. The tool change program is automatically called as soon as you have programmed a tool in the G code via softkey.					

9777	\$MM_CMM	ENABLE_T	IME_DISPLAY				
MD number	Enable the	Enable the time display					
Default setting: 0x7F		Min. input lir	nit: –	Max. input li	mit: –		
Change becomes effective a	after: IMMED	ATELY	Protection level: 3/4		Units: –		
Data type: BYTE				Valid as of s	oftware version		
				ShopTurn 7.	1		
Significance:	This MD is u	used to define	the display of the runtimes	S.			
	Bit 0: Progra	am progress c	lisplay				
	Bit 1: Displa	y time					
	Bit 2: Displa	y date					
	Bit 3: Displa	y machine rui	ntime				
	Bit 4: Display processing time						
	Bit 5: Display utilization						
	Bit 6: Displa	y program rep	peats				

Note

For a description of the display machine data for the measuring cycle, please refer to section 9.1.2 "Display machine data for measuring cycle".

9802 MD number	\$MM_ST_INDEX_AXIS_C_SUB Axis index for separate C axis of counterspindle					
Default setting: 0		Min. input limit: 0			imit: 127	
Change becomes effective after: IMMEDIATELY Protection level: 3/4					Units: –	
Data type: BYTE Valid as of software version ShopTurn 6.4					oftware version .4	
Significance:	This MD is u	his MD is used to enter the axis number of the additional counterspindle.				

9803	\$MM_ST_IN	NDEX_AXIS_	4			
MD number	Axis index	for 4th axis				
Default setting: 5		Min. input limit: 0 Max. input limit: 127				
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: –	
Data type: UBYTE	Data type: UBYTE			Valid as of software version		
ShopTurn 6.1					.1	
Significance:	This MD is used to enter the axis number of the 4th axis (special axis) you want to display.					
	This can be, for example, the axis you are using to drive the counter-spindle. The axis					
	index of the	Y axis is not a	entered here.			

9804 MD number	\$MM_ST_INDEX_SPINDLE_MAIN Axis index for main spindle					
Default setting: 3	Min. input limit: 0 Max. input limit: 127					
Change becomes effective after: IMMEDIATELY Protection level: 3/4					Units: –	
Data type: UBYTE			·	Valid as of s	oftware version	
ShopTurn 6.1					.1	
Significance:	This MD is u	his MD is used to enter the axis number of the main spindle.				

9805 MD number	\$MM_ST_INDEX_SPINDLE_TOOL Axis index for tool spindle					
Default setting: 4	Min. input limit: 0			Max. input limit: 127		
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: –	
Data type: UBYTE				Valid as of software version		
ShopTurn 6.1					.1	
Significance:	This MD is u	used to enter t	the axis number of the too	l spindle.		

9806 MD number	\$MM_ST_INDEX_SPINDLE_SUB Axis index for counter-spindle					
Default setting: 6	Min. input I	imit: 0	Max. input limit: 127			
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –		
Data type: UBYTE			Valid as of software version			
	ShopTurn 6	.1				
Significance:	This MD is used to enter	his MD is used to enter the axis number of the counter-spindle.				

9807 MD number	\$MM_ST_INDEX_AXIS_C Axis index for C axis					
Default setting: 3	Min. input li	mit: 0	Max. input limit: 127			
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: –		
Data type: UBYTE		Valid as of software version				
ShopTurn 6.1						
Significance:	This MD is used to enter	This MD is used to enter the axis number of the C axis.				

9808 MD number	\$MM_ST_INDEX_AXIS_B Axis index for B axis					
Default setting: 0		Min. input limit: 0 Max. input limit: 127				
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –		
Data type: BYTE			Valid as of s ShopTurn 7.	oftware version 2		
Significance:	This MD is used to enter the axis number of the B axis. This is necessary for aligning tools or machining inclined surfaces.					

9810	\$MM_ST_GEAR_STEPS_SPINDLE_MAIN					
MD number	Number of	Number of gears on main spindle				
Default setting: 0		Min. input limit: 0 Max. input limit: 5				
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –		
Data type: UBYTE				Valid as of software version		
ShopTurn 6.1					.1	
Significance:	This MD is u	This MD is used to stipulate the number of gear stages for the main spindle.				

9811 MD number	\$MM_ST_GEAR_STEPS_SPINDLE_TOOL Number of gears on tool spindle					
Default setting: 0		Min. input limit: 0			imit: 5	
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: –	
Data type: UBYTE				Valid as of software version		
				ShopTurn 6	.1	
Significance:	This MD is u	This MD is used to stipulate the number of gear stages for the tool spindle.				

9812 MD number	\$MM_ST_GEAR_STEPS_SPINDLE_SUB Number of gears on counter–spindle					
Default setting: 0	Min. input	limit: 0	Max. input limit: 5			
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –		
Data type: UBYTE				Valid as of software version		
ShopTurn 6.1						
Significance:	This MD is used to stipu	This MD is used to stipulate the number of gear stages for the counter-spindle.				

9820 MD number	\$MM_ST_MAGN_GLASS_POS_1 Position of magnifying glass for measuring tool, 1st axis					
Default setting: 0		Min. input limit: –			mit: –	
Change becomes effective after: IMMEDIATELY Protection level: 3/4					Units: mm	
Data type: DOUBLE				Valid as of software version		
ShopTurn 6.1				.1		
Significance:	This MD is u	his MD is used to enter the X coordinate of the zoom-in function.				

9821 MD number	\$MM_ST_MAGN_GLASS_POS2 Position of magnifying glass for measuring tool, 2nd axis					
Default setting: 0	1	Min. input limit: –			mit: –	
Change becomes effective a	after: IMMEDIA	TELY	Protection level: 3/4		Units: mm	
Data type: DOUBLE				Valid as of s	oftware version	
ShopTurn 6.1					1	
Significance:	This MD is us	ed to enter t	he Z coordinate of the zoo	m-in function.		

9822 MD number	\$MM_ST_DI Displayed di	SPL_DIR_N	AIN_SPIND_M3 rotation for main spindle v	with M3	
Default setting: 0		Min. input lii	mit: 0	Max. input li	mit: 1
Change becomes effective a	after: IMMEDIA	ATELY	Protection level: 3/4		Units: –
Data type: BYTE				Valid as of s ShopTurn 6.	oftware version 1
Significance:	This MD is us M function M looking from 1 0 = Clockwise 1 = Counterc For more info	sed to stipula 3 in the oper the inside ou e lockwise prmation plea	ate which direction of rotation rator interface. The settings ut. ase refer to the section on "	on of the main for the directi Spindle contro	spindle is displayed for on of rotation are as seen ol".

9823	\$MM_ST_DISPL_DIR_SUB_SPIND_M3				
MD number	Displayed direction of r	otation for counter-spind	lle with M3		
Default setting: 0	Min. input li	mit: 0	Max. input li	mit: 1	
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: –	
Data type: BYTE Valid as of software version ShopTurn 6.1					
Significance:	This MD is used to stipula for M function M3 in the c seen looking from the ins 0 = Clockwise 1 = Counterclockwise For more information plea	ate which direction of rotation operator interface. The settini ide out. ase refer to the section on "	on of the coun ngs for the dir Spindle contro	ter-spindle is displayed ection of rotation are as pl".	

9824	\$MM_ST_DISPL_DIR_MAIN_C_AX_INV					
MD number	Displayed direction	of rotation for C axis main	spindle with M	13		
Default setting: 0	Min. inp	ut limit: 0	Max. input li	mit: 1		
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: –		
Data type: BYTE			Valid as of s	oftware version		
			ShopTurn 6	.1		
Significance:	This MD is used to st	ipulate which direction of rota	tion of the C ax	tis (main spindle) is dis-		
	played for M function	M3 in the operator interface.	The settings m	ust be made according to		
	the actual direction of	rotation of the C axis on the	machine.			
	The settings for the d	irection of rotation are as look	king from the ins	side out.		
	0 = Clockwise					
	1 = Counterclockwise	9				
	For more information	please refer to the section or	"Spindle contro	ol".		

9825	\$MM_ST_DISPL_DIR_SUB_C_AX_INV						
MD number	Displayed direction	on of rot	tation for C axis count	er–spindle wit	h M3		
Default setting: 0	Min. i	nput limi	t: 0	Max. input li	mit: 1		
Change becomes effective a	after: IMMEDIATELY	(I	Protection level: 3/4		Units: –		
Data type: BYTE					Valid as of software version		
				ShopTurn 6	.1		
Significance:	This MD is used to	stipulate	e which direction of rotat	ion of the C ax	is (counter–spindle) is		
	displayed for M fun	nction M3	3 in the operator interfac	e. The settings	must be made according		
	to the actual directi	ion of rot	ation of the C axis on th	e machine.			
	The settings for the	e directio	n of rotation are as look	ing from the ins	side out.		
	0 = Counterclockw	rise					
	1 = Clockwise						
	For more information	on pleas	e refer to the section on	"Spindle contro	ol".		

9826	\$MM_ST_D	\$MM_ST_DEFAULT_DIR_TURN_TOOLS				
MD number	Main direct	on of rotatio	on for all turning tools			
Default setting: 3		Min. input lir	nit: 3	Max. input li	mit: 4	
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –		
Data type: BYTE				Valid as of software version		
				ShopTurn 6	.1	
Significance:	This MD is u	This MD is used to stipulate the main direction of rotation for all turning tools.				
	3 = M3					
	4 = M4					

9827	\$MM_ST_DEFAULT_MACHINING_SENSE				
MD number	Basic settings for mach	nining direction – milling			
Default setting: 0	Min. input li	mit: 0	Max. input l	imit: 1	
Change becomes effective	after: IMMEDIATELY	Protection level: 3/4		Units: –	
Data type: BYTE			Valid as of software version		
			ShopTurn 6	.1	
Significance:	This MD is used to stipula	ate the basic setting for the	direction of m	nachining rotation when	
	milling, except for track m	nilling.			
	0 = Reverse				
	1 = Synchronous				
	The basic setting only ha	s an effect in the case of n	ewly created p	programs.	

9829	\$MM ST SPINDLE CHUCK TYPES					
MD number	Type of spir	Type of spindle chuck				
Default setting: 0		Min. input lii	mit: –	Max. input li	mit: –	
Change becomes effective a	after: IMMEDI	ATELY	Protection level: 3/4		Units: –	
Data type: BYTE				Valid as of s ShopTurn 6	oftware version .4	
Significance:	This MD is u then acts au Bit 0 = 0: Co Bit 0 = 1: Co Or, alternativ "Spindles" in the paramet	used to stipula tomatically as punter-spindle punter-spindle vely, you can h the "Jaw typ er and vice v	ate which edge is measure s reference point when mo e without jaw dimensions (e with jaw dimensions (dim make these settings in the be" parameter. Changes to ersa.	d for the count ving the count dimensions of ensions of sto "Tools zero o the MD are au	ter-spindle. This edge er-spindle. front edge) p edge) ffset" menu \rightarrow ">" \rightarrow itomatically transferred to	

9830	\$MM_ST_SPINDLE_PARA_ZLO				
MD number	Chuck dime	nsion for ma	ain spindle		
Default setting: 0		Min. input lir	nit: –	Max. input li	nit: –
Change becomes effective a	after: IMMEDI	ATELY	Protection level: 3/4		Units: mm
Data type: DOUBLE Valid as of software version ShopTurn 6.4					oftware version 4
Significance:	This MD is us mensions are manual tool r Or, alternativ "Spindles" in rameter and	sed to stipula e required wh measuremen ely, you can parameter "2 vice versa.	ate the chuck dimension ZL nen you use the chuck of th t. make these settings in the ZL0". Changes to the MD a	0 of the main le main spindl "Tools zero of re automatica	spindle. The chuck di- e as reference point for fset" menu \rightarrow ">" \rightarrow lly transferred to the pa-

9831	\$MM_ST_S	PINDLE_PAF	RA_ZL1		
MD number	Chuck dime	ension for co	ounter-spindle		
Default setting: 0		Min. input lir	nit: —	Max. input li	mit: —
Change becomes effective	after: IMMEDI	ATELY	Protection level: 3/4		Units: mm
Data type: DOUBLE				Valid as of s	oftware version
				ShopTurn 6.	4
Significance:	This MD is u	ised to stipula	ate the chuck dimension ZL	1 of the count	ter-spindle. The chuck
	dimensions	are required v	when you use the chuck of	the counter-s	pindle as reference point
	for manual to	ool measuren	nent. You also need the chu	uck dimension	is for determining the
	reference po	pint when mov	/ing the counter-spindle (se	ee MD 9829	
	\$MM_ST_S	PINDLE_CH	UCK_TYPES).		
	Or, alternatively, you can make these settings in the "Tools zero offset" menu $ ightarrow$ ">" $ ightarrow$				
	"Spindles" in	ı parameter "Z	ZL1". Changes to the MD a	re automatica	lly transferred to the pa-
	rameter and	vice versa.			

9832	\$MM_ST_SPINDLE_PARA_ZL2				
MD number	Stop dimensio	on for cou	nter–spindle		
Default setting: 0	M	/lin. input lin	nit: –	Max. input li	mit: –
Change becomes effective a	after: IMMEDIAT	TELY	Protection level: 3/4		Units: mm
Data type: DOUBLE Valid as of software version ShopTurn 6.4					oftware version 4
Significance:	This MD is user stop dimension MD 9829 \$MM Or, alternatively "Spindles" in par rameter and vice	ed to stipula ns for detern I_ST_SPIN y, you can n arameter "Z ce versa.	te the stop dimension ZL2 mining the reference point of DLE_CHUCK_TYPES). make these settings in the ZL2". Changes to the MD a	of the counter when moving "Tools zero of re automatica	r–spindle. You need the the counter–spindle (see ffset" menu → ">" → Ily transferred to the pa-

9833	\$MM_ST_SPINDLE_PARA_ZL3				
MD number	Jaw dimension for cou	nter-spindle			
Default setting: 0	Min. input li	mit: –	Max. input li	mit: —	
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: mm	
Data type: DOUBLE			Valid as of s	oftware version	
			ShopTurn 6.	4	
Significance:	This MD is used to stipul jaw dimensions for detern MD 9829 \$MM_ST_SPIN Or, alternatively, you can "Spindles" in parameter " rameter and vice versa.	ate the jaw dimension ZL3 mining the reference point NDLE_CHUCK_TYPES). make these settings in the ZL3". Changes to the MD	of the counter- when moving t e "Tools zero of are automatica	-spindle. You need the he counter–spindle (see fset" menu → ">" → Ily transferred to the pa-	

9836 MD number	\$MM_ST_TAILSTOCK_DIAM Tailstock diameter					
Default setting: 0		Min. input limit: – Max. input limit: –				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: mm				Units: mm		
Data type: DOUBLE				Valid as of s ShopTurn 7.	oftware version .1	
Significance:	This MD is used to stipulate the diameter of the tail stock. The tail stock diameter is needed for the purposes of displaying the tail stock in simulation.					

9837	\$MM_ST_T	\$MM_ST_TAILSTOCK_LENGTH				
MD number	Tailstock le	Tailstock length				
Default setting: 0	Min. input limit: – Max. input limit: –				mit: –	
Change becomes effective after: IMMEDIATELY Protection level:			Protection level: 3/4		Units: mm	
Data type: DOUBLE				Valid as of software version		
ShopTurn 7.1					1	
Significance:	This MD is u the purpose	This MD is used to stipulate the length of the tail stock. The tail stock length is needed for the purposes of displaying the tail stock in simulation.				

9838	\$MM_ST_BORDER_TOOL_LEN_X_REV_2					
MD number	Limit value of tool lengt	th X for the 2nd tool carr	ier			
Default setting: 0	Min. input li	Min. input limit: – Max. input limit: –				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: mm						
Data type: DOUBLE			Valid as of software version			
			ShopTurn 7.1			
Significance:	This MD is used to specif	fy the limit value of tool ler	igth X for the 2	nd tool carrier.		
	MD 9838 = 0; Only one tool carrier is available					
	X < MD 9838; Tool belongs to tool carrier 1					
	$X \ge MD$ 9838; Tool belong	gs to tool carrier 2				

9840	\$MM_ST_ENABLE_MAGN_GLASS					
MD number	Magnifying g	lass functio	on in manual: Measuring	a tool		
Default setting: 0		Min. input limit: 0 Max. input limit: 1				
Change becomes effective after: IMMEDIATELY Protection leve			Protection level: 3/4		Units: –	
Data type: BYTE				Valid as of software version		
				ShopTurn 6	.1	
Significance:	This MD can I	This MD can be used to activate the "Measure tool with zoom-in" function.				
	0 = Function r	0 = Function not available				
	1 = Function a	available				

9841	\$MM_ST_E	\$MM_ST_ENABLE_PART_OFF_RECEPT				
MD number	Enable rece	eptacle funct	tion for cut–off			
Default setting: 0		Min. input limit: 0 Max. input limit: 1				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: -					Units: –	
Data type: BYTE				Valid as of s	oftware version	
				ShopTurn 6	.1	
Significance:	This MD car	n be used, if y	ou have implemented the	"Receptacle for	or cut-off" function via	
	machine ma	nufacturer cy	cle ST_CUST.SPF, to activ	vate the "Part	gripper" parameter in the	
	"Part cut–off" mask.					
	0 = "Part gripper" parameter is not displayed.					
	1 = "Part gri	oper" parame	eter is displayed.			

9842 MD number	\$MM_ST_ENABLE_TAILSTOCK Enable tail stock				
Default setting: 0	Min. input li	mit: 0	Max. input li	mit: 1	
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: –	
Data type: BYTE			Valid as of s ShopTurn 6	oftware version 1	
Significance:	This MD is used to activate the "tail stock" parameter in the program header mask. 0 = "Tail stock" parameter is not displayed 1 = "Tail stock" parameter is displayed				

9843	\$MM_ST_ENABLE_SPINDLE_CLAMPING					
MD number	Enable spindle clampin	ig (C axis)				
Default setting: 0	Min. input li	mit: 0	Max. input li	mit: 1		
Change becomes effective	after: IMMEDIATELY	Protection level: 3/4		Units: –		
Data type: WORD	oftware version					
			ShopTurn 6	4		
Significance:	This MD can be used, if y machine manufacturer cy rameter in the drilling and	/ou have implemented the ' /cle ST_CUST.SPF, to activ I milling masks.	Clamp/unclar ate the "Clam	np spindle" function via p/unclamp spindle" pa-		
	0 = "Clamp/unclamp spindle" parameter is not displayed in the drilling and milling masks. ShopTurn automatically clamps the spindle when machining if clamping is useful for the current application.					
	1 = "Clamp/unclamp spindle" parameter is displayed in the drilling and milling masks. The operator decides for which machining the spindle should be clamped.					

9849 MD number	\$MM_ST_CYCLE_SUB_SP_PARK_POS_Y Parking position of Y axis with counterspindle					
Default setting: 0		Min. input limit: – Max. input limit: –				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units:					Units: mm	
Data type: DOUBLE				Valid as of s	oftware version	
				ShopTurn 7.	2	
Significance:	This MD is u tion for the c	This MD is used to specify the Y position in the MCS when approaching the parking posi- tion for the counterspindle cycle.				

9850	\$MM_ST_C	\$MM_ST_CYCLE_THREAD_RETURN_DIST				
MD number	Return dist	ance for thre	ad turning			
Default setting: 2	Min. input limit: 0 Max. input limit: 1000					
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: mm					Units: mm	
Data type: DOUBLE				Valid as of software version		
				ShopTurn 6.	1	
Significance:	This MD is used to stipulate the distance from the workpiece by which the tool is retracted					
	between infeeds for thread cutting.					

9851 MD number	SMM_ST_CYCLE_SUB_SP_WORK_POS Retraction position Z for counter-spindle					
Default setting: 0		Min. input limit: – Max. input limit: –				
Change becomes effective a	e after: IMMEDIATELY Protection level: 3/4				Units: mm	
Data type: DOUBLE				Valid as of software version ShopTurn 6.1		
Significance:	This MD is u travels at pro -1: Suppres	This MD is used to stipulate the position in the Z direction to which the counter–spindle travels at program start. –1: Suppress retraction of counter–spindle				

9852 MD number	\$MM_ST_CYCLE_SUB_SP_DIST Distance as of which feed rate is used when approaching fixed stop with counter- spindle					
Default setting: 10	Min. input limit: 0.001 Max. input limit: 1000					
Change becomes effective after: IMMEDIATELY Protection level: 3/4				L	Units: mm	
Data type: DOUBLE			·	Valid as of s ShopTurn 6	software version 5.1	
Significance:	This MD is used to stipulate the distance from the programmed target position as of which the counter–spindle travels with a special feed rate when approaching the fixed stop. You define the feed rate in MD 9853 \$MM_ST_CYCLE_SUB_SP_FEED.					

9853	\$MM_ST_CYCLE_SUB_SP_FEED					
MD number	Feed rate for	or traveling t	o fixed stop with counter	-spindle		
Default setting: 0		Min. input limit: – Max. input limit: –				
Change becomes effective a	e after: IMMEDIATELY Protection level: 3/4				Units: mm/min	
Data type: DOUBLE				Valid as of software version		
				ShopTurn 6	.1	
Significance:	This MD is u	used to stipula	ate the feed rate with which	the counter-	spindle travels to the fixed	
	stop. You define the distance as of which the axis travels at this feed rate in MD 9852					
	\$MM_ST_C	YCLE_SUB_	SP_DIST			

9854	\$MM_ST_C	\$MM_ST_CYCLE_SUB_SP_FORCE				
MD number	Force in pe	Force in percent for traveling to fixed stop, counter-spindle				
Default setting: 10		Min. input limit: 1 Max. input limit: 100				
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: %						
Data type: DOUBLE		Valid as of software version				
				ShopTurn 6.	1	
Significance:	This MD is used to stipulate the percentage of the driving force with which the counter- spindle should stop when traveling to the fixed stop.					

9855	\$MM_ST_CYCLE	_TAP_	SETTINGS				
MD number	Settings for rigid tapping						
Default setting: 0	Min. i	input lir	nit: –	Max. input I	imit: –		
Change becomes effective a	after: IMMEDIATEL	Y	Protection level: 3/4		Units: –		
Data type: WORD				Valid as of s ShopTurn 6	software version 3.3		
Significance:	Units digit: Exact re	espons	e				
	0: Exact stop resp	oonse a	ctive as before cycle ca	II			
	1: Exact stop G60)1					
	2: Exact stop G60)2					
	3: Exact stop G60)3					
	lens digit: Feed-to	orward	control	6			
	0: With/without fee	ed-forw	ard control active as be	fore cycle call			
	1: With feed-forwa	ard con					
	2: Without feed-to	orward					
			IUII active on hefere evelo er	.11			
	1: With jork limiting		r	ui			
	2: Without jerk lim	y SOL I					
	2: Without Jerk Imiting BRISK 2: Poducod accoloration DPIVE						
	3. neuloceu acceleration DRIVE						
	0. For MCALL Res	activate	spindle operation				
	1: For MCALL rem	nain in i	position control				

9856	\$MM_ST_CYCLE_TAP_	MID_SETTINGS		
MD number	Settings for center tapp	ing		
Default setting: 0	Min. input lin	nit: –	Max. input li	mit: –
Change becomes effective a	after: IMMEDIATELY	Protection level: 3/4		Units: –
Data type: WORD			Valid as of s ShopTurn 6	oftware version .3
Significance:	Units digit: Exact respons 0: Exact stop response a 1: Exact stop G601 2: Exact stop G602 3: Exact stop G603 Tens digit: Feed-forward 0: With/without feed-forward 1: With feed-forward of Hundreds digit: Accelerati 0: SOFT/BRISK/DRIVE a 1: With jerk limiting SOFT 2: Without jerk limiting BF 3: Reduced acceleration Thousands digit: MCALL 0: For MCALL Reactivate 1: For MCALL remain in	e active as before cycle call control vard control active as befor itrol FFWON control FFWOF ion active as before cycle call T RISK DRIVE e spindle operation position control	e cycle call	

9857 MD number	\$MM_ST_CYCLE_RET_DIST_FIXEDSTOP Retraction distance before clamping after traveling to fixed stop				
Default setting: 0	Min. input	imit: 0	Max. input li	mit: 10	
Change becomes effective after: IMMEDIATELY Protection level: 3/4				Units: mm	
Data type: DOUBLE	Valid as of software version ShopTurn 6.3				
Significance:	This MD is used to stipulate the retraction distance that the counter-spindle is to travel between traveling to fixed stop and gripping in order to eliminate compressive stress in the workpiece.				

9858	\$MM_ST_CYCLE_RET_DIST_PART_OFF						
MD number	Retraction	distance befo	ore cut–off with counter-	-spindle			
Default setting: 0		Min. input lir	nit: 0	Max. input li	mit: 1		
Change becomes effective after: IMMEDIATELY Protection level: 3/4			Protection level: 3/4		Units: mm		
Data type: DOUBLE				Valid as of software version			
				ShopTurn 6	.3		
Significance:	This MD is u	ised to stipula	ate the retraction distance	that the counte	er–spindle is to travel		
	before cut-c	before cut-off in order to exert tensile stress on the workpiece. This relieves pressure on					
	the tool whe	n cutting off.					

9859	\$MM_ST_C	\$MM_ST_CYCLE_PART_OFF_CTRL_DIST				
MD number	Distance fo	r cut–off che	eck			
Default setting: 0.1		Min. input lir	nit: 0	Max. input li	mit: 10	
Change becomes effective a	after: IMMEDI	ATELY	Protection level: 3/4		Units: mm	
Data type: DOUBLE				Valid as of software version		
				ShopTurn 6	.3	
Significance:	This MD is u	ised to stipula	ate the distance that the co	unter-spindle	is to travel after cut-off in	
	order to perf	orm a cut–off	f check. The cut-off check	employs the "	travel to fixed stop" func-	
	tion. The cut-off is successful if travel to fixed stop fails.					
	0 = Do not c	arry out cut-	off check			
Corresponding to	MD 9860 \$N	M_ST_CYC	LE_PART_OFF_CTRL_FE	ED		

9860	\$MM_ST_CYCLE_PART_OFF_CTRL_FEED					
MD number	Feed for cu	t–off check				
Default setting: 0		Min. input lir	nit: —	Max. input li	mit: –	
Change becomes effective a	after: IMMEDI	ATELY	Protection level: 3/4		Units: mm/min	
Data type: DOUBLE				Valid as of software version ShopTurn 6.3		
Significance:	This MD is u in order to p function. The 0 = Do not c	This MD is used to stipulate the feed with which the counter-spindle is to travel after cut-off in order to perform a cut-off check. The cut-off check employs the "travel to fixed stop" function. The cut-off is successful if travel to fixed stop fails. 0 = Do not carry out cut-off check				
Corresponding to	MD 9859 \$N	IM_ST_CYCI	LE_PART_OFF_CTRL_DI	ST		

9861	\$MM_ST_C	YCLE_PART	_OFF_CTRL_FORC		
MD number	Force in pe	rcent for cut	–off check		
Default setting: 10		Min. input lir	nit: 1	Max. input li	mit: 100
Change becomes effective after: IMMEDIATELY F			Protection level: 3/4		Units: %
Data type: BYTE				Valid as of software version	
				Shop full o	.5
Significance:	This MD is u	used to stipula	ate the percentage of the d	riving force wi	th which the cut–off check
	is to be performed after cut-off. The cut-off check employs the "travel to fixed stop" func-				
	tion. The cu	t-off is succes	sstul it travel to fixed stop fa	ails.	

9862 MD number	\$MM_ST_CYC_DRILL_MID_MAX_ECCENT Maximum center offset for center drilling				
Default setting: 0.5	g: 0.5 Min. input limit: 0.0			Max. input limit: 10.0	
Change becomes effective a	Protection level: 3/4		Units: mm		
Data type: DOUBLE				Valid as of software version ShopTurn 6.4	
Significance:	This MD is u	ised to stipula	ate the maximum center of	fset for "cente	r drilling".

0	1/	2	0	0	8
-	• /	_	-	-	-

9863	\$MM_ST_MAX_INP_AREA_GAMMA				
MD number	Maximum input area for	r gamma alignment angle			
Default setting: 5	Min. input li	mit: 0	Max. input li	mit: 90	
Change becomes effective after: IMMEDIATELY Protection level: 3/4 Units: –					
Data type: DOUBLE			Valid as of software version		
			ShopTurn 7	2	
Significance:	This MD is used to specify the maximum input area for the gamma alignment angle.				
	The value acts as a +/- a	rea for the angle values 0°	and 180°.		

9897 MD number	\$MM_ST_OPTION_MASK_MAN_FUNC Settings for ShopTurn manual functions					
Default setting: 8	Ū	Min. input lir	nit: –	Max. input li	imit: –	
Change becomes effective a	after: IMMEDI	ATELY	Protection level: 3/4		Units: –	
Data type: LONG					Valid as of software version ShopTurn 7.1	
Significance:	Bit 0 = 0: Co Bit 0 = 1: Co Bit 1 = 0: Co Bit 1 = 1: Co Bit 2: Resen Bit 3 = 0: Ma Bit 3 = 1: Ma	ntrol of main ntrol of main ntrol of tool s ntrol of tool s /ed nual taper tu nual taper tu	spindle via machine contro spindle via operator interfa pindle via machine control pindle via operator interfac rning hidden rning displayed	bl panel ace panel ce		

0000	ANNA OT O							
9898								
MD number	Settings for	Settings for ShopTurn						
Default setting: H7000		Min. input lii	mit: 0000	Max. input I	imit: FFFF_FFFF			
Change becomes effective a	after: IMMED	ATELY	Protection level: 1		Units: Hex			
Data type: LONG				Valid as of s	software version			
				ShopTurn 7	.5			
Significance:	Bit 0 = 1: En	able machini	ng "internal/rear" in screens	that define t	he machining level them-			
	selves.		-		-			
	Bit 1 to bit 5	Reserved						
	Bit 6 = 1: All	ow simultane	ous recording despite prog	ram start.				
	Bit 7 and bit	8: Reserved						
	Bit 9 = 1: Dis	sable entering	g an offset in X in the zero o	offset list.				
	Bit 10 = 1: D	isplay progra	m view under simultaneous	s recording.				
	Bit 11 = 0: A	fter reset, ret	ain currently active zero off	set.				
	Bit 11 = 1 ar	nd MD 20152	[7] = 0: After reset, the zero	offset which	is entered in menu "T, S,			
	M" remains	effective.						
	Bit 12 = 1: E	nable "Plung	e-turning" and "Plunge-tur	ning residual	material" functions.			
	Bit 13 = 1: E	nable "Plung	e–cutting" and "Plunge–cut	ting residual ı	material" functions.			
	Bit 14 = 1: A	llow negative	final machining allowance	for contour tu	urning.			
	Bit 15 = 1: C	ounterspindle	e: Allow internal/external cla	amping.				
	Bit 16 = 1: N	leasure tools	with probe: Additional prob	e on counters	spindle.			
	Bit 17 = 1: T	ool measurer	nent for rotating tools with r	otating spindl	le			
	Bit 18 = 1: D	isplay colum	n "Rotation" in the zero offs	et list.				
	Bit 19 to bit 24: Reserved							
	Bit 25: A full	cross-sectio	n of the side view is always	s displayed in	the simulation.			
	Bit 26: Beta	and gamma a	angles are not positioned d	uring tool mea	asurements.			
	Bit 27: Rese	rved						
7.2 Display machine data for ShopTurn

9899	\$MM_ST_TRACE						
MD number	Settings for ShopTu	Settings for ShopTurn					
Default setting: 0	Min. inp	Min. input limit: 0000 Max. input limit: FFFF					
Change becomes effective after: IMMEDIATELY Protection level: 1 Units: Hex							
Data type: LONG			Valid as of software version ShopTurn 7.1				
Significance:	Bit 0: Reserved						

01/2008

Space for your notes

8

Tool Management

8.1 Overview of functions

Option	ShopTurn only runs when the tool management option is set. Tool management is shipped together with ShopTurn as standard. The option is already set in the standard set of machine data for ShopTurn.
	References: /FBW/, Description of Tool Management Functions
Data	Data storage and management is carried out in the NCK. All data can be read and written by manual entry, via the initialization program, or by data transfer.
Operation	Operation is performed via system screens.
Programming	When using tool management a tool can be called using another name, e.g. "Roughing tool_80". The tool can still also be called using a T no. (tool number). The T no. is then the name of the tool.
PLC	Separate PLC blocks are available for tool management to handle communica- tion between NCK and PLC.
Tools	With ShopTurn on NCU (HMI Embedded sl), a maximum of 250 tools can be set up; on the PCU 50.3 the maximum number of tools is limited by MD 18082 \$MN_MM_NUM_TOOL. Up to 9 cutting edges can be defined per tool.
Replacement tools	Maximum 98 replacement tools can be set up for each tool.
Magazine	It is possible to manage turret, chain or disk-type magazines. If you want to use chain or disk-type magazines, you need to set bit 13 in display machine data 9478 \$MM_TO_OPTION_MASK. The maximum number of magazines is set in the NC. The magazine list can be hidden via display MD 9674 \$MM_CMM_ ENABLE_TOOL_MAGAZINE.
Magazine location blocking	Magazine locations can be blocked, e.g. for oversized tools occupying adjacent magazine locations.

Overview of functions

8.1

Monitoring functions	Tool monitoring in the tool management system can be performed according to tool life, the number of completed workpieces, or tool wear. Replacement tools (sister tools) are distinguished by their Duplo number (DP). The tool monitoring can be deactivated via the display MD 9652 \$MM_CMM_TOOL_LIFE_CONTROL. The wear monitoring is activated via the MD 18080, bit 5.
Tool management without loading/ unloading	Tool management without the load/unload softkey can be set by means of value 2 in display MD 9651 \$MM_CMM_TOOL_MANAGEMENT.
Tool management with loading/ unloading	Tool management with the load/unload softkey can be set by means of value 4 in display MD 9651 \$MM_CMM_TOOL_MANAGEMENT.
Load	Loading brings the tool to its magazine location.
Unload	Unloading removes the tool from the magazine.
Sorting	Tools can be sorted in the tool list and the tool wear list according to magazine location, name, type, and tool number.
Other functions	
	 Loading/unloading point for tools by means of display MD 9673 \$MM_CMM_TOOL_LOAD_STATION
	 Display tools (mill/drill) in diameter or radius via display MD 9663 \$MM_CMM_TOOL_DISPLAY_IN_DIAM.
Modifying data	
	Note
	Changes to the tool and cutting edge data made via system variables in the part program are only displayed in the tool list in the ShopTurn user interface if they refer to the active tool.

8.2 Commissioning sequence

8.2 Commissioning sequence

You can start up tool management either together with ShopTurn or afterwards 4.2 (see section "First commissioning sequence").

To commission tool management, proceed as follows:

- 1. NCK commissioning
- 2. PLC commissioning
- 3. Adapt display machine data

If tool management has already been installed on your machine, you do not need to install tool management specifically for ShopTurn; i.e. it is not necessary to start up the NCK/PLC; you only need to adapt the display machine data for tool management.

For a precise description of tool management commissioning, please refer to: **References:** /FBIW/, Description of Functions Tool Management

Note

With PCU 50.3 you can also commission tool management (generating configuration file and PLC data) via the CNC–ISO operator interface.

References: /FBW/, Description of Tool Management Functions

8.3 Commissioning in NCK

Requirements

- PCU commissioning is performed and the connection to the NCK established.
- NCK commissioning is carried out with the default machine data.

Implementation

- Enter the NCK machine data for tool management.
- Create a new configuration file for tool management or use and adapt the examples from the toolbox.
- Load the configuration file into the controller.

8.3.1 Enter the NCK machine data

In order to use tool management the machine data for memory setting and for activating tool management must be set.

Machine data for	Memory space must be made available for tool management in the battery-
memory setting	backed RAM.

The following machine data must be set:

MD 18080	Activate the memory for the tool management
MD 18082	Number of tools to be managed by the NCK
MD 18084	Number of turrets that the NCK can manage (min. 3);
	include intermediate memory and loading magazine in the count!
MD 18086	Number of turret locations that the NCK can manage;
	include 1 intermediate memory location (tool holder) and
	2 load locations in the count!
MD 18100	Number of cutting edges in the NCK

Note

ShopTurn can manage 9 cutting edges per tool. Define the total number of all available cutting edges in MD 18105 MM_MAX_CUTTING_EDGE_NO. It is not necessary to enter the number of tools multiplied by 9 cutting edges. You can simply specify approximately how many cutting edges you will need in total.

8.3 Commissioning in NCK

Example	Assignment of n 18082=40; 18084=3; 18086=15; 18100=80;	nachine data: 40 tools (12 turret locations + 28 additional locations) 1 turret + 1 buffer magazine + 1 load magazine 12 turret locations + 1 buffer location + 2 load locations 80 cutting edges					
	Note						
	Via the machine data you simply reserve memory; the locations are only actually assigned to the turret, etc. when the configuration file is created and loaded; (see section 8.3.3 "Creating and loading the configuration file").						
	Modifying the "memory–influencing" machine data also reformats the battery–backed RAM. Data must therefore be backed up in advance.						
Machine data for activating tool	In addition, the f ment:	ollowing machine data must be set for activating tool manage-					
U	MD 20310 MD 20320	Channel–specific activation of tool management Activation of tool life monitoring for the spindle specified here					
	MD 20124	Activate tool holder					
	Note						
	Bits 0–3 of MD 20310 \$MC_TOOL_MANAGEMENT_MASK and MD 18080 \$MN_MM_TOOL_MANAGEMENT_MASK must always be set identically.						

Default

For a detailed description of the NCK machine data for tool management please refer to the next section 8.3.2 "Description of the NC Machine Data for Tool Management".

8.3.2 Description of NCK machine data

18080	MM_TOOL_MANAGEMENT_MASK						
MD number	Activate the memory for tool management						
Default setting: HB	Min. input limit:	put limit: 0xFFFF					
Change becomes effective at	fter: POWER ON	Protection level: 1/4		Units: HEX			
Data type: DWORD		Valid as of software ver	sion: 4.3	1			
Significance:	Activation of the tool management memory with "0" means: The tool management data set does not occupy any memory: tool management is not						
	available.		,	<i>,</i> , , , , , , , , , , , , , , , , , , ,			
	Bit 0=1: Memory for data s memory must be set acco MM_NUM_MAGAZINE)	specific to tool managem rdingly (18086 MM_NUM	ent is av 1_MAGA	ailable; the MDs for reserving ZINE_LOCATION, 18084			
	Bit 1=1: Memory is availab	ble for monitoring data					
	Bit 2=1: Memory is availab	ole for user data (CC data	a)				
	Bit 3=1: Memory is availab	ble for considering the ad	jacent lo	cation			
	Bit 4=1: Memory and function release for PI service _N_TSEARC = "Complex search for tools in magazine" is available.						
	Bit 5=1: Wear monitoring a	active (SW5 and later, 84	0D)				
	Bit 6=1: Wear grouping av	ailable (SW5 and later, 8	40D)				
	Bit 7=1: Reserve memory	for magazine location ad	lapters				
	Bit 8=1: Memory for opera	tion and/or setup correct	ions				
	Bit 9=1: Tools in a turret no longer vacate their turret location on tool change (in the display)						
	The coded type of memory reservation enables economic use of memory manager for the functionality provided.						
	Example: Standard memory reserva MD = 3 (bit 0 + 1=1) mear	tion for tool management is tool management and	t: tool mon	itoring data are available			
	MD = 1 means tool manag	MD = 1 means tool management without tool monitoring data					

18082	MM_NUM_TOOL				
MD number	Number of tools the NCK can manage				
Default setting: 24	Min. input limit: 0 Max. input limit: 600				
Change becomes effective after: POWER ON Protection level: 2/4 Units: —				Units: —	
Data type: DWORD	Valid as of software version: 2.				
Significance:	The number of tools which the NCK can manage is entered here. The maximum number of tools equals the number of cutting edges in the NCK. Battery-backed memory is reserved for the number of tools.				
Additional references	Description of functions: Memory Configuration (S7), Tool Offset (W1)				

8.3 Commissioning in NCK

18084	MM_NUM_TOOL_MAGAZINE				
MD number	Number of magazines the NCK can manage				
Default setting: 3	Min. input limit: 0 Max. input limit: 32				
Change becomes effective after: POWER ON			Protection level: 2/4	el: 2/4 Units:	
Data type: DWORD Valid as of software version: 2.					
Significance:	Number of magazines that the NCK can manage (active and background magazines). This MD is used to reserve battery-backed memory for the magazines. Important: One load magazine and a buffer magazine is set up in the tool management for each TOA unit. These magazines must be taken into account. Value = 0: Tool management cannot be active because no data can be created.				
Additional references	Description of functions: Memory configuration (S7)				

18086	MM_NUM_MAGAZINE_LOC				
MD number	Number of magazine locations the NCK can manage				
Default setting: 15		Min. input limit:	0	Max. ir	nput limit: 600
Change becomes effective at	fter: POWE	RON	Protection level: 2/4		Units: —
Data type: DWORD	Data type: DWORD Valid as of software version: 2.				
Significance:	Number of magazines the NCK can manage. This MD reserves the battery-backed memory for the magazine locations.				
	Important: The locations in the intermediate memory and a loading magazine must be taken into account.				
	Value = 0: Tool management cannot be active because no data can be created.				
Additional references	Description of functions: Memory configuration (S7)				

18100	MM_NUM_CUTTING_ED	GES_IN_TOA				
MD number	Number of tool cutting edges per TOA block					
Default setting: 48	Min. input limit:	0	Max. input limit: 1500			
Change becomes effective at	fter: POWER ON	Protection level: 2/4	Units: —			
Data type: DWORD		Valid as of software ver	sion: 2.			
Significance:	Valid as of software version: 2. This MD is used to stipulate the number of cutting edges in the NCK. For each cutting edge – irrespective of tool type – this machine data reserves approximately 250 bytes per TOA block in the battery–backed memory. Tools with cutting edges of type 400–499 (= grinding tools) occupy space for a cutting edge in addition. Example: Define 10 grinding tools each with one cutting edge. The following minimum requirements apply: MM_NUM_TOOL = 10 MM_NUM_CUTTING_EDGES_IN_TOA = 20 See also MM_NUM_TOOL Special cases: If this machine data is altered the buffered data is lost.					
Additional references	Description of functions: Memory configuration (S7)					

8 Tool Management

8.3 Commissioning in NCK

20124 MD number	TOOL_MANAGEMENT_TOOLHOLDER Toolholder number					
Default setting: 0,0,0,	1	Min. input lir	Min. input limit: 0		Max. input limit: 16	
Change becomes effective	after: POWEF	RON	Protection le	evel: 2/7		Units: –
Data type: DWORD			Valid as of software version: 3.2.			on: 3.2.
Significance:	This MD only It is used to in order to do which tool ho If the MD is I numbers. The automa and no longe For machine the MD acts tool change. Tools which and which h with a value Command S When definii -\$TC_MPP ⁻ assignes a c	y takes effect stipulate whe efine the loca older the tool larger than 0, atic address e er the value o as a default SETMTH(n) are to be loa ave the value not equal to r SETMTH resto ng the magaz 1=2=spindle l	if tool manage ther a tool hol tion of the too is to be loaded the spindle n extension of T of MD 20090 S al tool holders value defining designates to ded in a buffe \$TC_MPP5= n have no effect ores the tool h cine locations ocation— can holder to the l	ement is active der number of l to be loaded d. umbers \$TC and of M06 is SPIND_DEF_I without a des the tool holder of holder n as r location of the n have the effect on the offse to to n the offse of internal mate be cassigned a ocation.	ve. r spindle num . Tool manage MPP5 are inter then the value MASTER_SP ignated master to which the the master to the spindle typ fect of correct et. ed in the MD a gazines, spin- a location type	ber have to be indicated ement must know on erpreted as tool holder ue of this MD IND. er spindle e tool is to be loaded on bol holder. ing the tool path. Tools as master tool holder. dle locations e index (\$TC_MPP5). This
Corresponding to	MD 20090 S MD 20110: F MD 20112: S MD 20122: T MD 20130: C	SPIND_DEF_ RESET_MOD START_MOD FOOL_RESE CUTTING_EL	MASTER_SP DE_MASK DE_MASK T_NAME DGE_RESET	IND _VALUE		
Additional references						

8.3 Commissioning in NCK

20310 T	TOOL_MANAGEMENT_MASK						
MD number C	Channel-specific activation of tool management						
Default setting: 1400B		Min. input limit: 0	Max. input limit: 0xFFFFF				
Changes effective after POWER ON		Protection level: 2/4	Units: HEX				
Data type: DWORD		Valid as of	f software version: 2				
Significance: N	MD = 0: Tool management inactive						
B	8it 0=1:	Tool management active					
		The tool management functions are					
		enabled for the current channel.					
B	Sit 1=1:	Tool monitoring function active					
		Functions that are used for tool monito	pring (tool life and				
		workpiece count) are enabled.					
В	SIT 2=1:	OEM functions active	_				
	The memory can be used for user data						
P	(see also MID 18090 to 18098).						
В	on 3=1.	Bit 0 to Dit 2 must be get as for MD 19090;					
	MM TOOL MANAGEMENT MASK						
В	Bit 4=1: The PLC is able to request another tool change preparation process						
		modified parameters.					
w	With T selection or M06 the part program pauses until acknowledged by the PLC						
p	rogram						
В	Bit 5=1: When the tool command is output the main run of the main spindle						
		stopped within one OB1 cycle (e.g. by	read–in halt).				
В	8it 5=0:	When the command is output to the PLC the main run of the main spindle is resumed. When the tool command is output the main run of the auxiliary spindle can be stopped within one OB1 cycle (e.g. by read–in halt). When the command is output to the PLC the main run of the main spindle is resumed					
В	Bit 6=1:						
В	8it 6=0:						
	it 7_1.	The main run of the main spindle is halted					

until acknowledgment with status 1 is received via FC7, FC8.

When the command is output to the PLC the main run of the main spindle is

When the command is output to the PLC the main run of the auxiliary spindle is

M06 is delayed until "prepare change" is received

The main run of the auxiliary spindle is halted until acknowledgment with

		via FC8 (status 1) from the PLC.
		The change signal (e.g. M06) is only output
		when tool selection (DBX [n+0].2) is acknowledged. The part program is
		halted with M06 until tool selection is acknowledged.
B	it 10=0:	The tool change ON command NCK -> PLC is not output until the PLC
		preparation acknowledgment has been received. This is relevant for
		PLC command 3 (i.e. programming of M06 in a
		block containing no T).
B	it 11=1:	The preparation command is output even if it has already been issued once for
		the same tool.
		This system is used to position the chain with the first "Tx"
		and to check with the second call whether the tool is in the correct tool-change
		location (e.g. in front of the changing station)
B	it 11=0:	The preparation command can be output only once for a tool.
В	it 12=1:	The preparation command is executed even if the tool is already in the spindle.
		This means that the T selection signal (DB72.DBXn.2) is set
		even if it has already been set once for the same tool. (TxTx)
B	it 12=0:	The preparation command is not executed if the tool is already inserted
		in the spindle.

status 1 is received via FC7, FC8.

Bit 7=0:

Bit 8=1:

Bit 8=0:

Bit 9:

resumed.

resumed.

Reserved 10=1:

8 Tool Management

8.3 Commissioning in NCK

20310	TOOL_MA	NAGEMENT_MASK
MD number	Channel-sp	pecific activation of tool management
Significance:	Bit 13=1:	Only for systems with sufficient memory capacity. Recording of tool sequences in a diagnostics buffer. On reset the commands are transferred from the diag nostics buffer to the passive file system (NCATR xx.MPF under part program). This file is required by the Hotline. Tool sequences are recorded in the diagnostics buffer only on systems with sufficient memory (NCUE72)
	Bit 14=1:	An automatic tool change takes place on reset and start as per MD20120 TOOL_RESET_NAME MD20110 RESET_MODE_MASK MD20124 TOOL_MANAGEMENT_TOOLHOLDER. If the tool specified in TOOL_RESET_NAME is to be loaded (this is set in RESET_MODE_MASK), a tool selection and change command is output to the user interface on RESET or START (DB72). If RESET_MODE_MASK is set, thus retaining the active tool, and the active
		tool is disabled in the spindle (by the user), a tool change command for a replacement tool is output to the user interface.
	Bit 14=0:	No automatic tool change takes place on RESET and START.
	Bit 15=1:	The tool is not returned in response to several preparation commands $(Tx \rightarrow Tx)$. This method of function activation permits various combinations. Example for default activation of tool management: MD 20310 TOOL_MANAGEMENT_MASK = 3 (Bit0 + 1 = 1)
		Bit16=1: T location number is active
	Bit 15=0:	The tool is not returned.
	Bit 16=1: Bit 17=1:	Tool life decrementation can be started/stopped via the PLC in channel DB 2.1DBx 1.3.
	Bit 18=1: Bit 18=0:	Activation of monitoring "last tool in tool group". No monitoring for "last tool in tool group"
	Bit 19=1:	Activation for bits 5 to 8
	Bit 19=0: Bit 20=0:	Functions described under bits 5 to 8 are not available. On PLC signal "program testing active" the commands generated on are not output to the PLC. The NCK acknowledges the commands itself. Magazine and tool data are not changed. Exception: The status of the tool activated in the test area can be changed to "active".
	Bit 20=1:	On PLC signal "program testing active" the commands generated are output to the PLC. In so doing. depending on the type of PLC acknowledgment, tool/magazine data in the NCK may be altered. If the acknowledgment parameters for the target magazine are set with the same values as the source magazine, the tool is not transported and thus no data is modified in the NCK. Exception: The status of the tool activated in the test area can be changed to "active".
	Bit 21=0:	Ignore tool status "W" on tool selection.
	Bit 21=1:	Tools with status "W" cannot be selected by another tool change or tool preparation command.
	Bit 22=0 Bit 22=1	Default setting If the function T="Location" (see Bit 16) is active, the tool groups are automatically divided into subgroups. \$TC_TP11 is the grouping and selection parameter. On transition to replacement tool only those tools in the tool group
	Bit 23=0	are recognized as replacement tools that in the \$IC_TP11-value have at least one bit of the tool set to the programmed location. Default setting
	Bit 23=1	Tool management selects the tool in the main run with optimum certainty; i.e. the interpreter must, if correction is required, wait for the end of tool selection. For single applications the interpreter selects the tool itself; i.e. if correction is required, no synchronization with the main run is needed. (If after selection but before loading the tool becomes no longer usable, a non-correctable alarm

8.3 Commissioning in NCK

20320 MD number	TOOL_TIME_MONITOR_MASK Activation of tool life monitoring for the spindle here specified					
Default setting: 1	Min. input limit:	Min. input limit: 1 Max. input limit: 4				
Change becomes effective after: POWER ON Protection level: 2/4 Units:						
Data type: DWORD	Valid as of software version: 2					
Significance:	Value = 1: Monitoring is Value = 2: Monitoring is	Value = 1: Monitoring is carried out for spindle 1. Value = 2: Monitoring is carried out for spindle 1 and spindle 2.				
Additional references	Description of functions: N	lemory configuration (S7	7)			

8.3.3 Creating and loading the configuration file

For tool management commissioning, a configuration file for the turret must be created and loaded in the NCK.

Create a new configuration file or adapt the example from the toolbox.

Note

Make sure that you adapt the data in the configuration file to match the machine data for tool management.

The configuration file must include the following settings:

- Define the type of search strategy
- Define the real magazine
- Define buffer magazine
- Define load magazine
- Define locations for the real magazine
- Define locations for the buffer magazine
- Define the spindle assignment
- Define the locations for the load magazine
- Define the distances for the real magazine

Transfer the configuration file to the NCK.

Example The configuration file TM_REV12.8x0 is located in the PLC toolbox under \ShopMill Turn and has been generated for a turret magazine with 12 locations,

1 tool holder, and 2 loading points.

Enter the value 15 in MD 18086 \$MN_MM_NUM_MAGAZINE_LOCATION.

Adapt configuration file TM_REV.12.8X0 at the positions marked bold.

%_N_TO_TMA_INI
CHANDATA(1)

```
;TM_REV.12.8x0
```

;-

;tool management configuration for ShopTurn machine with turret

;delete old data

8 Tool Management

8.3 Commissioning in NCK

```
$TC MAP1[0]=0
$TC_DP1[0,0]=0
;type of search strategy
                     ;search forward from 1st location for
$TC MAMP2=257
                     ;active tools
;definition of magazines
;-
;real magazine
$TC MAP1[1]=3
                     ;magazine type (3: turret, 1: chain)
$TC MAP3[1]=17
                     ;magazine status (17: active magazine,
                     ;enabled for loading)
$TC MAP6[1]=1
                     ;number of lines in the magazine
$TC_MAP7[1]=12
                     ;number of magazine locations
; buffer magazine
$TC_MAP1[9998]=7
                     ;magazine type (7: buffer)
$TC MAP3[9998]=17
$TC MAP6[9998]=1
$TC MAP7[9998]=1
                     ;number of buffer locations
                     ;(1: spindle)
;load magazine
$TC MAP1[9999]=9
                     ;magazine type (9: load magazine)
$TC_MAP3[9999]=17
$TC_MAP6[9999]=1
                     ;number of load points
$TC MAP7[9999]=2
;locations of real magazine
:-
;location no 1
$TC_MPP1[1,1]=1
                     ;location kind (1: magazine location)
$TC_MPP2[1,1]=1
                     ;location type
$TC_MPP3[1,1]=1
                     ; consider adjacent location (1: on)
$TC MPP4[1,1]=2
                     ;location state (2: location free)
$TC MPP5[1,1]=1
                     ;location kind index (1: location no 1)
;location no 2
$TC_MPP1[1,2]=1
                     ;location kind (1: magazine location)
$TC MPP2[1,2]=1
$TC_MPP3[1,2]=1
$TC_MPP4[1,2]=2
                     ;location kind index (2: location no 2)
$TC MPP5[1,2]=2
$TC MPP1[1,3]=1
$TC _MPP2[1,3]=1
$TC_MPP3[1,3]=1
$TC MPP4[1,3]=2
$TC MPP5[1,3]=3
;
.
```

```
$TC MPP1[1,12]=1
                      $TC_MPP2[1,12]=1
                      $TC MPP3[1,12]=1
                      $TC_MPP4[1,12]=2
                      $TC MPP5[1,12]=12
                      ;
                      ;locations of buffer magazine
                      ;-
                      ;spindle
                      $TC_MPP1[9998,1]=2 ;location kind (2: spindle)
                      $TC_MPP2[9998,1]=0 ;location type
                      $TC_MPP3[9998,1]=0 ;consider adjacent
                                           ;location state (2: location free)
                      $TC_MPP4[9998,1]=2
                      $TC_MPP5[9998,1]=1 ;location kind index (1: spindle)
                      ;locations of load magazine
                      :-
                      ;1st load point
                      $TC MPP1[9999,1]=7
                                           ;location kind (7: load point)
                      $TC MPP2[9999,1]=0 ;location type
                      $TC_MPP3[9999,1]=0 ;consider adjacent
                      $TC_MPP4[9999,1]=2 ;location status (2: location free)
                      $TC_MPP5[9999,1]=1 ;location kind index (1: load point 1)
                      ; distance to change position of real magazine
                      ;-
                                       ;spindle
;1st load point
;2nd loci
                      $TC MDP2[1,1]=0
                      $TC_MDP1[1,1]=0
                      $TC_MDP1[1,2]=0
                                           ;2nd load point
                      M17
Variable
                      The main variables for the configuration file are described here. For a detailed
description
                      description of the system variables, please refer to:
                      References:
                                    /FBW/, Description of Tool Management Functions
                      $TC MAP1[MagazineNo]= Magazine type
                       1: Chain
                        3: Revolver
                       5: Flat magazine
```

- 7: Internal magazine tool buffer
- 9: Internal magazine loading station

8.3 Commissioning in NCK

\$TC_MAP3[MagazineNo]= Magazine status

- Bit 0 = 1: Active magazine
- Bit 1 = 1: Blocked
- Bit 2 = 1: Magazine is at load position
- Bit 3 = 1: Tool motion is active
- Bit 4 = 1: Enabled for loading

Default: Bit 0 and bit 4 set

\$TC_MAP6= Number of magazines for ShopTurn: 1

\$TC_MAP7= Number of locations e.g. number of buffer locations 1= tool holder

\$TC_MAMP2= Type of search strategy

This mask is divided into a right and left byte.

- The right byte describes the tool search (bits 0 and 1).
- · The left byte describes the empty location search for the active tool.

A value must be specified for both strategies.

- Bit 0 = 1: Search for active tool with tool designation (1)
- Bit 1 = 1: Search for next tool with tool designation (2)
- Bit 8 = 1: Search from 1st location onwards (256)
- Bit 9 = 1: Search from current location onwards (512)
- Bit 10 = 1: Search from last location backwards (1024)
- Bit 11 = 1: Search from current location backwards (2048)
- Bit 12 = 1: Search from current location symmetrically (4096)

Example: \$TC MAMP2=257 (bit 0=1 and bit 8=1)

Bit 0 = 1: Search for active tool with tool designation, Bit 8 = 1 Search from 1st location onwards

\$TC_MPP1[MagazineNo, LocNo]= Type of location:

- 1 = magazine location
- 2 = Tool holder
- 3 = gripper
- 4 = loader
- 5 = transfer location
- 6 = loading station
- 7 = loading point

Default: Value corresponding to location type

\$TC_MPP2[MagazineNo, LocNo]= Type of location:

Any values can be entered here. The values must match the tools to be loaded at the location.

Example:

- Value = 0: Every tool fits in this location
- Value = 1: Location for heavy tools
- Value = 2: Location for long tools

\$TC_MPP3[MagazineNo, LocNo]= Considering adjacent location ON = 1

- Value = 1: An adjacent location is considered for the location specified
- Value = 0: No adjacent location is considered for the location specified
- Value = 0: This must be entered for buffer and load locations.

\$TC_MPP4[MagazineNo, LocNo]= Location status:

- Bit 0 = 1: Blocked
- Bit 1 = 1: Free/allocated

Default: Bit 1 set

\$TC_MPP5[MagazineNo, LocNo]= Location type index

For \$TC_MPP1[Magazine no., Location no.]=1 (location type is the magazine location), the location number is entered here. For other location types, the type index is incremented.

8.3 Commissioning in NCK

\$TC_MDP2[MagazineNo, BufferNo.]= Distances between buffer and magazine

Turret revolver: Value = 0

\$TC_MDP1[MagazineNo, BufferNo.]= Distances between load points and magazine

Turret revolver: Value = 0

Requirements

- PCU commissioning is performed and the connection to the NCK established.
- NCK commissioning is carried out with the NCK machine data for ShopTurn.
- The basic PLC program is loaded.

General



Fig. 8-1 Overview of tool management

FC 6 supplies data blocks DB71, 72, and 73 with the information for the new and old tools. Block FC 6 is called by the basic PLC program and must not be called again in the PLC user program.

To ensure that tool management always knows where the current tool is located, each tool location change must be reported to tool management via FC 7/8 (transfer block). The FC 7/8 (transfer block) is called by the PLC user program (FB110).

FB110 is provided as example.

Data blocks DB71, 72, 73, and 74 are set up automatically. The lengths of the data blocks are determined by the parameters for tool management in DB4. DB4 is written by the PLC user program. FB100 is available as an example for this.

Implementation Implement call FC 8 and create PLC data (DB4). For this purpose, either adjust the blocks FC 100 and FB110 in the directory \ShopMill_Turn or use your own blocks.

8.4.1 Example for FC 100 and FB 110

The AWL source TM_REV.AWL is provided as an example for tool management in directory $\ShopMill_Turn.$

Procedure

 Modify source file TM_REV.AWL (data transfer for turret) and then compile the file.

Source file TM_REV.AWL contains the following blocks:

- FC 100 (block for tool management configuration)
- FB 110, DB 110 (blocks for data transfer in tool management)

The blocks for transferring tool management data (FB110, DB110) must be adapted to suit the individual machine.

- Load the blocks to the PLC.
- Call the blocks in OB 1 and OB 100:
 - Call FC 100 in OB 100
 - Call FB 110 in OB 1

8.4

FC 100	Block FC 100 transfers the PLC data for tool management to DB4.
	The PLC data is set up for 2 loading stations (DB71), one tool holder (DB72), and the turret magazine (DB73). The signals for DB71, DB72, and DB73 are described in section 8.4.2 "Signal description".
	The "Real MagLoc" parameter of FC 100 (number of locations on the turret magazine) must be assigned values when FC 100 is called.
FB 110	Block FB 110 controls the data transfer for tool management.
	The block includes the following functions:
	Acknowledge load/unload/relocate for 1st loading point
	Acknowledge change for tool holder
	Abort, i.e. negative acknowledgment for the above-mentioned functions
	The acknowledgment for these functions can be enabled by the PLC via the input parameter of FB 110, e.g. confirm load/unload via user key. The default settings for the input parameters are for automatic acknowledgement, so that block FB 110 can be used on test stations involving no further link to the machine; (see Table 8-1). Automatic acknowledgment is performed by means of interface signals from the tool management data blocks; each of these can be skipped.
Data transfer	For data transfer with the turret FB 110 from STL source file TM_REV.AWL can be used.

Signal	Туре	Default	Comment
Change_Rev_IF1	BOOL	TRUE	Acknowledge change for turret
Load_IF1	BOOL	TRUE	Acknowledge loading for loading point 1
Unload_IF1	BOOL	TRUE	Acknowledge unloading for loading point 1
Relocate_IF1	BOOL	TRUE	Acknowledge relocation for loading point 1
Position_IF1	BOOL	TRUE	Acknowledge positioning to loading point 1
Reset_IF	BOOL	FALSE	Abort for one of the above-mentioned func- tions

Table 8-1 Input parameters of FB 110 from TM_REV.AWL

Note

MD 9673 CMM_TOOL_LOAD_STATION defines the interface via which the magazine will be loaded or unloaded.

Signal description 8.4.2

Overview of data blocks	The followin assigned by	g data blocks are used by tool management; i.e. they must not be the PLC user program:
	DB 71	for loading/unloading points
	DB 72	for tool holder

DB 73	for turr

et DB 74 internal data block for tool management

If you need to change the data for magazines, buffers, or loading positions, delete data blocks DB 71 to DB 74 and restart the PLC.

Overview DB71

DB71 Data b	lock	Signals of load/unload points NCK –>PLC interface							
Byte		Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
					In	terfaces		I.	
DBB 0	1	INT 8	INT 7	INT 6	INT 5	INT 4	INT 3	INT 2	INT 1
DBB 1		INT 16	INT 15	INT 14	INT 13	INT 12	INT 11	INT 10	INT 9
DBB 2	, 3								
DBB n	+ 0				NC program positions magazine	Position at loading point	Relocate	Unload	Load
DBB	n + 1				Un	assigned			
DBB	n + 2				Assigned of	hannel (8bit–Int)		
DBB	n + 3		Tool management number (8bit–Int)						
DBD	n + 4		\$P_VDITCP[0] User parameter 0 (DWord)						
DBD	n + 8		\$P_VDITCP[1] User parameter 1 (DWord)						
DBD	n + 12				\$P_` User para	VDITCP[2] meter 2 (DWord)	1		
DBW	n + 16			Identi	fier for load/unload	l point (Int), (fixe	d value 9999)		
DBW	n + 18				Location no. of	load/unload poin	t (Int)		
DBW	n + 20			Magazine	e no. (source) for l	oading/relocatior	n/positioning ((Int)	
DBW	n + 22			Location	no. (source) for lo	ading/relocation	/positioning (I	nt)	
DBW	n + 24			Maga	azine number (targ	jet) for loading/re	locating (Int)		
DBW	n + 26		1	Loca	ation number (targ	et) for loading/re	locating (Int)		
DBW HMI oi	n + 28 n PLC								Load/un- load with- out mov- ing maga- zine

Initial addresses of load/unload locations:

Loading/unloading location	1:	n = 4
	2:	n = 34
	3:	n = 64
	4:	n = 94

Example calculation of address DBW n+24 (magazine no. target)

n = (m–1) * len + 4		m = location no. of loading station/point len = 30 (length of a loading station)			
m =2 ;	len = 30	n = (2–1) * 30 + 4 ==> n = 34 DBW (34 + 24) = DBW 58			

Address for magazine no. target of 2nd load point is DBW 58.

Loading point 1 is intended for loading/unloading in (all) spindles/tool holders. This must be considered when assigning the loading interfaces (applies with ShopTurn on NCU (HMI Embedded sl); with PCU 50.3 this is taken into account automatically). Loading point 1 is also used to relocate/ position tools in any location (e.g. buffer location).

DB72		Spindle as change position								
Dala D	NUCK				Interface N	ICK->PLC	2			
Byte		Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	
DBB 0	1	INT 8	INT 7	INT 6	INT 5	INT 4	INT 3	INT 2	INT 1	
DBB 1		INT 16	INT 15	INT 14	INT 13	INT 12	INT 11	INT 10	INT 9	
DBB 2	, 3									
DBB	n + 0	Reserved	Detach manual tool	Attach manual tool	OldTool in BL No. (n+42)	то	Prepare change	Change tool (initiated by: M06)	Obliga- tory change	
DBB	n + 1				Unass	signed	1	4	1	
DBB	n + 2			A	Assigned cha	nnel (8–bit	Int)			
DBB	n + 3			Tool	management	number (8	bit–Int)			
DBD	n + 4		\$F	P_VDITCP[0], user–assig	nable para	meter 0 (DWo	rd)		
DBD	n + 8		\$F	P_VDITCP[1], user–assig	nable para	meter 1 (DWo	rd)		
DBD	n + 12		\$F	P_VDITCP[2], user–assig	nable para	meter 2 (DWo	rd)		
DBW	n + 16			Buffer equa	identifier (Int als "Target po), fixed valu sition for ne	ue 9998) ew tool"			
DBW	n + 18			Relative loc	cation (target)	in buffer n	nagazine (Int)			
DBW	n + 20			Magaz	zine no. (sour	ce) for new	v tool (Int)			
DBW	n + 22			Locati	on no. (sourc	e) for new	tool (Int)			
DBW	n + 24			Maga	azine no. (tarç	get) for old	tool (Int)			
DBW	n + 26			Loca	tion no. (targ	et) for old to	ool (Int)			
DBW	n + 28			Ν	New tool: Loc	ation type (Int)			
DBW	n + 30				New tool: Siz	e on left (li	nt)			
DBW	n + 32			1	New tool: Siz	e on right (l	Int)			
DBW	n + 34				New tool: Siz	ze at top (Ir	nt)			
DBW	n + 36			N	lew tool: Size	at bottom	(Int)			
DBW	n + 38				Tool status	for new too	bl			
		Tool has been used	Tool with fixed loc. code		Prewarn- ing limit reached	Measure tool		Enable tool	Active tool	
DBW	n + 40			New to	ol: Internal T	number of	NCK (Int)			
DBW	n + 42		If DBX (n+0.4)	= 1, then th	e buffer locat	ion of the c	old tool must b	e entered here		
DBW	n + 44				Sp	are				
	11 + 40	1			30	are				

Overview DB72

Initial addresses of spindles: Spi Spi n = (m-1)* len + 4 m = len

Spindle 1: n = 4Spindle 2: n = 52Spindle 3: n = 100m = Location number of change positionlen = 48

Note

DBB (n+1) to DBW (n+46) are updated **only** by a T selection.

8 Tool Management

8.4 Commissioning in the PLC

Overview DB73

DB73 Data block	Turret as change position Interface NCK->PLC							
Byte	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
DBB 0	INT 8	INT 7	INT 6	INT 5	INT 4	INT 3	INT 2	INT 1
DBB 1	INT 16	INT 15	INT 14	INT 13	INT 12	INT 11	INT 10	INT 9
DBB 2, 3								
DBB n+0					то		Perform change (initia- tion: T no.	Obliga- tory change
DBB n+1				Unas	signed			
DBB n + 2			A	ssigned cha	nnel (8–bit l	nt)		
DBB n+3	Tool management number (8bit–Int)							
DBD n+4	<pre>\$P_VDITCP[0], user-assignable parameter 0 (DWord)</pre>							
DBD n + 8	<pre>\$P_VDITCP[1], user-assignable parameter 1 (DWord)</pre>							
DBD n + 12	\$P_VDITCP[2], user-assignable parameter 2 (DWord)							
DBW n + 16	Reserved							
DBW n + 18	Reserved							
DBW n + 20	Magazine no. of turret (Int)							
DBW n + 22		Location no. of new tool (Int)						
DBW n+24		Reserved						
DBW n + 26	Location no. of old tool (Int)							
DBW n + 28	Tool new: loc. type (Int)							
DBW n + 30		Tool new: size left (Int)						
DBW n+32		Tool new: size right (Int)						
DBW n+34	Tool new: size top (Int)							
DBW n+36	Tool new: size bottom (Int)							
DBW n + 38	Tool status	Tool status for tool						
	Tool was in use	Tool with fixed loc. code		Prewarn. limit reached	Measur- ing tools		Tool enabled	Active tool
DBW n + 40		Tool new: Internal T no. of NCK (Int)						
DBW n + 42		Reserved						

Initial addresses of turrets:

```
Turret 3: n = 92
n = (m-1)* len + 4
                                      m = Location number of change position
                                      len = 44
                                 n = (3–1)*n 44+ 4= 2*44 + 4= 88 + 4= 92
```

Turret 1: n = 4Turret 2: n = 48

Example for change position 3:

Note

For a description of data blocks DB71 and DB74, please see **References:** /FBW/, Description of Functions Tool Management

Description DB73

DB73 – DBX 0.0 – 0.15	Active status of interface 1–16		
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2	
Signal state 1	Associated interface has a valid data block		
Signal state 0	Operation for this interface has ended. Is reset by FC 7.		

DB73.DBX(n+0).0	Command code: Obligatory change		
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2	
Signal status 1			
Signal status 0			
Corresponding to	Position of involved tools		

DB73.DBX(n+0).1	Command code: Perform change		
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2	
Signal state 1	Execute tool change		
Signal state 0			

DB73.DBB(n+0).3	то	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Indicates that T0 has been programmed.	

DB73.DBB(n+2)	Assigned channel		
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2	
Description	Number of channel from which the T word was programmed.		

DB73.DBB(n+3)	Tool management no.		
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2	
Description	Associated tool management number (TO area) of channel		

Note

The bits in DBB (n+0) (obligatory change, execute change,...) are <u>not</u> reset by the system. They are current only if the corresponding interface bit in DBB0 is set to "1". However, the bits can be reset by the user if necessary.

DB73.DBD(n+4)	User parameter 0 (DInt)		
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2	
Description	If you need to send a value to the be programmed with \$P_VDITCP the T command.	PLC via the part program, the transfer can [0]=(value). Parameters 0–2 are passed with	

DB73.DBD(n+8)	User parameter 1 (DInt)		
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2	
Description	If you need to send a value to the PLC via the part program, the transfer can be programmed with \$P_VDITCP[1]=(value);.		

DB73.DBD(n+12)	User parameter 2 (DInt)		
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2	
Description	If you need to send a value to the PLC via the part program, the transfer can be programmed with \$P_VDITCP[2]=(value);.		

DB73.DBW(n+16)	Reserved	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2

DB73.DBW(n+18)	Reserved	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2

DB73.DBW(n+20)	Magazine no. of new tool	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Magazine number of the new tool to be used for machining.	
Corresponding to	DBW(n+22)	

DB73.DBW(n+22)	Location number of new tool to be loaded	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Location number of the new tool to be used for machining.	
Corresponding to	DBW(n+20)	

DB73.DBW(n+24)	Reserved	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2

DB73.DBW(n+26)	Location no. of old tool to be unloaded	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Location number of the old tool (used up to now for machining)	

DB73.DBW(n+28)	Tool new: Location type
Description	The location type of the new tool is entered here.
Corresponding to	Tool size: Left, right, top, bottom

DB73.DBW(n+30)	Tool new: Size left (Int)	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Specification of new tool size on left in half locations.	

DB73.DBW(n+32)	Tool new: Size right (Int)	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Specification of new tool size on right in half locations.	

DB73.DBW(n+34)	Tool new: Size top	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Specification of new tool size at top in half locations.	

DB73.DBW(n+36)	Tool new: Size bottom	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Specification of new tool size at bottom in half locations.	

DB73.DBW(n+38)	Tool status for new tool	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Bit 0: Active tool Bit 1: Tool enabled Bit 2: Tool disabled Bit 3: Measure tool Bit 4: Prewarning limit reached Bit 5: Tool is being changed Bit 6: Tool is fixed–location–code Bit 7: Tool was in use	d

DB73.DBW(n+40)	Tool new: Internal T no. of NCK	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2
Description	Display of internal T no. of NCK for the new tool. Tool management variables can be read/written via FB2/FB 3 using this T no.	

DB73.DBW(n+42)	Reserved	
Edge evaluation	Signal(s) updated: Conditional	Signal(s) valid from SW: 2

8.5 Display machine data

8.5 Display machine data

Display machine data can be used to activate certain functions and settings at the operator interface.

MD 9450 \$MM_WRITE_TOA_FINE_LIMIT Limit value for fine wear

MD 9478 \$MM_TO_OPTION_MASK Settings for ShopTurn

MD 9639 \$MM_CTM_MAX_TOOL_WEAR Upper input limit for tool wear

MD 9651 \$MM_CMM_TOOL_MANAGEMENT Tool management variant

MD 9652 \$MM_CMM_TOOL_LIFE_CONTROL Tool monitoring

MD 9663 \$MM_CMM_TOOL_DISPLAY_IN_DIAM Radius/diameter display for tool

MD 9667 \$MM_CMM_FOLLOW_ON_TOOL_ACTIVE Tool preselection active

MD 9671 \$MM_CMM_TOOL_LOAD_DEFAULT_MAG Load tool in default magazine

MD 9672 \$MM_CMM_FIXED_TOOL_PLACE Fixed location coding

MD 9673 \$MM_CMM_TOOL_LOAD_STATION Number of loading point

MD 9674 \$MM_CMM_ENABLE_TOOL_MAGAZINE Display of magazine list

MD 9687 \$MM_CMM_TOOL_MOVE_DEFAULT_MAG Relocate tool to default magazine

For the defaults and description of this machine data please refer to section 7.2 "Display machine data for ShopTurn".

8.6 Enable spindle and coolant

8.6 Enable spindle and coolant

Here you can assign a direction of rotation (CW/CCW/OFF) and coolant to a tool.

	"Coolant 1/2 ON/OFF"											
	"Spindle CW/CCW/OFF"											
Werkzeugliste												
P1.	Тур	Werkzeugname	DP1. Schneide						# ⇒⇒			
			Länge XLänge ZRadius						Plat. länge	1	2	
1		SCHRUPPER_80N	1	78.057	37.260	0.800	+ 80	93.0	15.0	Ω		
2	ø	PILZ_8N	1	83.546	26.109	4.000				2		

Fig. 8-2 Tool list: Coolant and direction of spindle rotation

Coolants are assigned to the appropriate M commands via the following machine data:

MD 9680 \$MM_CMM_M_CODE_COOLANT_I MD 9681 \$MM_CMM_M_CODE_COOLANT_II MD 9668 \$MM_CMM_M_CODE_COOLANT_I_AND_II MD 9686 \$MM_CMM_M_CODE_COOLANT_OFF

8.7 Moving the turret manually

8.7 Moving the turret manually

To bring another tool located in the turret into machining position, move the turret manually via the machine control panel. Any manual movement must be reported to the NCK so that the correction values for the new tool can be calculated. You can implement this check–back signal providing that the option "actions that go across modes (asynchronous subprograms ASUB and synchronized actions in all modes)" is set (Order No. 6FC5 800–0AM43–0YB0).



Fig. 8-3 Example of check–back signal from tool number to NCK

8.7 Moving the turret manually

01/2008

The ASUB derives the tool number from the location number (actual position) that it has received from the PLC block and forwards this to the NCK.

The toolbox contains the sources TM_REV_M_GR.AWL in German mnemonics, TM_REV_M_UK.AWL in English mnemonics, and the ASUB TM_REV_M.SPF. The PLC block and ASUB use interrupt 8 and analog input 1. Please set the following machine data:

MD 11602 \$MN_ASUP_START_MASK = H3 Ignore stop reasons for ASUB

MD 11604 \$MN_ASUP_START_PRIO_LEVEL = H64 Priorities for MD 11602 \$MN_ASUP_START_MASK effective

MD 20116 \$MC_IGNORE_INHIBIT_ASUP, bit 7 = 1 (ASUB on interrupt 8 can always be executed.) If another interrupt number is used, the corresponding bit must be set.

MD 10300 \$MN_FASTIO_ANA_NUM_INPUTS = Total number of analog inputs used.

MD 10320[0] \$MN_FASTIO_ANA_INPUT_WEIGHT = 32767 Weighting of the analog input (index 0 corresponds to input 1)

You might have to adapt the PLC block and the ASUB. Please note the following:

- Assign new block numbers in the symbols table.
- Make sure that the interrupt numbers are identical when you initialize (FB4 call) and call them (FC9 call) (default setting 8).
- If necessary, adapt the interface signals to the analog input.
- Compile and load the TM_REV_M.
- Call up the function block in the user PLC and parameterize it.
- Set interface VAR_INPUT to start and combine the VAR_OUTPUT signals for the check–back signal of the block in your user PLC.
- In your user PLC make sure that the tool turret cannot be restarted manually while an ASUB is being executed. This would otherwise cause the incorrect actual turret position to be detected.

Note

Calling the TM_REV_M.SPF starts a new tool change call (change request at turret interface in DB 73). If all is correct, setpoint position = actual position and no further movement of the turret is triggered. However, if an incorrect actual position is returned, this could cause the turret to swivel again. You should therefore only permit manual movement of the turret in NCK mode JOG and only permit the change request via the interface signal in DB 73 in NCK mode AUTO.

8.7 Moving the turret manually

Note

If you permit manual movement of the turret – even if the program has not been interrupted, you must ensure that the ASUB is executed without error and that the interrupted program can be resumed.

8.8 Configuring the operator interface

8.8 Configuring the operator interface

There are two ways you can modify the existing operator interface for the tool management system:

- In tool management, in addition to the tools, wear, and magazine lists, an additional list can also be activated on the 3rd horizontal softkey; (see section 8.8.1 "Integrating additional list").
- In these lists, depending on the tool, all existing or user-defined parameters can be configured; (see section 8.8.2 "Modifying lists").

8.8.1 Integrating additional list

To activate an additional list proceed as follows:

 Set machine data 9478 \$MM_TO_OPTION_MASK, Bit 2 = 1 Activate additional list

In tool management you can now, by means of the 3rd horizontal softkey, call up a list with the following parameters :

- "Length Y"
- "Wear length Y"

– "H number" .

Parameter "H number" will only be displayed if ShopTurn is set up for ISO dialects (see section 11.4 "ISO dialects").

 Specifying texts for additional list (optional) If you want to change the softkey label (OEM tool list) and header (OEM tool list) of the additional list, you must define new texts (see chapter 8.8.7 "Defining texts").
8.8.2 Configuring lists

To modify existing lists (including an integrated additional list) you must proceed as follows:

Activate the configuration file	Set the following machine data:
	MD 9478 \$MM_TO_OPTION_MASK, bit 8 Analyze the file TO_TURN.INI
	The configuration file TO_TURN.INI, in which you configure changes from the standard settings, is analyzed (see chapter 8.8.3 "Creating the configuration file").
Activate use of	If you use user-defined OEM data, set the following machine data:
OEM data	MD 18080 \$MN_MM_TOOL_MANAGEMENT_MASK, Bit 2 Provide memory for user data
	MD 18094 \$MN_MM_NUM_CC_TDA_PARAM Number of user-defined parameters
	MD 18095 \$MN_MM_TYPE_CC_TDA_PARAM[n]=4 Data type (REAL) of user-defined parameters
	MD 20310 \$MC_TOOL_MANAGEMENT_MASK, Bit 2 Activate user functions
	Texts for user-defined parameters (optional) If you want to change the column headers and cursor texts of the user-defined parameters, define new texts (see chapter 8.8.7 "Defining texts").
Adapt the configuration file	Specify all changes changes with respect to the default settings in the configuration file TO_TURN.INI; (see section 8.8.3 "Creating the configuration file").

8.8.3 Creating the configuration file

You must save all changes made in the lists with respect to the default setting in configuration file TO TURN.INI.

Please note the following:

- After the column "DP number" you can define further columns and also hide ٠ existing columns.
- The number of columns displayed is limited by the width of the window be-• cause each column has a fixed width. Horizontal scrolling is not possible.
- Per column define cutting edge parameters only, tool parameters only, or • magazine parameters only.
- Define the cutting edge parameters in consecutive columns.

The sample file TO TURN.INI, which can be adapted, is located in ShopTurn on NCU (HMI Embedded sl) under CYCLE STORAGE\SEQUENCER CYCLES\TEMPLATES ENG. The adapted file is then found on the CF card (NCU 7x0) under oem\sinumerik\hmi\cfg\ - user\sinumerik\hmi\cfg\.

For ShopTurn on PCU 50.3, this example is located on the supplied CD under Tools\TEMPLATES ENG.

The file is copied to the directory OEM or USER.

Syntax

Entries in the configuration file are subject to the following syntax rules; (see also example at end of this section):

First specify in which tool management list you would like to make changes. [DISPLAY IDENTIFIER] **DISPLAY IDENTIFIER: Tool management list**

> © Siemens AG 2008 All Rights Reserved SINUMERIK 840D sl Commissioning CNC: ShopTurn – 01/2008 Edition

Next define the changes themselves:

- Modify a specific column for all tools: COLUMNx=CONTENTS_IDENTIFIER COLUMN: Column command x: Column number, 1 – 12 CONTENTS_IDENTIFIER: Parameter or property of tool
- Modify a specific column for a specific tool: TOOL_IDENTIFIER = x=CONTENTS_IDENTIFIER TOOL_IDENTIFIER: Tool type
- Define different columns for each tool: TOOL_IDENTIFIER = CONTENTS_IDENTIFIER / CONTENTS_IDENTIFIER / ... TOOL_IDENTIFIER = CONTENTS_IDENTIFIER / CONTENTS_IDENTIFIER /

The parameters or properties of a tool are listed one after the other by means of a CONTENTS_IDENTIFIER and are separated from one another by a slash "/". If the default setting is to be used for individual columns, you still need to insert a forward slash.

If, for example, you only want to modify the last few columns, specify the number (x) of the first column you would like to modify and list the respective CONTENTS_IDENTIFIERs for the subsequent columns.

TOOL_IDENTIFIER = x=CONTENTS_IDENTIFIER / CONTENTS_IDENTIFIER / ...

Note

Using the COLUMN command, you can first define one column identically for all tools and then adapt it specifically for individual tools.

You can mark comments by means of a semicolon (;) symbol.

If errors occur during evaluation of the configuration file, refer to the TO_INI_F.LOG file for a description of the error. With ShopTurn on NCU (HMI Embedded sl), the file is located in drive I: and with the PCU 50.3 in the directory F:\MMC0W32\TMP.

Identifier The following tables list the SCREEN_IDENTIFIERS, TOOL_IDENTIFIERS, and CONTENTS_IDENTIFIERS available for defining the columns.

Table 8-2	SCREEN IDENTIFIER

SCREEN_IDENTIFIER	Tool management list
TOOL_LIST	Tool list
TOOL_LIST_2ND_EDGE	Tool list, further cutting edges
TOOL_WEAR	Tool wear list
TOOL_WEAR_2ND_EDGE	Tool wear list, further cutting edges
TOOL_MAGA	Magazine list
TOOL_LIST_OEM	Additional list
TOOL_LIST_OEM_2ND_EDGE	Further cutting edges

Table 8-3 TOOL_IDENTIFIER

TOOL_IDENTIFIER	ΤοοΙ
SHANK_END_CUTTER_TR	(End) cutter
END_MILL_CUTTER_TR	Facing tool
POINTED_DRILL_TR	(Twist) drill
ROUGHER	Roughing tool
FINISHER	Finishing tool
PARTING_OFF	Plunge cutter
SCREW_CUTTER	Threading tool
BUTTON	Button tool
STOPPER	Stop
TURN_DRILL	Rotary drill
TO_SCREW_TAP_TR	Screw tap
3DTRACER_TR	3D probe

Table 8-4 CONTENT_ID

CONTENT_ID	Parameter type *	Parameter or property	Field width in number of char- acters
EMPTY		Empty field	
NOT_USED		Empty column	
LENGTH1	S	Length X	7
LENGTH2	S	Length Z	7
LENGTH3	S	Length Y	7
RADIUS	S	Radius	7
RADIUS_ DIAM	S	Radius with possible diameter calculation	7

CONTENT_ID	Parameter type *	Parameter or property	Field width in number of char- acters
RADIUS_ DIAM9	s	Radius with possible diameter calculation – rotary drill bit radius	5
ANGLE_TR	S	Angle	5
CUTTDIR	S	Reference direction for holder angle	1
PLATELEN	S	Tip length	5
PLATEWID	S	Tip width	5
PLATEANG	S	Tip angle	2
PITCH	S	Pitch for screw tap	5
HOLDERANG	S	Holder angle	5
N	S	Number of teeth	2
SPINDLE	S	Spindle direction	1
COOL1	S	Cooling water 1	1
COOL2	S	Cooling water 2	1
DLENGTH1	S	Wear length X	7
DLENGTH2	S	Wear length Z	7
DLENGTH3	S	Wear length Y	7
DRADIUS	S	Wear radius	6
DRADIUS_ DIAM	s	Wear radius with possible diameter cal- culation	6
T_OR_C	W	Method of wear monitoring	1
P_TIME	S	Tool life	7
PW_TIME	S	Tool life warning limit	7
P_COUNT	S	Quantity	7
PW_COUNT	S	Pre-warning limit for count	7
P_WEAR	S	Wear	7
PW_WEAR	S	Prewarning limit for wear	7
T_LOCKED	W	Tool disabled	1
T_SIZE	W	Oversized tool	1
T_FIXED	W	Tool in fixed location	1
T_STATE	w	Status code: Active/prewarning limit reached/blocked	5

Table 8-4 CONTENT_ID

CONTENT_ID	Parameter type *	Parameter or property	Field width in number of char- acters
T_SIZE_ LONG	W	Tool size This parameter is not contained in the ShopTurn standard tool list. Column header: LROU Cursor text: Tool size Input: Number of adjacent half locations (maximum 7) to be blocked. The first half location is always the magazine location in which the tool is mounted. The number of adjacent half locations is specified as a four-digit number. The first digit is the number of adjacent locations to the left, the second to the right, the third above, and the fourth below. Requirement input: The tool must be lo- cated outside a magazine.	4
T_MAG_ PLACE_TYPE	w	Magazine location type This parameter is not contained in the ShopTurn standard tool list. Column header: Location type Cursor text: Magazine location type Input: Number of magazine location type Entry requirement: The tool must be lo- cated outside a magazine.	5
P_LOCKED	М	Magazine location locked	6
MAG_T_ LOCKED	w	Display only: Tool disabled	1
MAG_T_SIZE	W	Display only: Oversized tool	1
MAG_T_ FIXED	w	Display only: Tool in fixed location	1
H_NBR	S	H number of an ISO dialect program	3
TPC1	W	Parameter 1	7
TPC2	W	Parameter 2	7
TPC3	W	Parameter 3	7
TPC4	W	Parameter 4	7
TPC5	W	Parameter 5	7
TPC6	W	Parameter 6	7
TPC7	W	Parameter 7	7
TPC8	W	Parameter 8	7
TPC9	W	Parameter 9	7
TPC10	W	Parameter 10	7

Table 8-4 CONTENT_ID

* Parameter types: S = cutting edge data, W = tool data, M = magazine data.

Parameter "H number" will only be displayed if ShopTurn is set up for ISO dialects (see section 11.4 "ISO Dialects").

	;======================================			
-	[TOOL LIST OEM] ; screen OEM tool list;			
	;Default values for columns			
	COLUMN1 = LENGTH3			
	COLUMN2 = DLENGTH3			
	COLUMN3 = TPC1			
	COLUMN4 = TPC2			
	COLUMN5 = NOT_USED			
	COLUMN6 = NOT_USEDY			
	COLUMN7 = NOTUSED			
	COLUMN8 = NOT_USED			
	COLUMN9 = NOT_USED			
	COLUMN10= NOT_USED			
	COLUMN11= NOT_USED			
	COLUMN12= NOT_USED			
	In the example list, the following columns are to be displayed: Column 1: Tool length Y			
	Column 2: Wear Y			
	Column 3: 1. user-specific parameter			
	Column 4: 2. user-specific parameter			
	You have set the following machine data for the example shown:			
	MD 18080 \$MN_MM_TOOL_MANAGEMENT_MASK, bit 2 Provide memory for user data			
	MD 18094 \$MN_MM_NUM_CC_TDA_PARAM=2 For each of the user-defined parameters (TPC1 and TPC2)			
	MD 18095 \$MN_MM_TYPE_CC_TDA_PARAM[n]=4 Data type (REAL) of user–defined parameters			
	MD 20310 \$MC_TOOL_MANAGEMENT_MASK, bit 2 Activate user functions			

8.8.4 Adapting individual parameters

Using the configuration file to_turn.ini, you can change the default settings for specific tool parameters.

PARAMETER_IDENTIFIER	Parameter
T_MAG_PLACE_TYPE	Magazine location type
TPC1	Parameter 1
TPC2	Parameter 2
TPC3	Parameter 3
TPC4	Parameter 4
TPC5	Parameter 5

Table 8-5	PARAMETER	IDENTIFIER

	PARAMETER_IDENTIFIER	Parameter
	TPC6	Parameter 6
	TPC7	Parameter 7
	TPC8	Parameter 8
	TPC9	Parameter 9
	TPC10	Parameter 10
Magazine location type	You can change the input field into a to location type". The following values are	oggle field for the parameter "Magazine e entered: You must define the values of
	the toggle field in the section T_MAG_ cursor texts. Value = Text–ID Valid Text–IDs and information on defin "Defining texts").	PLACE_TYPE, by assigning values to ning texts are provided in Chapter 8.8.7
Example	[T_MAG_PLACE_TYPE] DEFAULT = 89891 1 = 89868 2 = 89869	
	 5 = 89872 9 = 89876 In this example, in the column "location or 9 using the "alternative" softkeys. Hected. Cursor texts that have been sa If the actual value of the parameter det text, saved as DEFAULT, is displayed. 	n type" you can select the values 1, 2, 5 ere, the values have been randomly se- ved are displayed for the selected values. vices from the configured values, then the as cursor text.
OEM parameter	You can change the input fields into toggle fields for the OEM tool parameters In so doing, specific values are entered. You must define the values of the toggle field in Sections TPC1 TPC10, by assigning cursor texts to the values (refer to Chapter 8.8.7 "Defining texts"). Also refer to the example on "Magazine location type" parameters. You can define the width of the toggle field or the input field to a specific numl	
	of characters. The standard width is 7 Further, for the input field, you can also however, only if you have not specified data type, then, the double data type s	characters. o specify the data type (integer or double), a toggle field. If you do not change the set as default, is used.

Table 8-5 PARAMETER_IDENTIFIER

Example

[TPC1] WIDTH = 2 TYPE = INTEGER

In this example, the input fields of the column OEM tool parameter 1 are 2 characters wide. You can only enter integer values in the input fields.

8.8.5 Defining texts for the magazine locations on the intermediate buffer

The magazine locations of the buffer are shown, as standard using symbols in the tool manager lists. You can assign texts to the location using the configuration file to_turn.ini.

ID for the buffer: BUFFER

In the section BUFFER, the magazine locations of the buffer are assigned texts.

Magazine location = Text-ID

Valid text IDs and information on defining texts are provided in Chapter 8.8.7 "Defining texts").

Example

[BUFFER] DEFAULT = 89768 1 = 89790 2 = 89791 3 = 89792

In this example, three magazine locations of the buffer (spindle, gripper 1 and gripper 2) are assigned texts for the display in the tool manager lists. A default text is displayed for additional magazine locations of the buffer.

8.8.6 Designating a load magazine in the tool list sorted according to magazines

If the tool list is sorted according to magazines, all of the magazine locations are displayed in an increasing sequence according to magazine location and magazine number. Using the configuration file to_turn.ini, a magazine can be high-lighted as a load magazine by sorting this magazine so that it is directly at the beginning of the tool list (sorted according to magazines).

ID for the load magazine: OEM_LOAD_MAGAZINE

Example [OEM_LOAD_MAGAZINE] MAGAZINE = 3

In this example, magazine 3 is configured as load magazine,. The magazine locations of magazine 3 are displayed directly at the beginning of the tool list that is sorted according to magazine locations.

8.8.7 Define texts

Texts (softkey name and list header for additional lists, column headers, and cursor texts for user-defined parameters) are assigned to specific text numbers in a text file.

These are subject to the following syntax: Text number 0 0 "Text"

The two parameters 2 and 3 separated by blanks are control characters for text output and must always be set to 0.

The column header in the parameter name can consist of three lines, each line with its own text number; (see Table 8-6).

Table 8-6 Text assignment

Text type	Text number
3rd horizontal softkey	89923
List header	89924
Column header parameter TPC1	89925, 89926, 89927
Cursor text parameter TPC1	89931
Column header parameter TPC2	89928, 89929, 89930
Cursor text parameter TPC2	89932
Column header parameter TPC3	89953, 89954, 89955
Cursor text parameter TPC3	89965
Column header parameter TPC4	89937, 89938, 89939
Cursor text parameter TPC4	89949
Column header parameter TPC5	89940, 89941, 89942

Text type	Text number
Cursor text parameter TPC5	89950
Column header parameter TPC6	89943, 89944, 89945
Cursor text parameter TPC6	89951
Column header parameter TPC7	89956, 89957, 89958
Cursor text parameter TPC7	89966
Column header parameter TPC8	89946, 89947, 89948
Cursor text parameter TPC8	89952
Column header parameter TPC9	89959, 89960, 89961
Cursor text parameter TPC9	89967
Column header parameter TPC10	89962, 89963, 89964
Cursor text parameter TPC10	89968

Example: 89924 0 0 "Tool data"

The texts must not exceed the following number of characters: Softkey: 6 List header: 20 Column header parameter: 7 Cursor text parameter: 45

A line break in the softkey text can be made by inserting two consecutive blanks.

Note

Table 8-6

Text assignment

The columns for parameters TPC1 and TPC2 are already preset with example texts; these can be modified.

Magazine location type, OEM parameter, magazine locations of the buffer The texts for the magazine locations of the buffer and the cursor texts for the parameter, magazine location type and OEM parameter must be located as toggle field in the number range 89700 to 89899.

ShopTurn on NCU	With ShopTurn on NCU (HMI Embedded sl), enter the texts and numbers in the text file ALLIC TXT. There is an ALLIC TXT text file in each language directory.

PCU 50.3

With the PCU 50.3 enter the texts and numbers in the text file F:\DH\CUS.DIR\ALUC_xx.COM. If the ALUC_xx.COM file does not exist, you need to create it in the CUS.DIR directory. The texts are assigned to a language by means of the text file name. In the text file name "xx" is replaced by one of the following codes:

Abbreviation XX	Language
gr	German
uk	English
fr	French
it	Italian
sp	Spanish
nl	Dutch
dk	Danish
fi	Finnish
SW	Swedish
pl	Polish
tr	Turkish
ch	Simplified Chinese
tw	Chinese (Traditional)
ko	Korean
hu	Hungarian
ро	Brazilian Portuguese
ru	Russian
cz	Czech
ja	Japanese

Table 8-7 Language assignment

In the file F:\USER\MBDDE.INI or F:\OEM\MBDDE.INI add the following line in the section [TextFiles]: UserZYK=F:\dh\cus.dir\aluc_

8.9 Reading in tool data

Tool data that has been defined on an external tool presetting device can be imported directly into ShopTurn tool management.

Save the tool data as an INI file.

The header in the file must be exactly as follows:

;TOOL MAGAZIN ZEROPOINT,TOOL=2,MAGAZIN=0,NPV=0,BNPV=0

However, you can modify the values for "Tool" and "Magazine".

Tool=1:	Delete all existing tools in tool management and replace with new tools.
Tool=2:	Add new tools to tool management
Magazine=0:	Do not evaluate magazine location number (\$TC_MPP6)
Magazine=1:	Evaluate magazine location number (\$TC_MPP6)

Note

Always keep to the precise order (including blanks) in the header. If you enter an incorrect header line, the INI file on opening will be evaluated as a G code program. Starting the program with "Cycle start" causes existing data in tool management to be overwritten by the data contained in the program.

The tool data must be assigned the following variables in the INI file, where:

- x = tool number
- y = cutting edge number

Variable Value Description \$TC_TP1[x] Duplo number Number \$TC_TP2[x] Tool name Name \$TC TP3[x] Number of adjacent half locations on ShopTurn default setting the left to be blocked for oversized 1 = Do not block adjacent location tools. or 2 = Block half of adjacent location on the left ShopTurn default setting \$TC_TP4[x] Number of adjacent half locations on the right to be blocked for oversized 1 = Do not block adjacent location tools. or 2 = Block half of adjacent location on the right \$TC TP5[x] Number of adjacent half locations ShopTurn default setting above to be blocked for oversized 1 = Do not block adjacent location tools. \$TC TP6[x] Number of adjacent half locations be-ShopTurn default setting low to be blocked for oversized tools. 1 = Do not block adjacent location \$TC_TP7[x] Magazine location type Number \$TC_TP8[x] Tool status Bit 1 = 1: Tool enabled Bit 2 = 1: Tool disabled Bit 4 = 1: Prewarning limit reached

Table 8-8Variable assignment

8 Tool Management

8.9 Reading in tool data

Variable	Description	Value
\$TC_TP9[x]	Tool monitoring	Bit 0 = 1: Tool life monitoring active Bit 1 = 1: Workpiece count monitoring active Bit 2 = 1: Wear monitoring active
\$TC_TPC1[x]	User-defined parameter 1	
\$TC_TPC2[x]	User-defined parameter 2	
\$TC_TPC3[x]	User-defined parameter 3	
\$TC_TPC4[x]	User-defined parameter 4	
\$TC_TPC5[x]	User-defined parameter 5	
\$TC_TPC6[x]	User-defined parameter 6	
\$TC_TPC7[x]	User-defined parameter 7	
\$TC_TPC8[x]	User-defined parameter 8	
\$TC_TPC9[x]	User-defined parameter 9	
\$TC_TPC10[x]	User-defined parameter 10	
\$TC_DP1[x,y]	Tool type	120: Cutter 140: Facing tool 200: Drill 240: Tap 500: Roughing tool 510: Finishing tool 520: Plunge–cutter 540: Threading tool 550: Button 560: Rotary drill 580: 3D probe 750: Stop
\$TC_DP2[x,y]	Length of cutting edge	When machining behind the turning center, the tool tip is pointing to: 1: Top right 2: Top left 3: Bottom left 4: Botton right 5: Right 6: Top 7: Left 8: Bottom 9: Tool tip = tool nose center
\$TC_DP3[x,y]	Length or	Number [mm]
	Length X	Number [mm]
\$TC_DP4[x,y]	Length 2	Number [mm]
	or Length Z	Number [mm]
\$TC_DP5[x,y]	Length 3 or Length Y	Number [mm] Number [mm]
\$TC_DP6[x,y]	Radius	Number [mm]
	or internal radius (facing tool)	Number [mm]
\$TC_DP7[x,y]	External radius	Number [degrees]
\$TC_DP8[x,y]	Tip length	Number [mm]
\$TC_DP9[x,y]	Tip width	Number [mm]
\$TC_DP10[x,y]	Holder angle	Number [degrees]

Table 8-8 Variable assignment

8.9 Reading in tool data

Variable	Description	Value
\$TC_DP11[x,y]	Reference direction for holder angle	 Traversing motion in negative direction, x– Traversing motion in positive direction, x+ Longitudinal travel in negative direction, z– Longitudinal travel in positive direction, z+
	tool angle/chamfer angle (facing tool)	Number [degrees]
\$TC_DP12[x,y]	Wear length	Number [mm]
	or Wear length X	Number [mm]
\$TC_DP13[x,y]	Wear length 2 or	Number [mm]
	Wear length Z	Number [mm]
\$TC_DP14[x,y]	Wear length 3	Number [mm] or
	Wear length Y	Number [mm]
\$TC_DP15[x,y]	Wear radius	Number [mm]
\$TC_DP24[x,1]	Number of teeth (milling tool)	Number
\$TC_DP24[x,y]	tool tip angle (drill) or	Number [degrees]
\$TC_DP24[x,y]	tool clearance angle (turning tool) ShopTurn calculates the tip angle from the tool clearance angle and dis- plays this in tool management: Tip angle = 180 – tool clearance angle – holder angle.	Number [degrees]
\$TC_DP25[x,1]	Direction of spindle rotation Coolant M function	Bit 8 and bit 9 = 0: Spindle stop Bit 8 = 1: Spindle rotates clockwise Bit 9 = 1: Spindle rotates counter-clockwise Bit 10 = 1: Cooling water 1 ON Bit 11 = 1: Cooling water 2 ON Bit 0 = 1: M function 1 Bit 1 = 1: M function 2 Bit 2 = 1: M function 3 Bit 3 = 1: M function 4
\$TC_DPH[x,y]	H number of an ISO dialect program	Number
<pre>\$TC_MOP1[x,y]</pre>	Tool life warning limit	Number [min]
\$TC_MOP2[x,y]	Tool life	Number [min]
\$TC_MOP3[x,y]	Pre-warning limit for count	Number
\$TC_MOP4[x,y]	Quantity	Number
\$TC_MOP5[x,y]	Prewarning limit for wear	Number [mm]
\$TC_MOP15[x,y]	Maximum wear	Number [mm]
\$TC_MPP6[n,m]	Magazine location number	Number n: Magazine number m: Magazine location number

Table 8-8 Variable assignment

For bit-coded parameters you must specify a hexadecimal value.

The H number for ISO dialect programs will only be evaluated if ShopTurn is set up for ISO dialects (see Section 11.4 "ISO Dialects").

8.9 Reading in tool data

If you do not define parameters, tool management will subsequently set them to zero.

You must program the command "M30" at the end of the file.

For information about importing tool data into tool management, please refer to: **References:** /BATsI/, ShopTurn Operating/Programming Guide

Example

;TOOL MAGAZINE ZEROPOINT,TOOL=2,MAGAZINE=0,NPV=0,BNPV=0 \$TC TP1[1]=1 ;Duplo number \$TC_TP2[1]=ROUGHING TOOL ;Tool "ROUGHING TOOL" \$TC TP3[1]=1 ;Adjacent location on left unoccupied \$TC TP4[1]=1 ;Adjacent location on right unoccupied \$TC TP5[1]=1 ;Adjacent location above unoccupied \$TC TP6[1]=1 ;Adjacent location below unoccupied \$TC TP7[1]=1 ;Magazine location type \$TC_TP8[1]=2 ;Tool enabled \$TC_TP9[1]=1 ;Tool life monitoring \$TC_DP1[1,1]=500 ;Tool type, roughing tool \$TC_DP2[1,1]=3 ;Cutting edge position (left bottom) \$TC DP3[1,1]=35.92 ;Length X \$TC DP4[1,1]=67.89 ;Length Z \$TC DP6[1,1]=0.6 ;Radius \$TC_DP8[1,1]=14 ;Tip length \$TC DP10[1,1]=93 ;Holder angle ;Reference direction for holder angle \$TC DP11[1,1]=3.0 ;-Z direction \$TC DP24[1,1]=2 ;Tool clearance angle ;End of program M30

Additional Functions

9.1 Measuring cycle

9.1.1 Brief description

Overview	You can use a measuring cycle for automatic measurement of tools on turning machines with ShopTurn.				
	This is achieved simply by connecting a touch trigger probe to the control				
	References:	/FB2/, Function Manual on Expansion Functions, Measuring (M5); /GDsl/, Device Manual NCU, SINUMERIK 840D sl /IDsl/, Commissioning Manual CNC: NCK, PLC, drive, SINUMERIK 840D sl,			
Measuring cycle	The measuring c	ycle is supplied with ShopTurn.			
	You have to adap machine.	ot the measuring cycle data to the specific characteristics of the			
Function test	The probe operates internally with the command MEAS.				
	The function test of the probe is conducted using a part program. References: /PGA/, Programming Manual on Production Planning /BNM/, Programming Manual on Measuring cycles				

9.1 Measuring cycle

9.1.2 Display machine data for measuring cycle

9749	CMM_ENAB	CMM_ENABLE_MEAS_T_AUTO					
MD number	Enable auton	natic tool measure	ement				
Default setting: 1	•	Min. input limit: (0		Max. input lin	nit: 1	
Changes effective as from	NOW Protection level: 3/4 Units: –				Units: –		
Data type: WORD	Valid as of software version: ShopTurn 6.4						
Significance:	This MD enal 0 = "Automat 1 = "Automat	This MD enables the "Automatic tool measurement" function on the user interface. 0 = "Automatic tool measurement" function is not displayed 1 = "Automatic tool measurement" function is displayed					

9751	CMM_MEAS	CMM_MEAS_T_PROBE_INPUT						
MD number	Measuring in	put for tool prob	ре					
Default setting: 0		Min. input limit: 0 Max. input limit: 1						
Changes effective as from	NOW	Protection level: 3/4				Units: –		
Data type: BOOL		Valid as of software version:						
	ShopTurn 6.3							
Significance:	This MD is used to stipulate the number of the input for the tool probe for the main spindle.							
	0 = Measuring input 1 is activated							
	1 = Measurin	1 = Measuring input 2 is activated						

9754	CMM_MEAS_DIST_TOOL_LENGTH					
MD number	Maximum me	easurement distan	ice for tool le	ength for rotati	ng Spindle	
Default setting: 10	- -	Min. input limit: 0	0.001		Max. input lin	nit: 1000
Changes effective as from	NOW	/ Protection level: 3/4 Units: mm				Units: mm
Data type: DOUBLE	Valid as of software version:					
	ShopTurn 6.4					
Significance:	This MD stipulates the maximum measurement distance before and after the expected switching					
	position (tool length) for measuring the tool length with rotating spindle. If no switching signal is output within this range the error message "Probe does not switch" is output.					

9759	CMM_MAX_CIRC_SPEED_ROT_SP						
MD number	Maximum cire	Maximum circumferential speed for tool measurement for rotating Spindle					
Default setting: 100	·	Min. input limit: 1		Max. input lin	nit: 200		
Changes effective as from	NOW	NOW Protection level: 3/4 Units: m/min					
Data type: DOUBLE	Valid as of software version:						
	ShopTurn 6.3						
Significance:	This MD is used to stipulate the maximum permissible circumferential speed of the tools to be						
	measured for tool measurement with rotating spindle. The permissible spindle speed for carrying						
	out tool meas	surement is calculated accord	ling to this MD				

01/2008

9 Additional Functions

9.1 Measuring cycle

9760	CMM_MAX_	CMM MAX SPIND SPEED ROT SP						
MD number	Maximum spe	eed for tool me	asurement for	rotating Spind	lle			
Default setting: 1000		Min. input limit: 100 Max. input limit: 25000						
Changes effective as from	NOW	Protection level: 3/4			Units: rev/min			
Data type: DOUBLE	ata type: DOUBLE Valid as of software version: ShopTurn 6.3							
Significance:	This MD is us measured for	This MD is used to stipulate the maximum permissible rotational speed of the tools to be measured for tool measurement with rotating spindle.						

9771	CMM_MAX_	CMM_MAX_FEED_ROT_SP				
MD number	Maximum fee	Vaximum feed for tool measurement for rotating Spindle				
Default setting: 20		Min. input limit: 1			Max. input lir	nit: 1000
Changes effective as from	NOW	Protection level: 3/4			Units: mm/min	
Data type: DOUBLE		Valid as			ftware versior	1:
				ShopTurn 6.4	ŀ	
Significance:	This MD is us	sed to stipulate	the feed rate	for tool measu	rement with ro	tating spindle.

9772	CMM_T_PR	CMM_T_PROBE_MEASURING_DIST				
MD number	Measuremen	t distance for to	ool measurem	ent with statior	nary spindle	
Default setting: 10	Min. input limit: 1 Max. input limit: 1000				nit: 1000	
Changes effective as from	NOW	Protection level: 3/4			Units: mm	
Data type: DOUBLE				Valid as of so	oftware version	:
	ShopTurn 6.4					
Significance:	This MD is used to stipulate the measurement distance for tool measurement with stationary					
	spindle and d	uring probe ca	libration.			

9773	CMM_T_PR	CMM_T_PROBE_MEASURING_FEED			
MD number	Feed rate for	Feed rate for tool measurement with stationary spindle			
Default setting: 300	Min. input limit: 10 Max. input limit: 5000				nit: 5000
Changes effective as from	NOW	Protection level: 3/4			Units: mm/min
Data type: DOUBLE	Valid as of software version:			:	
	ShopTurn 6.4				
Significance:	This MD is used to stipulate the feed for tool measurement with stationary spindle and during probe calibration.				

9828	ST_MEAS_T_PROBE_INPUT_SUB					
MD number	Input number	Input number for tool probe for counterspindle				
Default setting: 1	Min. input limit: 0 Max. input limit: 1			nit: 1		
Changes effective as from	NOW	Protection level: 3/4		el: 3/4		Units: –
Data type: UNSIGNED WORD				Valid as of software version:		
ShopTurn 6.3						
Significance:	This MD is us	sed to stipulate th	he number of	the input for t	he tool probe f	or the counter–spindle.
	0 = Measuring input 1 is activated					
	1 = Measuring input 2 is activated					

9.2 Network link

9.2 Network link

Option

The function "Manage up to 4 additional network drives" is an option with Order No. 6FC5 800–0AP01–0YB0.

For installing the network, please refer to

References: /IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840D/840Di; /IHE/, Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl

9.3 Cylinder surface transformation, end face machining

9.3.1 General

The cylinder surface transformation and end face machining functions can be used to machine the peripheral and end faces of a turned part.

The functions "cylinder surface transformation" (Tracyl) and "face end machining" (Transmit) are a software option set on the CNC–ISO operator interface. The Order No. is: 6FC5 800–0AM27–0YB0.

These functions must also be set up via machine data.

- Face-end machining main spindle: Transformation 1 MD 24100 \$MC_TRAFO_TYPE_1=256 (without Y axis) MD 24100 \$MC_TRAFO_TYPE_1=257 (with Y axis)
- Face-end machining counter-spindle: Transformation 2 MD 24200 \$MC_TRAFO_TYPE_2=256 (without Y axis) MD 24200 \$MC_TRAFO_TYPE_2=257 (with Y axis)
- Cylinder surface transformation main spindle: Transformation 3 without groove side offset (without Y axis): MD 24300 \$MC_TRAFO_TYPE_3=512 with groove side offset (with Y axis): MD 24300 \$MC_TRAFO_TYPE_3=513 with groove side offset and Y correction: MD 24300 \$MC_TRAFO_TYPE_3=514
- Cylinder surface transformation counter–spindle: Transformation 4 without groove side offset (without Y axis): MD 24400 \$MC_TRAFO_TYPE_4=512 with groove side offset (with Y axis): MD 24400 \$MC_TRAFO_TYPE_4=513 with groove side offset and Y correction: MD 24400 \$MC_TRAFO_TYPE_4=514

Note

For each of the individual transformations you must also set up other machine data (see following sections).

The "cylinder surface transformation" and "end face machining" functions are automatically integrated in the ShopTurn cycles, with the exception of "straight line" and "circle". For these two cycles you can call the functions in the Program operating area under Straight line, Arc, Tool.

References: /BATsl/, ShopTurn Operating/Programming Guide

9.3.2 Example: X axis and Z axis, main spindle and tool spindle

For example, for a turning machine with X and Z axes, main spindle (C1) and tool spindle (WZ) you must configure the following machine data:

	2008020080 20080 20080 20080	<pre>\$MC_AXCONF_CHANAX_NAME_TAB[0]="XC" Channel axis XC \$MC_AXCONF_CHANAX_NAME_TAB[1]="ZC" Channel axis ZC \$MC_AXCONF_CHANAX_NAME_TAB[2]="C1" Channel axis C1 \$MC_AXCONF_CHANAX_NAME_TAB[3]="WZ" Channel axis WZ</pre>
	General settir 10602 Take coordina between geor 24040 Adaptation of 28082 Configuring o	ngs for transformations: \$MN_FRAME_GEOAX_CHANGE_MODE=1 ate transformations in total frame into account when switching metry axes \$MC_FRAME_ADAPT_MODE=H7 factive frames \$MC_MM_SYSTEM_FRAME_MASK, Bit 6=1 f channel–specific system frames included in channel calculation
Face end	Data set for fa	ace end machining (main spindle):
machining	24100	\$MC_TRAFO_TYPE_1=256 Definition of 1st transformation in channel: TRANSMIT main spindle
	24110	\$MC_TRAFO_AXES_IN_1[0]=1 Channel axis perpendicular to rotary axis (XC) for 1st transformation
	24110	\$MC_TRAFO_AXES_IN_1[1]=3 Channel axis of rotary axis (C1) for 1st transformation
	24110	\$MC_TRAFO_AXES_IN_1[2]=2 Channel axis parallel to rotary axis (ZC) for 1st transformation
	24120	\$MC_TRAFO_GEOAX_ASSIGN_TAB_1[0]=1 1st channel axis (X) for 1st transformation
	24120	\$MC_TRAFO_GEOAX_ASSIGN_TAB_1[1]=3 2nd channel axis (Y) for 1st transformation
	24120	\$MC_TRAFO_GEOAX_ASSIGN_TAB_1[2]=2 3rd channel axis (Z) for 1st transformation
	24900	\$MC_TRANSMIT_ROT_AX_OFFSET_1=0 Offset of rotary axis for 1st TRANSMIT transformation
	24905	\$MC_TRANSMIT_ROT_AX_FRAME_1=2 Axial offset of rotary axis is taken into account during TRANSMIT
	24910	\$MC_TRANSMIT_ROT_SIGN_IS_PLUS_1=0 Arithmetic sign of rotary axis for 1st TRANSMIT transformation
	24911	\$MC_TRANSMIT_POLE_SIDE_FIX_1=1 Restriction of working area in front of/behind pole,
	24920	SC TRANSMIT transformation \$MC_TRANSMIT_BASE_TOOL_1[0]=0 Vector of basic tool for 1st TRANSMIT transformation

9.3	Cylinder	surface	transformation,	end face	machining

Cylinder surface transformation	Data set for cylinder surface transformation without groove side offset (main spindle):				
without aroove	24300	\$MC_TRAFO_TYPE_3=512			
side offset		Definition of 3rd transformation in channel: TRACYL main spindle			
	24310	\$MC_TRAFO_AXES_IN_3[0]=1			
		Channel axis perpendicular to rotary axis (XC) for 3rd transformation			
	24310	\$MC_TRAFO_AXES_IN_3[1]=3			
		Channel axis of rotary axis (C1) for 3rd transformation			
	24310	\$MC_TRAFO_AXES_IN_3[2]=2			
		Channel axis parallel to rotary axis (ZC) for 3rd transformation			
	24320	\$MC_TRAFO_GEOAX_ASSIGN_TAB_3[0]=1			
		1st channel axis (X) for 3rd transformation			
	24320	\$MC_TRAFO_GEOAX_ASSIGN_TAB_3[1]=3			
		2nd channel axis (Y) for 3rd transformation			
	24320	\$MC_TRAFO_GEOAX_ASSIGN_TAB_3[2]=2			
		3rd channel axis (Z) for 3rd transformation			
	24800	\$MC_TRACYL_ROT_AX_OFFSET_1=0			
		Offset of rotary axis for 1st TRACYL transformation			
	24805	\$MC_TRACYL_ROT_AX_FRAME_1=2			
		Axial offset of rotary axis is taken into account during TRACYL			
	24810	\$MC_TRACYL_ROT_SIGN_IS_PLUS_1=1			
		Arithmetic sign of rotary axis for 1st TRACYL transformation			
	24820	\$MC_TRACYL_BASE_TOOL_1[n]=0			
		Vector of basic tool for 1st TRACYL transformation			

9.3.3 Example: X axis and Z axis, main spindle and tool spindle, Y axis

	For example, and tool spine	for a turning machine with X, Z, and Y axes, main spindle (C1) dle (WZ) you must configure the following machine data:
	2008020080	\$MC_AXCONF_CHANAX_NAME_TAB[0]="XC" Channel axis XC
	20080	\$MC_AXCONF_CHANAX_NAME_TAB[1]="ZC" Channel axis ZC
	20080	\$MC_AXCONF_CHANAX_NAME_TAB[2]="C1" Channel axis C1
	20080	\$MC_AXCONF_CHANAX_NAME_TAB[3]="WZ" Channel axis WZ
	20080	\$MC_AXCONF_CHANAX_NAME_TAB[5]="YC" Channel axis YC
	General setti 10602 Take coordin	ngs for transformations: \$MN_FRAME_GEOAX_CHANGE_MODE=1 ate transformations in total frame into account when switching
	between geo 24040	metry axes \$MC_FRAME_ADAPT_MODE=H7
	Adaptation of	factive frames
	28082 Qaafi waxia a	\$MC_MM_SYSTEM_FRAME_MASK, Bit 6=1
	Configuring c	or channel-specific system frames included in channel calculation
Face end	Data set for f	ace end machining (main spindle):
machining	24100	SMC_TRAFO_TYPE_1=257 Definition of 1st transformation in channel:
	04110	TRANSMIT main spindle
	24110	SINC_IMAPO_AXES_IN_I[U]=1 Channel axis perpendicular to rotary axis (XC) for 1st transformation
	24110	\$MC TRAFO AXES IN 1[1]=3
		Channel axis of rotary axis (C1) for 1st transformation
	24110	\$MC_TRAFO_AXES_IN_1[2]=2
		Channel axis parallel to rotary axis (ZC) for 1st transformation
	24120	\$MC_TRAFO_GEOAX_ASSIGN_TAB_1[0]=1
	04400	1st channel axis (X) for 1st transformation
	24120	\$MC_IRAFO_GEOAX_ASSIGN_IAB_1[1]=3
	2/120	SMC TRAFO GEOAX ASSIGN TAB 1[2]-2
	24120	3rd channel axis (Z) for 1st transformation
	24900	\$MC TRANSMIT ROT AX OFFSET 1=0
		Offset of rotary axis for 1st TRANSMIT transformation
	24905	\$MC_TRANSMIT_ROT_AX_FRAME_1=2
		Axial offset of rotary axis is taken into account during TRANSMIT
	24910	\$MC_TRANSMIT_ROT_SIGN_IS_PLUS_1=0
	04011	Arithmetic sign of rotary axis for 1st TRANSMIT transformation
	24911	Divid_IMANDIVIT_PULE_DIDE_FIX_1=1 Postriction of working area in front of/bobind polo
		1st TRANSMIT transformation
	24920	SMC TRANSMIT BASE TOOL 101=0
	2.020	Vector of basic tool for 1st TRANSMIT transformation

9.3	Cylinder	surface	transformation,	end face	machining

Cvlinder surface	Data set for c	vlinder surface transformation with groove side offset (main spindle):
transformation	24300	\$MC TRAFO TYPE 3=513
with groove side		Definition of 3rd transformation in channel: TRACYL main spindle
offect	24310	\$MC TRAFO AXES IN 3[0]=1
Unset		Channel axis perpendicular to rotary axis (XC) for 3rd transformation
	24310	\$MC TRAFO AXES IN 3[1]=3
		Channel axis of rotary axis (C1) for 3rd transformation
	24310	\$MC TRAFO AXES IN 3[2]=2
		Channel axis parallel to rotary axis (ZC) for 3rd transformation
	24310	\$MC TRAFO AXES IN 3[3]=6
	24010	Channel axis parallel to cylinder peripheral surface and perpendicular to
		rotary axis (ZC) for 3rd transformation
	24320	\$MC TRAFO GEOAX ASSIGN TAB 3[0]=1
		1st channel axis (X) for 3rd transformation
	24320	\$MC TRAFO GEOAX ASSIGN TAB 3[1]=3
		2nd channel axis (Y) for 3rd transformation
	24320	\$MC TRAFO GEOAX ASSIGN TAB 3[2]=2
		3rd channel axis (Z) for 3rd transformation
	24800	\$MC_TRACYL_ROT_AX_OFFSET_1=0
		Offset of rotary axis for 1st TRACYL transformation
	24805	\$MC_TRACYL_ROT_AX_FRAME_1=2
		Axial offset of rotary axis is taken into account during TRACYL
	24810	\$MC_TRACYL_ROT_SIGN_IS_PLUS_1=1
		Arithmetic sign of rotary axis for 1st TRACYL transformation
	24820	\$MC_TRACYL_BASE_TOOL_1[n]=0
		Vector of basic tool for 1st TRACYL transformation

9.3.4 Example: X axis and Z axis, main spindle, tool spindle and counter–spindle

	For example, spindle (WZ) chine data:	for a turning machine with X and Z axes, main spindle (C1), tool , and counter-spindle (C2) you must configure the following ma-
	2008020080	\$MC_AXCONF_CHANAX_NAME_TAB[0]="XC" Channel axis XC
	20080	\$MC_AXCONF_CHANAX_NAME_TAB[1]="ZC" Channel axis ZC
	20080	\$MC_AXCONF_CHANAX_NAME_TAB[2]="C1" Channel axis C1
	20080	\$MC_AXCONF_CHANAX_NAME_TAB[3]="WZ" Channel axis WZ
	20080	\$MC_AXCONF_CHANAX_NAME_TAB[4]="C2" Channel axis C2
	General setti	ngs for transformations: \$MN_EBAME_GEOAX_CHANGE_MODE-1
	Take coordin	ate transformations in total frame into account when switching
	between geo	metry axes
	24040	\$MC_FRAME_ADAPT_MODE=H7
	Adaptation of	f active frames
	28082	\$MC_MM_SYSTEM_FRAME_MASK, Bit 6 = 1
	Configuring c	of channel-specific system frames included in channel calculation
Face end	Data set for f	ace end machining (counter-spindle):
machining	24200	\$MC_TRAFO_TYPE_2=256
		Definition of 2nd transformation in channel:
		TRANSMIT counter-spindle
	24210	\$MC_IRAFO_AXES_IN_2[0]=1
	04010	Channel axis perpendicular to rotary axis (XC) for 2nd transformation
	24210	\$MU_IRAFU_AXES_IN_2[I]=5 Chapped axis of retary axis (C2) for 2nd transformation
	24210	SMC TRAFO AXES IN 2[2]-2
	24210	Channel axis parallel to rotary axis (ZC) for 2nd transformation
	24220	SMC TRAFO GEOAX ASSIGN TAB 2[0]=1
		1st channel axis (X) for 2nd transformation
	24220	\$MC TRAFO GEOAX ASSIGN TAB 2[1]=5
		2nd channel axis (Y) for 2nd transformation
	24220	\$MC_TRAFO_GEOAX_ASSIGN_TAB_2[2]=2
		3rd channel axis (Z) for 2nd transformation
	24950	\$MC_TRANSMIT_ROT_AX_offset_2=0
		Offset of rotary axis for 2nd TRANSMIT transformation
	24955	\$MC_TRANSMIT_ROT_AX_FRAME_2=2
	0.0000	Axial offset of rotary axis is taken into account during TRANSMIT
	24960	\$MC_IHANSMII_HOI_SIGN_IS_PLUS_2=0
	04061	Arithmetic sign of rotary axis for 2nd I HANSMIT transformation
	24901	PIVIO_IMANOVIII_POLE_OIDE_FIA_2=1 Restriction of operating area in front of/bobind the pole

2nd TRANSMIT transformation

\$MC_TRANSMIT_BASE_TOOL_2[0]=0

Vector of basic tool for 2nd TRANSMIT transformation

24970

9.3	Cylinder	surface	transformation,	end face	machining

Cylinder surface transformation	Data set fo offset):	Data set for cylinder surface transformation on counter-spindle (without groov offset):		
without groove side offset	24400	\$MC_TRAFO_TYPE_4=512		
		Definition of 4th transformation in channel: TRACYL counter-spindle		
	24410	\$MC_TRAFO_AXES_IN_4[0]=1		
		Channel axis perpendicular to rotary axis (XC) for 4th transformation		
	24410	\$MC_TRAFO_AXES_IN_4[1]=5		
		Channel axis of rotary axis (C2) for 4th transformation		
	24410	\$MC_TRAFO_AXES_IN_4[2]=2		
		Channel axis parallel to rotary axis (ZC) for 4th transformation		
	24420	\$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1		
		1st channel axis (X) for 4th transformation		
	24420	\$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5		
		2nd channel axis (Y) for 4th transformation		
	24420	\$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2		
		3rd channel axis (Z) for 4th transformation		
	24850	\$MC_TRACYL_ROT_AX_offset_2=0		
		Offset of rotary axis for 2nd TRACYL transformation		
	24855	\$MC_TRACYL_ROT_AX_FRAME_2=2		
		Axial offset of rotary axis is taken into account during TRACYL		
	24860	\$MC_TRACYL_ROT_SIGN_IS_PLUS_2=1		
		Arithmetic sign of rotary axis for 2nd TRACYL transformation		
	24870	\$MC_TRACYL_BASE_TOOL_2[n]=0		
		Vector of basic tool for 2nd TRACYL transformation		

9.3.5 Example: X axis and Z axis, main spindle, tool spindle, and counter–spindle, Y axis

For example, for a turning machine with X, Z, and Y axes, main spindle (C1), tool spindle (WZ), and counter–spindle (C2) you must configure the following machine data:

20080	\$MC_AXCONF_CHANAX_NAME_TAB[0]="XC" Channel axis XC
20080	\$MC_AXCONF_CHANAX_NAME_TAB[1]="ZC" Channel axis ZC
20080	\$MC_AXCONF_CHANAX_NAME_TAB[2]="C1" Channel axis C1
20080	\$MC_AXCONF_CHANAX_NAME_TAB[3]="WZ" Channel axis WZ
20080	\$MC_AXCONF_CHANAX_NAME_TAB[4]="C2" Channel axis C2
20080	\$MC_AXCONF_CHANAX_NAME_TAB[5]="YC" Channel axis YC

General settings for transformations: 10602 \$MN_FRAME_GEOAX_CHANGE_MODE=1 Take coordinate transformations in total frame into account when switching between geometry axes 24040 \$MC_FRAME_ADAPT_MODE=H7 Adaptation of active frames 28082 \$MC_MM_SYSTEM_FRAME_MASK, Bit 6 = 1 Configuring of channel–specific system frames included in channel calculation

Face end	Data set for face end machining (counter-spindle):		
machining	24200	\$MC TRAFO TYPE 2=257	
J		Definition of 2nd transformation in channel:	
		TBANSMIT counter-spindle	
	24210	SMC TRAFO AXES IN 201=1	
	21210	Channel axis perpendicular to rotary axis (XC) for 2nd transformation	
	2/210	SMC TRAFO AXES IN 2[1]-5	
	24210	Channel axis of rotary axis (C2) for 2nd transformation	
	24210		
	24210	General axis parallel to ratery axis (70) for and transformation	
	04000		
	24220	sivic_IRAFO_GEOAX_ASSIGN_IAB_2[0]=1	
	04000		
	24220	SINC_IRAFO_GEOAX_ASSIGN_IAD_2[I]=5	
	04000		
	24220	SINC_IRAFO_GEOAX_ASSIGN_IAD_2[2]=2	
	04050	3rd channel axis (Z) for 2nd transformation	
	24950	\$MC_TRANSMIT_ROT_AX_Offset_2=0	
	04055	Unset of rotary axis for 2nd TRANSMIT transformation	
	24955	\$MC_IRANSMII_RUI_AX_FRAME_2=2	
		Axial offset of rotary axis is taken into account during TRANSMIT	
	24960	\$MC_IRANSMII_ROT_SIGN_IS_PLUS_2=0	
		Arithmetic sign of rotary axis for 2nd TRANSMIT transformation	
	24961	\$MC_TRANSMIT_POLE_SIDE_FIX_2=1	
		Restriction of operating area in front of/behind the pole,	
		2nd TRANSMIT transformation	
	24970	\$MC_TRANSMIT_BASE_TOOL_2[0]=0	
		Vector of basic tool for 2nd TRANSMIT transformation	
Cylinder surface	Data set for c	ylinder surface transformation with groove side offset (counter-spindle):	
Cylinder surface transformation	Data set for c 24400	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513	
Cylinder surface transformation with groove side	Data set for c 24400	ylinder surface transformation with groove side offset (counter–spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410	wylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410	wylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24410	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24410 24410	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24410 24410	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24410 24420	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24410 24420	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24410 24420 24420	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24410 24420 24420 24420	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5 2nd channel axis (Y) for 4th transformation	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24410 24420 24420 24420 24420	sylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5 2nd channel axis (Y) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24410 24420 24420 24420 24420	eylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5 2nd channel axis (Y) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24410 24420 24420 24420 24420 24420	eylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5 2nd channel axis (Y) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24410 24420 24420 24420 24420 24850	eylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5 2nd channel axis (Y) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24420 24420 24420 24420 24850 24855	eylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5 2nd channel axis (Y) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 Offset of rotary axis for 2nd TRACYL transformation \$MC_TRACYL_ROT_AX_FRAME_2=2	
Cylinder surface transformation with groove side offset	Data set for c 24400 24410 24410 24410 24420 24420 24420 24420 24850 24855	eylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5 2nd channel axis (Y) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRACYL_ROT_AX_OFFSET_2=0 Offset of rotary axis for 2nd TRACYL transformation \$MC_TRACYL_ROT_AX_FRAME_2=2 Axial offset of rotary axis is taken into account when	
Cylinder surface transformation with groove side offset	Data set for o 24400 24410 24410 24410 24410 24420 24420 24420 24850 24855	eylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5 2nd channel axis (Y) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis for 2nd TRACYL transformation \$MC_TRACYL_ROT_AX_OFFSET_2=0 Offset of rotary axis for 2nd TRACYL transformation \$MC_TRACYL_ROT_AX_FRAME_2=2 Axial offset of rotary axis is taken into account when TRACYL is active	
Cylinder surface transformation with groove side offset	Data set for o 24400 24410 24410 24410 24410 24420 24420 24420 24850 24855 24860	eylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5 2nd channel axis (Y) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis for 2nd TRACYL transformation \$MC_TRACYL_ROT_AX_FRAME_2=2 Axial offset of rotary axis is taken into account when TRACYL_BOT_SIGN_IS_PLUS_2=1	
Cylinder surface transformation with groove side offset	Data set for o 24400 24410 24410 24410 24410 24420 24420 24420 24850 24855 24860	eylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5 2nd channel axis (Y) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRACYL_ROT_AX_OFFSET_2=0 Offset of rotary axis for 2nd TRACYL transformation \$MC_TRACYL_ROT_AX_FRAME_2=2 Axial offset of rotary axis is taken into account when TRACYL is active \$MC_TRACYL_ROT_SIGN_IS_PLUS_2=1 Sign of rotary axis for 2nd TRACYL transformation	
Cylinder surface transformation with groove side offset	Data set for o 24400 24410 24410 24410 24420 24420 24420 24420 24850 24855 24855 24860 24870	eylinder surface transformation with groove side offset (counter-spindle): \$MC_TRAFO_TYPE_4=513 Definition of 4th transformation in channel: TRACYL counterspindle \$MC_TRAFO_AXES_IN_4[0]=1 Channel axis perpendicular to rotary axis (XC) for 4th transformation \$MC_TRAFO_AXES_IN_4[1]=5 Channel axis of rotary axis (C2) for 4th transformation \$MC_TRAFO_AXES_IN_4[2]=2 Channel axis parallel to rotary axis (ZC) for 4th transformation \$MC_TRAFO_AXES_IN_4[3]=6 Channel axis parallel to cylinder peripheral surface and perpendicular to rotary axis (ZC) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[0]=1 1st channel axis (X) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[1]=5 2nd channel axis (Y) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRAFO_GEOAX_ASSIGN_TAB_4[2]=2 3rd channel axis (Z) for 4th transformation \$MC_TRACYL_ROT_AX_OFFSET_2=0 Offset of rotary axis for 2nd TRACYL transformation \$MC_TRACYL_ROT_AX_FRAME_2=2 Axial offset of rotary axis is taken into account when TRACYL is active \$MC_TRACYL_ROT_SIGN_IS_PLUS_2=1 Sign of rotary axis for 2nd TRACYL transformation \$MC_TRACYL_BASE_TOOL_2[n]=0	

9.4 Inclined Y axis

	If your machine has an inclined Y axis (i.e. the Y axis is not perpendicular to the other axes), you can still program the entire machining sequence in the Cartesian coordinate system. The control uses the "Inclined axis" function (Traang) to transform the Cartesian coordinates to the traveling motions of the inclined axis. The function "Inclined Axis" (Traang) is a software option which you need to set in the CNC–ISO user interface. The Order No. is: 6FC5 800–0AM28–0YB0.			
	You also need References :	l to set up the "Inclined axis" function (Traang) via machine data. /FB2/, Function Manual on Extended Functions, M1, Kinematic Transformations		
	Once the "Incl face, it is auto select machini tion for the inc References:	ined axis" function has been set up in the ShopTurn user inter- matically integrated in the ShopTurn cycles. This means you can ing level "Face Y" or "Surface Y" in the masks and enter the posi- lined Y axis in Cartesian coordinates. /BATsl/, ShopTurn Operating/Programming Guide		
Example	For example, t spindle (C), ar data:	for a turning machine with X and Z axes and inclined Y axis, main nd tool spindle (WZ) you must configure the following machine		
	20050	\$MC_AXCONF_GEOAX_ASSIGN_TAB[0]=1		
	20050	\$MC_AXCONF_GEOAX_ASSIGN_TAB[1]=0		
	20050	\$MC_AXCONF_GEOAX_ASSIGN_TAB[2]=2		
	20110	3rd real geometric axis (Z axis) \$MC_RESET_MODE_MASK, Bit 0 = 1, Bit 7 = 0		
	20112	TRAANG retained after booting \$MC_START_MODE_MASK, Bit 7 = 1 TBAANG retained after "Cycle start"		
	20118	\$MC_GEOAX_CHANGE_RESET=1		
	20140	\$MC_TRAFO_RESET_VALUE=5		
	20144	TRAANG IS always active after reset \$MC_TRAFO_MODE_MASK, bit 0 = 1 TRAANG runs in background (persistent process) and is not displayed in the operator interface		

9.4 Inclined Y axis

20070	\$MC_AXCONF_MACHAX_USED[4]=5
	Channel axis YC = 5th machine axis
20080	\$MC_AXCONF_CHANAX_NAME_TAB[0]="XC"
	1st channel axis = XC
20080	\$MC_AXCONF_CHANAX_NAME_TAB[1]="ZC"
	2nd channel axis = ZC
20080	\$MC_AXCONF_CHANAX_NAME_TAB[2]="C"
	3rd channel axis = C
20080	\$MC_AXCONF_CHANAX_NAME_TAB[3]="WZ"
	4th channel axis = WZ
20080	\$MC_AXCONF_CHANAX_NAME_TAB[4]="YC"
	5th channel axis = YC

Data set for "Inc	lined axis":
24430	\$MC_TRAFO_TYPE_5=1024
	Transformation 5: TRAANG
24432	\$MC_TRAFO_AXES_IN_5[0]=5
	1st transformation axis with transformation 5 = channel axis YC
24432	\$MC_TRAFO_AXES_IN_5[1]=1
	2nd transformation axis with transformation 5 = channel axis XC
24432	\$MC_TRAFO_AXES_IN_5[2]=2
	3rd transformation axis with transformation 5 = channel axis ZC
24434	\$MC_TRAFO_GEOAX_ASSIGN_TAB_5[0]=1
	1st geometric axis with transformation 5 = channel axis XC
24434	\$MC_TRAFO_GEOAX_ASSIGN_TAB_5[1]=5
	2nd geometric axis with transformation 5 = channel axis YC
24434	\$MC_TRAFO_GEOAX_ASSIGN_TAB_5[2]=2
	3rd geometric axis with transformation 5 = channel axis ZC
24436	\$MC_TRAFO_INCLUDES_TOOL_5=0
	Tool included when 5th transformation is active
24700	\$MC_TRAANG_ANGLE_1=55
	Angle between 1st and 2nd transformation axes

Data set for linking (TRACON) face end machining on main spindle (TRANSMIT) and "Inclined axis" (TRAANG):

24440	\$MC_TRAFO_TYPE_6=8192
	Transformation 6: TRACON
24444	\$MC_TRAFO_GEOAX_ASSIGN_TAB_6[0]=1
	1st geometric axis with transformation 6 = channel axis XC
24444	\$MC_TRAFO_GEOAX_ASSIGN_TAB_6[1]=3
	2nd geometric axis with transformation 6 = channel axis C
24444	\$MC_TRAFO_GEOAX_ASSIGN_TAB_6[2]=2
	3rd geometric axis with transformation 6 = channel axis ZC
24995	\$MC_TRACON_CHAIN_1[0]=1
	Number of transformation TRANSMIT (main spindle) for linking
24995	\$MC_TRACON_CHAIN_1[1]=5
	Number of transformation TRAANG for linking

Data set for linking (TRACON) from cylinder surface transformation main spindle and "Inclined axis" (TRAANG):

24450	\$MC_TRAFO_TYPE_7=8192
	Transformation 7: TRACON
24454	\$MC_TRAFO_GEOAX_ASSIGN_TAB_7[0]=1
	1st geometric axis with transformation 7 = channel axis XC
24454	\$MC_TRAFO_GEOAX_ASSIGN_TAB_7[1]=3
	2nd geometric axis with transformation 7 = channel axis C
24454	\$MC TRAFO GEOAX ASSIGN TAB 7[2]=2
	3rd geometric axis with transformation 7 = channel axis ZC
24996	\$MC TRACON CHAIN 1[0]=1
	Number of transformation TRACYL (main spindle) for linking
24996	\$MC TRACON CHAIN 1[3]=5
	Number of transformation TRAANG for linking

9.5 Measuring cycle support in the G code editor

In ShopTurn you can integrate screen forms which provide support for programming measuring cycles into the G code editor. These cycles can then be recompiled automatically.

The "measuring cycles" function is a software option with Order No. 6FC5 $800{-}0AP28{-}0YB0.$

For more information on measuring cycle support, please refer to: **References**: /BNM/, Programming Manual on Measuring Cycles

For commissioning, proceed as follows:

ShopTurn on NCU (HMI Embedded sl)				
	•	Remove the semicolon ";" p	receding the following lines in file STAN-	
		;sc8406=aeditor.com	;Measuring cycles for turning (horizontal softkey 6 on ;the expanded softkey menu in the ;G code editor)	
		;sc8407=aeditor.com	;Measuring cycles for milling (horizontal softkey 7 ;on the expanded softkey menu in the ;G code editor)	
		By doing this, you create the suring cycles support and the	e connection between the softkeys used to call the mea- e configuration file of the support screens.	
	•	Remove the semicolon ";" pr DARD_CYCLES\COMMON	eceding the following line in file STAN- .COM:	
		;sc617=startup.com	;Startup operating area (horizontal :softkey 7 on the expanded softkey bar)	
		You can modify the character startup operating area.	ristics of the measuring cycle support in the	
	•	Restart the machine.		
	•	If required, modify the chara	cteristics for the measuring cycle support in the	

"Commissioning" \rightarrow ">" \rightarrow "Measuring cycles" menu.

9.5 Measuring cycle support in the G code editor

PCU 50.3 Requirements: When HMI Advanced was commissioned, the files AEDITOR.COM and STAR-TUP.COM must have been stored in the STANDARD CYCLES (CST.DIR) directory. when ShopTurn started up the archive ST CYC.ARC must have been transferred from the PCU 50.3 to the NCK. The COMMON.COM file must have been copied automatically to the STANDARD CYCLES (CST.DIR) directory. Copy the archive MCSUPP from the ARCHIVES\CYCLE ARCHIVES\MCYC. If you want to use the measurement result displays, you need to copy the MCRESULT archive from the ARCHIVES\CYCLE ARCHIVES\MCYC directory. If the versions of the standard measuring cycles supplied with ShopTurn (see file SIEMENSD.RTF or SIEMENSE.RTF on the software CD) differ from the HMI Advanced measuring cycles (see AR-CHIVES\CYCLE ARCHIVES\MCYC\VERSION.ARC) in the first 4 digits (e.g. 06.02), you need to copy the archive MCYCTURN from the ARCHIVES\CYCLE ARCHIVES\MCYC directory. Remove the semicolon ";" preceding the following lines in file STAN-DARD CYCLES\COMMON.COM: ;sc8406=aeditor.com ;Measuring cycles for turning (horizontal softkey 6 on ;the expanded softkey menu in the ;G code editor) ;sc8407=aeditor.com; ;Measuring cycles for milling (horizontal softkey 7 ;on the expanded softkey menu in the ;G code editor) Remove the semicolon ";" preceding the following lines in the file STAN-DARD CYCLES\AEDITOR.COM: ;HS15=(\$83531,,se1) ; PRESS(HS15) ; LS("F mess", "MZ SKL.COM", 1) ;END PRESS By doing this, you create the connection between the softkeys used to call the measuring cycles support and the configuration file of the support screens.

- In the file STANDARD_CYCLES\STARTUP.COM remove the semicolon ";" preceding the following lines:
 ;HS15=(\$83070,,se1)
 ;PRESS(HS15)
 ;LS("Messz")
 ;END_PRESS
 This allows you to modify the characteristics of the measuring cycle support in the Startup operating area.
- Restart the PCU 50.3.
- If required, modify the characteristics for the measuring cycle support in the "Commissioning" → ">" → "Measuring cycles" menu.

9.6 Counter-spindle

If your turning machine has a counter–spindle, you can machine workpieces with turning, drilling, and milling functions on the front and reverse side without having to rechuck the workpiece manually.

Before machining the reverse side, the counter–spindle must grip the workpiece, pull it out of the main spindle, and position it at the new machining position.

In order to use the counter-spindle on your machine, you need the software options "travel to fixed stop" (Order No. 6FC5 800-0AM01-0YB0) and "synchronous spindle" (Order No. 6FC5 800-0AM14-0YB0).

layout	When setting up the counter-spindle you need to take the following machine data into account: 9803 \$MM_ST_INDEX_AXIS_4: Axis index slide counter-spindle 9806 \$MM_ST_INDEX_SPINDLE_SUB: Axis index counter-spindle 9812 \$MM_ST_GEAR_STEPS_SPINDLE_SUB: Gear steps counter-spindle 9823 \$MM_ST_DISPL_DIR_SUB_SPIND_M3: Direction of rotation with M3 9825 \$MM_ST_DISPL_DIR_SUB_C_AX_INV: Direction of rotation C axis with M3
	The position to which the counter-spindle travels when the program starts is defined in the following machine data: 9851 \$MM_ST_CYCLE_SUB_SP_WORK_POS: Retraction position of the counter-spindle
	If the counter-spindle is to travel to fixed stop when gripping, ShopTurn will evaluate the following machine data: 9852 \$MM_ST_CYCLE_SUB_SP_DIST: Travel to fixed stop, distance 9853 \$MM_ST_CYCLE_SUB_SP_FEED: Travel to fixed stop, feed 9854 \$MM_ST_CYCLE_SUB_SP_FORCE: Travel to fixed stop, force
	Between traveling to the fixed stop and gripping, the counter-spindle can retract a short distance to counteract compressive stress in the workpiece. 9857 \$MM_ST_CYCLE_RET_DIST_FIXEDSTOP: Retraction distance for re- lieving compressive stress after traveling to fixed stop
	After gripping you can cut off the workpiece. Before doing so, the counter- spindle can travel back a short distance with the workpiece to exert tensile stress on the workpiece. This relieves pressure on the tool when cutting off. 9858 \$MM_ST_CYCLE_RET_DIST_PART_OFF: Retraction distance for tensile stress before cut-off
	After cut–off, you can carry out a cut–off check with ShopTurn using the function "Travel to fixed stop". You can activate/deactivate the cut–off check by means of the following machine data: 9859 \$MM_ST_CYCLE_PART_OFF_CTRL_DIST: Cut–off check, distance 9860 \$MM_ST_CYCLE_PART_OFF_CTRL_FEED: Cut–off check, feed 9861 \$MM_ST_CYCLE_PART_OFF_CTRL_FORC: Cut–off check, force

	The cut–off is successful if travel to fixed stop fails. Alarms 20091 "Axis %1 did not reach fixed stop" and 20094 "Axis %1 function was aborted" must therefore be deactivated in the machine data: 37050 \$MA_FIXED_STOP_ALARM_MASK = 2 This machine data must be set in the "Machine data" mask in operating area "Tools – zero offset"; you need to adapt it to the specific axis. If, however, the specified force was achieved during the cut–off control (i.e. travel to fixed stop was successful), alarm 61255 "Error at cut–off: Tool break?" is issued.	
	Note	
	The "Travel to fixed stop" function can also be used when gripping the spindle (see above). If travel to fixed stop does not succeed when gripping, an alarm will of course also be issued. Instead of alarms 20091 and 20094 the alarm 61254 "Error during travel to fixed stop" will be issued.	
Dimensions	To define the reference point for moving the counter–spindle, you must first in- form the counter–spindle of the dimensions. You can either enter the dimen- sions in the following machine data or in the menu "Tools – zero offset" → ">" → "Spindles". Changes to the machine data automatically become effective in the menu and vice versa. 9829 \$MM_ST_SPINDLE_CHUCK_TYPES: Spindle chuck selection 9831 \$MM_ST_SPINDLE_PARA_ZL1: Chuck dimensions for counter–spindle 9832 \$MM_ST_SPINDLE_PARA_ZL2: Stop dimension for counter–spindle 9833 \$MM_ST_SPINDLE_PARA_ZL3: Jaw dimension for counter–spindle	
Machine manufacturer cycle	If you would like to perform one of the following actions, you need to adapt the machine manufacturer cycle ST_CUST.SPF (see section 11.2 "Machine manufacturer cycles):	
	 Switch between spindle and C axis mode for the main spindle or counter- spindle 	
	Open, close, flush chuck (main spindle/counter-spindle)	
	Change default settings for the main spindle and counter-spindle	
Simulation	If your programming includes M functions to open or close the chuck on the main spindle or counter-spindle, the simulation will only display these actions if you observe the following:	
	In the machine data you must assign the M functions to cycles which will then perform the appropriate function. The functions performed by individual cycles are listed in the table below:	
9.6 Counter-spindle

Cycle	Function
chuck1cl.spf	Main spindle, close chuck
chuck1os.spf	Main spindle, open chuck when spindle is stationary
chuck1or.spf	Main spindle, open chuck when spindle is rotating
chuck2cl.spf	Counter-spindle, close chuck
chuck2os.spf	Counter-spindle, open chuck when spindle is stationary
chuck2or.spf	Counter-spindle, open chuck when spindle is rotating

Table 9-1 Cycles for opening/closing the opening closing the opening states of the opening of the opening states states of the openi
--

Please proceed as follows:

- Transfer the necessary cycles from the directory CYCLES\SC\PROG\TEMPLATES to the user cycles directory.
- Assign the M functions to cycles in the following machine data: MD 10715 \$MN_M_NO_FCT_CYCLE[n] = Number of M function MD 10716 \$MN_M_NO_FCT_CYCLE_NAME[n] = Name of cycle
- Execute a "Power ON" in the NCK.

Simulation example

Sample program: G54	
G0 G90 X200 M280 COUPDEF (S3,S4,1,1,"noc","dv") COUPON (S3,S4,1)	; Machine front face ; Retract tool ; Open chuck on counter–spindle ; Define coupling ; Coupling ON
G0 Z3=300 G1 G91 F1000 Z3=-40	; Position counter–spindle ; Gripper position
M281 M240	; Close chuck on counter-spindle ; Open chuck on main spindle
G0 G90 Z3=600 COUPOF (S3,S4) G55	; Machining position ; Coupling OFF ; Activate rear face WO with
мзо	; mirroring ; Machine rear face ; End of program
To obtain the sample program above, set the \$MN_M_NO_FCT_CYCLE[1]= M280 \$MN_M_NO_FCT_CYCLE_NAME[1]=chucl \$MN_M_NO_FCT_CYCLE[2]= M281 \$MN_M_NO_FCT_CYCLE_NAME[2]=chucl \$MN_M_NO_FCT_CYCLE[3]= M240	e following machine data: k2os k2cl

\$MN_M_NO_FCT_CYCLE_NAME[3]=chuck1os For further information about machining with the counter-spindle, please refer to:

References: /BATsl/, ShopTurn Operating/Programming Guide

9.7 Turning machines with a B axis

9.7 Turning machines with a B axis

	Where turning machines with an additional rotary axis B are concerned, the tool can be aligned or swiveled on the X/Y plane. If your machine has a counterspindle, you can alternate machining on the main spindle and counterspindle with, e.g., a tool. The basic setting, in which all tools are measured, must be B = 0.
Setup	When setting up your machine, you must take the following machine data into account: MD 9808 \$MM_ST_INDEX_AXIS_B
	The function CUTMOD is used to create the necessary tool offsets.
	References: PG/, "Programming Manual Fundamentals"
	The Swivel function is activated using MD 9723 \$MM_CMM_ENABLE_SWIV- ELLING_HEAD = 1.
	For aligning and swiveling purposes, the following swivel data records must be taken into account:
	 Swivel data record for aligning and swiveling tools on the main spindle and counterspindle (Turning, Face Y/C, Surface Y/C).
	 Swivel data record for machining inclined surfaces when milling on the main spindle (face B).
	• Swivel data record for machining inclined surfaces when milling on the coun- terspindle (face B).
	When commissioning swiveling, you must select the "Yes" setting in the "B axis kinematics" field in the "Commissioning Rotary axis parameters" menu.
	References: PGZ/, Programming Guide Cycles, chapter "Swiveling – Cycle800
Measuring a tool	The tool is measured with special brackets for β and γ , which can be set in the input mask. The rotary axes can be put in the requisite positions through the NC start.
	Before setting the length, these positions are compared with the specified values. If the values differ from one another by more than the value of the MD 36000 STOP_LIMIT_COARSE (coarse precise stop), the message "Tool orientation Beta contradictory, actuate NC start" (or gamma) is output. The tolerance limit is approved because there may be slight deviations from the target value, for example as a result of an axis jamming.
Transformations	To use the function "Tracking tool (hold tool tip when swiveling)", you must com- mission the relevant TRAORI.

It is possible to work on a single turning machine with two tool carriers, both of which are mounted on an X axis. The tool holders might be turrets, multifix, or a combination of both.

Since both tool adapters are mounted on the same axis, it is only ever possible to work with one tool at a time. The workpiece is located between the two tool adapters.

All tools have the same reference point (generally on tool carrier 1), regardless of which tool carrier they are located on. For this reason, the tool lengths of the second tool carrier are always longer than those of the tools on the first tool carrier. The main machining work is carried out in the negative range of the X axis.



If the tool length is \geq MD 9838, mirroring takes place.

For the mirroring used for the X and Y axes and offsets of the C axis, the following machine data must be configured:

MD 24006 \$MC_CHSFRAME_RESET_MASK='H11'; Bit 4 = 1 MD 24007 \$MC_CHSFRAME_RESET_CLEAR_MASK='H00'; Bit 4 = 0 MD 28082 \$MC_MM_SYSTEM_FRAME_MASK='H31'; Bit 4 = 1 MD 28083 \$MC_MM_SYSTEM_DATAFRAME_MASK='H1F'; Bit 4 = 1

Due to the coordinate system being mirrored, the following machine/setting data must be set:

MD 21202 \$MC_LIFTFAST_WITH_MIRROR=1 Mirroring with LIFTFAST

SD 42910 \$SC_MIRROR_TOOL_WEAR=1 Mirroring of tool wear

MD 9478 Bit 19 = 1; if no turret is being used.

G code programs

Note

If there are a large number of old G code programs that were programmed without mirroring of the X axis, you should consider setting mirroring for G code programs.

If the relevant mode of operation of the second tool carrier (with mirroring of the X axis) is also to be used for G code programs, further settings must be made.

To activate mirroring when loading tools on the second tool carrier, the following T replacement must be set:

10717 \$MN_T_NO_FCT_CYCLE_NAME="F_T_REV2"

If the necessary mirror images are also to be activated automatically when programming the TRASMIT command, this command must be replaced by a subprogram (e.g., in the manufacturer directory):

10712 \$MN_NC_USER_CODE_CONF_NAME_TAB[0]="TRANSMIT" 10712 \$MN_NC_USER_CODE_CONF_NAME_TAB[1]="TRANSM"

TRANSMIT.SPF PROC TRANSMIT(INT_NR) F_T_REV2 TRANSM(_NR) F_T_REV2 RET

Note

In the status display, TRANSM is now displayed instead of TRANSMIT.

Supplementary condition

The "Taper turning" option is not enabled when working with two tool carriers. It is not possible to use the turning machine with B axis at the same time.

Space for your notes

10

Customized User Interface

10.1 Configuring the custom boot screen

With the ShopTurn variant with PCU 50.3 you can create your own customized image (e.g. company logo, etc.) which will then appear when the control boots up.

To do so create your own image in 16–color mode. The maximum size of the image, for the OP010/OP010C/OP010S/OP012, is 224 x 224 pixels and, for the OP015, 352 x 352 pixels.

For the procedure for configuring this and exchanging the boot–up image, please refer to:

References: /IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sI/840D

10.2 Configuring the custom screen

You can use the "operator interface extension" software to build your own custom screens with specific functional expansions (e.g. custom cycles and measuring cycles) or just create your own screen layout (static screens).

References: /IHA/, Commissioning Base Software and HMI Advanced, Operator Interface Extension, SINUMERIK 840D sl/840Di/840D

Screen form properties In ShopTurn you cannot specify any dimensions for configuring the main part of the screen. The position and size of the various main parts of the screen are fixed according to the operating area and mode. This only applies for screens that can be accessed via entry softkeys.

Exit screen	Softkey	Size	Dimensions
Manual operating mode – Zero point workpiece/Measure workpiece	Vertical softkey 1 Vertical softkey 7		X–pos. = 0 Y–pos. = 272 height = 158 pixels width = 556 pixels
Manual operating mode	Horizontal softkey 8	Large	X-pos. = 0 Y-pos. = 34 height = 396 pixels width = 556 pixels
Manual operating mode	Horizontal softkey 8	Medium	X-pos. = 0 Y-pos. = 78 height = 352 pixels width = 556 pixels
Manual operating mode	Horizontal softkey 8	Small	X-pos. = 0 Y-pos. = 254 height = 176 pixels width = 556 pixels
Automatic mode	Horizontal softkey 6	Large	X-pos. = 0 Y-pos. = 34 height = 396 pixels width = 556 pixels
Automatic mode	Horizontal softkey 6	Medium	X-pos. = 0 Y-pos. = 78 height = 352 pixels width = 556 pixels
Automatic mode	Horizontal softkey 6	Small	X-pos. = 0 Y-pos. = 254 height = 176 pixels width = 556 pixels
Program operating area – Drilling/milling	Vertical softkey 6		X-pos. = 33 Y-pos. = 52 height = 378 pixels width = 523 pixels
Program operating area – Miscellaneous	Vertical softkey 4		X-pos. = 33 Y-pos. = 52 height = 378 pixels width = 523 pixels

Table 10-1 Fixed dimensions of ShopTurn screens

01/2008

10.2 Configuring the custom screen

Exit screen	Softkey	Size	Dimensions
Program operating area – G code editor	Horizontal softkey 2 Horizontal softkey 6		X–pos. = 0 Y–pos. = 34 height = 396 pixels width = 556 pixels
Alarms operating area	Horizontal softkey 7 Horizontal softkey 8		X–pos. = 0 Y–pos. = 34 height = 396 pixels width = 556 pixels
Operating area – Tools/ Zero offsets	Horizontal softkey 7		X–pos. = 0 Y–pos. = 34 height = 396 pixels width = 556 pixels

Table 10-1	Fixed dimensions of ShopTurn screens
------------	--------------------------------------

Generate code	Do not enter a target directory for the program operating area and the manual
	mode. ShopTurn defines the target file.

Entry softkeys The customized static screens can be displayed with the following entry softkeys, the SC number being the link between the entry softkey and the configuration file of the screen. In manual and automatic modes you have the choice between different sized screens that fill the following window areas:

- Large: Status area, position display, or program display and input window
- Medium: Position display or program display and input window
- Small: Input window

Table 10-2 Entry softkeys for screens

Exit screen	Softkey	Size	SCxxxx
Manual operating mode	Horizontal softkey 8	Large	SC818
	Horizontal softkey 8	Medium	SC8181
	Horizontal softkey 8	Small	SC8182
Automatic mode	Horizontal softkey 6	Small	SC826
	Horizontal softkey 6	Medium	SC8261
	Horizontal softkey 6	Large	SC8262
Messages/Alarms oper- ating area	Horizontal softkey 7		SC857
Messages/Alarms oper- ating area	Horizontal softkey 8		SC858
Operating area – Tools/ Zero offsets	Horizontal softkey 7		SC867

Note

The screen size is fixed in ShopTurn (see above "Screen Properties"). Take note of this in case you would like to program background images, for example, for screens you configured yourself.

Note

Open a user-configured screen before calling a softkey bar.

You can call your own cycles by means of the following access softkeys:

Table 10-3 Entry softkeys for cycles

Exit screen	Softkey	SCxxxx
Program operating area – Drilling	Vertical softkey 6	SC8426
Program operating area – Turning	Vertical softkey 6	SC9436
Program operating area – Milling	Vertical softkey 6	SC9456
Program operating area – Miscellaneous	Vertical softkey 4	SC8454

Note

In manual mode you can also assign your own user cycle to horizontal softkey 8. The NC code generated is then collected and you can then start the cycle with "Cycle Start"; (see section 10.2.3. "Integrating measuring cycles).

You can use the following entry softkeys to display your own measuring cycles, which are to replace the ShopTurn measuring cycles:

Exit screen	Softkey	SCxxxx
Manual operating mode – Zero point work- piece	Vertical softkey 1	SC8131
Manual operating mode – Zero point work- piece	Vertical softkey 2	SC8132
Manual operating mode – Zero point work- piece	Vertical softkey 3	SC8133
Manual operating mode – Zero point work- piece	Vertical softkey 4	SC8134
Manual operating mode – Zero point work- piece	Vertical softkey 5	SC8135
Manual operating mode – Zero point work- piece	Vertical softkey 6	SC8136
Manual operating mode – Zero point work- piece	Vertical softkey 7	SC8137
Manual operating mode – Tool measure- ment	Vertical softkey 1	SC8141
Manual operating mode – Tool measure- ment	Vertical softkey 2	SC8142
Manual operating mode – Tool measure- ment	Vertical softkey 3	SC8143
Manual operating mode – Tool measure- ment	Vertical softkey 4	SC8144
Manual operating mode – Tool measure- ment	Vertical softkey 5	SC8145
Manual operating mode – Tool measure- ment	Vertical softkey 6	SC8146
Manual operating mode – Tool measure- ment	Vertical softkey 7	SC8147

Table 10-4 Entry softkeys for measuring cycles

10.2.1 Transferring cycles to the machining plan

You can transfer all user cycles that you have inserted in the Program operating area (including measuring cycles) to the work plan and edit them there. However, the cycles will not be displayed as programming graphics. Use the "operator interface extension" software to define the cycle. Please note that the cycle must contain the Generate Code (GC) function and an OUTPUT method for NC code to be generated and sent to the NC for execution. If you call and validate the cycle on the ShopTurn user interface, the cycle will automatically appear in the work plan. The screen form name of the cycle will appear in the machining plan as plain text. Sample cycles Sample cycles are available for the following applications: Tail stock (TAILSTOK) Part gripper (RECEPTAC) Bar loader (BARLOAD) If you want to use these cycles, adapt them to the characteristics of your machine. Directory CYCLES\SC\PROG\TEMPLATES contains the archive file EQUIP-MENT.ARC which lists the cycles and operator interfaces. The associated texts are imported together with the alarm texts when you install ShopTurn. A readme file with information about how to install is also located in the same directory as the archive file. The cycles for tail stock, part gripper, and bar loader can be seen in the Program operating area under Miscellaneous -> Device. You will also find the tail stock cycle in Manual mode (horizontal softkey 8). Sample cycles -The "bar loader" cycle can be linked with a cut-off or stock removal cycle; (see linking "bar Sample cycle). loader" Note

If you want to use the sample cycle for bar loader, you must not change its name ("BARLOAD").

10.2.2 Linking cycles into the machining plan

	You can link user cycles into the work plan with the ShopTurn cycles "Positions".
Name	The name of the cycles to be linked in the work plan is mandatory and must not be changed: F_DR_Ox with x = 1 to 8
Variables	The following variables must be configured within the cycles:
	First you must define three variables that are not used until the program step is inserted in the ShopTurn work plan; i.e. you must assign the attribute invisible (wr0) to the variable input field. The variable sequence is as follows:
	1. Variable for the next tool, data type String (S)
	2. Variable for the position identifier in objects, data type Integer
	 Variable for the sequencer text that is to be displayed in the ShopTurn work schedule, data type character string (S) The easiest way to assign a value to this variable is in a LOAD method.
	Two variables for cycles processing must also be defined as well as one vari- able for each toggle field which has a different display content on the interface (e.g. mm/rev) than the internally transferred quantity (e.g. 1). You need to assign the attribute invisible (wr0) to these variables too as they do not have their own input field. You can place the variables in any order.
	Note
	When an OUTPUT method is used, all variables described above must be configured within this method so that they can all be interpreted on recompilation.
Once–only machining	If a particular work step is to be performed not in all positions but only once, the following user variable must be set in the associated cycle F_ONETIME = 1. This also provides the possibility of implementing modal changes for subsequent technologies.
Example	Directory CYCLES\SC\PROG\TEMPLATES contains a sample cycle F_DR_O1.SPF. The associated user interface is configured in file F_DR_O1.COM. The German and English texts are stored in files F_DR_TXD.COM and F_DR_TXE.COM. A number of help displays are also included with the sample cycle. Please see the README.TXT file for information on how to install the cycle.

10.2.3 Integrating measuring cycles

Manual operating mode	If you wish to integrate your own measuring cycles in Manual mode, vertical softkey 8 (VS8) in the new cycles screen acquires a special meaning. All actions that the new measuring cycle is supposed to perform after the "cycle start" key has been pressed must be defined in a PRESS method for VS8. If you press the "cycle start" button, NC code is generated that is written and executed in a program, i.e. the function Generate Code (GC) must be programmed in the PRESS method for VS8. This in turn means that an OUTPUT method must be defined.
	Note
	The user does not have to press VS8; it is triggered internally when the "cycle start" key is pressed. The VS8 must therefore not be labeled.
Example	Directory CYCLES\SC\PROG\TEMPLATES contains the archive file $F_MS_O1.ARC$ containing sample cycle $F_MS_O1.SPF$. The associated user interface is configured in file $F_MS_O1.COM$. In Files $F_MS_TXD.COM$ and $F_MS_TXE.COM$ contain the German and English texts, and file EDGE_Z.BMP contains a help display. Please see the README.TXT file for information on how to install the cycle.
"Program" operating area	If you want to link user measuring cycles into the operating area program, proceed as described in Section 10.2.1 "Transferring Cycles to the Machining Plan". A vertical softkey menu will then be created behind the entry softkey "Miscellaneous" \rightarrow "Zero point workpiece", via which you can call up your measuring cycles. Such a vertical softkey menu already exists behind the "Miscellaneous" \rightarrow "Measure tool" entry softkey.

10.3 ShopTurn Open (PCU 50.3)

In ShopTurn Open, the HMI Advanced operating areas "Parameter" (without tool management and zero offsets), "Services", "Diagnosis", and "Commissioning" are located on the extended horizontal softkey bar.

The extended horizontal softkey bar also includes the "Machine Service" and "Exit" softkeys for commissioning/diagnosis. These two softkeys are visible only when protection level 1 is selected.

In ShopMill Open you can also integrate Windows applications in the standard menu bar via softkeys. You must also install the Windows applications in the OEM directory and define them in the REGIE.INI file. This does not apply to Siemens additional products. You must install those in the ADD_ON directory. Refer to the ShopTurn DVD for details.

References: User's Guide HMI Programming Package Part 1 (BN)

10.3.1 Basic menu bar

Jump into application	There are various into the basic me	s methods by which you can integrate Windows applications nu bar:
	Horizontal sof	tkey 4, i.e. the Messages/Alarms operating area is replaced
	User-assigna	ble softkeys 7 and 8
	User-assigna	ble softkeys 1 to 8 in the extended horizontal softkey menu
Return jump	There are 3 meth another operating	ods by which you can jump from the Windows application to g area:
	 Using the "Me basic menu b 	enu Select" key on the operator panel, you can return to the ar and then select another operating area via a softkey.
	 You can confi ager", "Alarm' another operation 	gure the keys "Position", "Program", "Offset", "Program Man- ' and "Custom" on the operator panel to branch directly into ating area or sub-menu.
	• You can confi area or sub-r	gure so-called "PLC keys" to branch into another operating nenu.
	References:	/IHA/, Commissioning Base Software and HMI Advanced, Operator Interface Extension keyword "OP Hotkeys" and "PLC Keys", SINUMERIK 840D sl, 840D/840Di

10.4 Operator interface for ShopTurn on the NCU (HMI Embedded sl)

10.4 Operator interface for ShopTurn on the NCU (HMI Embedded sl)

Default setting	The operating areas "Machine" and "Program" are by default hidden without manufacturer password. In the operating area "Parameter" only the set-
Setting	ting data and the zero offsets can be seen without manufacture password.
	You can change the display by means of the following machine data
	9272 MM_USER_CLASS_APPLICATION [1] = 1 Machine area
	9272 MM_USER_CLASS_APPLICATION [3] = 1 Program area
	9273 MM_USER_CLASS_APP_PARAMETER [1] = 1 Tool list
	9273 MM_USER_CLASS_APP_PARAMETER [2] = 1 Tool wear
	9273 MM_USER_CLASS_APP_PARAMETER [3] = 1 OEM tool data
	9273 MM_USER_CLASS_APP_PARAMETER [4] = 1 Magazine
	9273 MM_USER_CLASS_APP_PARAMETER [6] = 1 R parameters
	9273 MM_USER_CLASS_APP_PARAMETER [10] = 1 User data
	9414 MM_TM_KIND_OF_TOOLMANAGEMENT = 1 Graphical representation of the tool management

10.5 User status display

You can display machine states controlled via the PLC as custom user icons in the program status line.

	<u> M</u> AUTO		
		/ Program status l	ine
	Fig. 10-1 Program status	line	
	You need to activate the SHOW_CHANNEL_SPA The program path of the together with the program	display of user icons in the displa NNING_STATE. currently selected program is sho n name.	ay MD 9052 own in the line below
	16 display positions are	defined in the program status ba	.
	The custom user icons n	nust meet the following requireme	ents:
S	Colors: 16–color mod	6–color mode	
	 Size: OP010/OP0⁻ OP012: 20 x OP015: 27 x 	I0C/OP010S: 16 x 16 pixels 20 pixels 26 pixel (height x width)	
	• File name: 8 charact	ers	
	Format: BMP		
	For ShopTurn on PCU 5 the directory F:\DH\CUS	0.3 (HMI Advanced), you should .DIR\HLP.DIR.	store user symbols in
	For ShopTurn on NCU (following folders:	HMI Embedded sl), you should pl	ace the icons in the
	Table 10-5 Directory for	or saving user-specific icons	
	Storage folder	OP/resolution	Size of icons (height x width)

OP 010 (640 x 480)

OP 012 (800 x 600)

OP 015 (1024 x 768)

ico640

ico800

ico1024

16 x 16 pixels

20 x 20 pixels

27 x 26 pixels

The user-specific images are stored in directories (icoxxx) in the following subdirectories:

- Manufacturer: \oem\sinumerik\hmi\ico\icoxxx
- User: \oem\sinumerik\hmi\ico\icoxxx

10.5.1 Configuring the user status display

The cross–channel status display is allocated and configured with user symbols in the HEADER.INI file.

ShopTurn on PCU 50.3 The HEADER.INI file is located in the directory F:\HMI_ADV and must be copied either to the directory F:\OEM or F:\USER.

In the section UserIcons of the HEADER.INI file, enter the names of the user symbols and the signal for the control of the symbol selection.

Note

If you have already made these entries for HMI Advanced, you do not need to make them again for ShopTurn.

[User icons] UI_0= <Icons_00.bmp>, <Position> UI_0: Identifier Icons_00.bmp: Name of the user icon Position: Position for display (1 to 16) ... UI_31= <Icons_31.bmp>, <Position> USER_ICON_BASE = DBx.DBBy DBx.DBBy: Signal defined by user for controlling icon selection

The user icons are addressed bit by bit, i.e. if bit **n** is set in signal DBx.DBBy, then the user icon with identifier UI_**n** is displayed. If the bit is reset by the PLC, the associated user icon is deleted in the program

If the bit is reset by the PLC, the associated user icon is deleted in the program status display.

If several user symbols are assigned to the same position, the user symbol with the highest identifier number is displayed. You do not need to specify blank positions.

Additional information can be found in

References: /IHA/, Commissioning Base Software and HMI Advanced, SINUMERIK 840D sl/840D/840Di

Sh	opTu	rn	
on	NCU	(HI	MI
Em	bedd	ed	sl)

The CompactFlash card contains the HEADER.INI file in the directory siemens\sinumerik\hmi\cfg\

Copy the HEADER.INI file to the directory oem\sinumerik\hmi\cfg. Open the file using the editor and assign the desired positions to the user symbols.

Additional information can be found in

References: /IHE/, Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl

10.6 OP hotkeys, PLC keys

OP hotkeys	You can configure the keys "Position", "Program", "Offset", "Program Manager", "Alarm", and "Custom" on the operator panel to branch to an operating area of your choice.
PLC keys	You can configure so-called "PLC keys" to branch to particular operating areas.
Configuration	You can switch to the following operating areas with the OP hotkeys or PLC keys:
	 ShopTurn on NCU (HMI Embedded sl) From ShopTurn to any operating area of ShopTurn.
	 PCU 50.3 From ShopTurn to any other operating area in ShopTurn. From ShopTurn to any other operating area in HMI Advanced and vice versa.
	Information about the configuration can be found in: References: /IHA/, Commissioning Base Software and HMI Advanced, Operator Interface Extension keyword "OP Hotkeys" and "PLC Keys", SINUMERIK 840D sl, 840D/840Di
	Note
	The configuration of the "PLC Keys" in ShopTurn is carried out in the file KEYS.INI, not via the DB 19 interface. The file KEYS.INI must feature the following entry in the section

[HMI_INI_FILES]:

Task6 = shopturn.ini

11

Miscellaneous

11.1 Machine data for protection levels

Lockable data areas

The machine manufacturer or end user can set operator panel machine data to assign the appropriate protection levels for individual functions and data areas For a number of data types, it is possible to input different protection levels for read and write access authority.

The machine data which can be locked by means of protection levels in Shop-Turn is listed below:

Operator panel machine data	Access to
9182 USER_CLASS_INCH_METRIC	Switch over between Inch/metric
9200 USER_CLASS_READ_TOA	Read tool offsets
9201 USER_CLASS_WRITE_TOA_GEO	Write tool geometry (including type and cutting edge)
9202 USER_CLASS_WRITE_TOA_WEAR	Write tool wear (without limit value)
9203 USER_CLASS_WRITE_FINE	Write fine tool wear and fine offsets
9206 USER_CLASS_WRITE_TOA_SUPVIS	Change limit values for tool monitoring
9210 USER_CLASS_WRITE_ZOA	Write rough offsets
9215 USER_CLASS_WRITE_SEA	Write setting data
9216 USER_CLASS_READ_PROGRAM (protection level must be \leq 6)	Read program
9217 USER_CLASS_WRITE_PROGRAM (protection level must be \leq 5)	Write/edit program
9218 USER_CLASS_SELECT_PROGRAM (protection level must be \leq 7)	Enable program selection
9222 USER_CLASS_WRITE_RPA	Write R parameters
9252 USER_CLASS_TM_SKTOOLLOAD	Enable loading of a tool
9253 USER_CLASS_TM_SKTOOLUNLOAD	Enable unloading of a tool
9254 USER_CLASS_TM_SKTOOLMOVE	Enable relocation of a tool
9258 USER_CLASS_TM_SKNCNEWTOOLE	Enable setting up of new cutting edges

11.1 Machine data for protection levels

9259 USER_CLASS_TM_SKNCDELTOOL	Enable deleting of a tool
9264 USER_CLASS_TM_SKTLNEWTOOL	Enable setting up of a new tool
9510 USER_CLASS_DIRECTORY1_P	Enable network drive 1
9511 USER_CLASS_DIRECTORY2_P	Enable network drive 2
9512 USER_CLASS_DIRECTORY3_P	Enable network drive 3
9513 USER_CLASS_DIRECTORY4_P	Enable network drive 43
9890 ST_USER_CLASS_MEAS_T_CAL	Calibrate tool probe

11.2 Machine manufacturer cycle

The machine manufacturer cycle ST_CUST.SPF is called by the ShopTurn cycles. Adapt the cycle if you want to perform one of the following actions:

 Switch between spindle and C axis mode of the main spindle or counterspindle.
 Marks M1, M2, M21, M22

(see also Section 9.6 "Counter-spindle")

- Clamp or release the rotary axes (main spindle/counter-spindle). Marks _M3, _M4, _M23, _M24 (see also MD 9843 \$MM ST ENABLE SPINDLE CLAMPING)
- Open, close, flush chuck (main spindle /counter-spindle). Marks _M5 to _M8, _M25 to _M29 (see also Section 9.6 "Counter-spindle")
- Engage/disengage rotating tool (make/break connection to drive). Marks _M41, _M42
- Configure special functions for switchover between machining planes. (You do not have to make any settings for cylinder surface transformation or face end machining with the C axis.) Marks M61 to M68
- Position, extend, or retract receptacle for cutting off. Marks _M100, _M101, _M102 (see also MD 9841 \$MM ST ENABLE PART OFF RECEPT)
- Configure special functions for tool changing. (These special functions are called after the T command is output.) Marks _M110, _M111, _M112
- Change default for coupling between main spindle and counter-spindle. Mark _M120 (see also Section 9.6 "Counter-spindle")
- Set special properties for program start or program end. Marks _M131, _M135, _M136

The cycle is located in directory CYCLES\SC\PROG\TEMPLATES.

11.3 Spindle control

	For configuration	n of the spindle control, please refer to:
	References:	/FB1/, Function Manual, Basic Machine, Spindles (S1)
End of program	ShopTurn distin M function set ir in "Manual" or "N Setting MD 3504 to switch off the function program One of the purpo spindle in manua	guishes between M2/M30 (end of a ShopTurn program) and the MD 10714 \$MN_M_NO_FCT_EOP (end of a program created MDI" mode). 40 \$MA_SPIND_ACTIVE_AFTER_RESET=2 causes the NCK spindle in response to M2/M30 but not in response to the M nmed in MD 10714 \$MN_M_NO_FCT_EOP. oses of this functionality is to allow continuous starting of the al mode (e.g. for scratching).
	ShopTurn uses	the following M functions for end of program:
	 M function fr spindle conti 	om MD 10714 \$MN_M_NO_FCT_EOP: End of main program, inues
	 M2, M30: Er spindle stops 	d of main program and return jump to beginning of program, s
	 M17: End of ues operatin 	subprogram and return jump to main program, spindle contin- g
Direction of rotation	In order to ensure rectly displayed grammed Shop settings. You muspindle/C axis o	re that the rotational direction of the spindle and C axis is cor- in the ShopTurn interface and executed directly for pro- Furn functions you must enter a number of mutually coordinated ust base these settings on the actual direction of rotation of the n the machine.
	If you want to us chining, commis The following m 24810 \$MC_TR 24860 \$MC_TR 24910 \$MC_TR 24960 \$MC_TR	se functions cylinder surface transformation and end face ma- sioning must have been correctly performed for the functions. achine data in particular must be correctly set: ACYL_ROT_SIGN_IS_PLUS_1 ACYL_ROT_SIGN_IS_PLUS_2 ANSMIT_ROT_SIGN_IS_PLUS_1 ANSMIT_ROT_SIGN_IS_PLUS_2
	In display machi axis is to be disp	ne data you stipulate which direction of rotation of the spindle/C played for M function M3 in the ShopTurn interface.
	MD 9822 \$MM_ MD 9823 \$MM_ MD 9824 \$MM_ MD 9825 \$MM_	ST_DISPL_DIR_MAIN_SPIND_M3 ST_DISPL_DIR_SUB_SPIND_M3 ST_DISPL_DIR_MAIN_C_AX_INV ST_DISPL_DIR_SUB_C_AX_INV
	The direction of direction of the 0 the relevant C a rection (=0) or in	spindle rotation (M3/M4) is assigned to the positive rotational C axis via interface signal DB3n.DBX17.6 (where $n = index$ of xis). The bit defines whether M3 and C+ rotate in the same dimopposite directions (=1).
	The following se spindle; the sett which the user v and 9825 and th	ettings are possible for the main spindle and the counter- ings for machine data 9822 and 9823 depend on the direction in views the coordinate axis. The settings for machine data 9824 the interface signal DB3n.DBX17.6 must be observed.

Main spindle direction of rotation	MD 9822*	MD 9824	DB3n.DBX17.6
C++++ M3	0	0	0
C+P M4	1	0	1
С+ M3	1	1	0
M4	0	1	1

Table 11-1 Direction of rotation of main spindle

The setting of machine data marked with "*" assumes that the viewing direction was towards the negative coordinate axis. If on the other hand you are looking towards the positive coordinate axis, you need to reverse the values, i.e. swap "0" and "1".

Machine data 9822 is only relevant for display in the ShopTurn interface, not for correct operation on the machine.

11 Miscellaneous

11.3 Spindle control

Counter-spindle direction of rotation	MD 9823*	MD 9825	DB3n.DBX17.6
M3 (C+)	1	0	0
M4	0	0	1
M3	0	1	0
M4	1	1	1

Table 11-2 Direction of rotation of count

The setting of machine data marked with "*" assumes that the viewing direction was towards the negative coordinate axis. If on the other hand you are looking towards the positive coordinate axis, you need to reverse the values, i.e. swap "0" and "1".

Machine data 9823 is only relevant for display in the ShopTurn interface, not for correct operation on the machine.

11.4 ISO dialects

You can also create and run ISO dialect programs under ShopTurn. For more information on how to set up ISO dialects, please refer to the following documentation:

References: /FBFA/, Function Manual on ISO Dialects for SINUMERIK

11.5 Automatically generated programs

11.5 Automatically generated programs

ShopTurn creates certain programs automatically during operation.

Directory of part programs:

- **CMM_SINGLE** The program is created when a function is executed in "Manual" mode. The program is started via an asynchronous subprogram.
- **INPUT_DATA_MM INPUT_DATA_IN** The last parameter values entered in a screen are saved in these programs, depending on the unit of measurement. (INPUT_DATA_MM = values with the unit "mm"; INPUT_DATA_IN = values with the unit "Inch")

Directory commissioning:

REM_DATA.TRC Data which needs to remain stored when the machine is next switched off (e.g. the last selected program) is saved in this program.

11.6 Manual machine

Option	"Manual machine" is an option (Order No. 6FC5 800–0AP11–0YB0).
	The "Manual machine" option allows work to be carried out with large cycles in manual mode, without the need to write programs for this purpose.
	For a more detailed description of the cycles available in "Manual" mode, and how to work with the "Manual machine" option, please refer to:
	References: /BATsl/, Operation/Programming ShopTurn
	Manual operation in the "Manual" mode is based on the jogging functions in the NCK.
Tool selection	For tool selection enter the name of the tool and start by means of "Cycle start".
	 Turret revolver With "Cycle start" the turret revolver starts to rotate.
	 Multifix With "Cycle start" tool correction is activated.
Feedrate	SD 42600 JOG_FEED_PER_REV_SOURCE is used to stipulate whether one or two feed fields should be available in the basic screen "Manual".
	 42600 JOG_FEED_PER_REV_SOURCE = 0 One feedrate field is offered. The entry field can be switched from mm/min to mm/rev. SD 41100 JOG_REV_IS_ACTIVE is then altered from 0 (mm/min) to 1 (mm/rev).
	 42600 JOG_FEED_PER_REV_SOURCE = -3 Two separate feedrate fields are offered for mm/min and mm/rev. The JOG function only uses the mm/rev feedrate when the main spindle is rotating. Otherwise, it uses the mm/min value.
	At the same time, the axis-specific setting data SD 43300 must be set so that it is identical for each of the relevant axes.
Feedrate override	With the MD 12200 \$MN_RUN_OVERRIDE_0 = 1, it is possible to move the handwheels even when there is a 0% feedrate override.

11.6 Manual machine

Rotational speed (main spindle)	The speed entry field can be switched between rpm and m/min. SD 43206 SA_SPIND_SPEED_TYPE is set accordingly to the appropriate G code (G94, G95, G96).
	 rpm SD 43200 SPIND_S is written.
	 m/min SD 43202 SPIND_CONSTCUT_S is written.
	You have the following possibilities for starting the spindle:
	 MD 9897 MM_ST_OPTION_MASK_MAN_FUNC Bit 0 = 1 Spindle start by means of "Cycle start". Select rpm or m/min and enter the desired value. Select the direction of rotation and start the spindle by means of "Cycle start".
	 MD 9897 MM_ST_OPTION_MASK_MAN_FUNC Bit0 = 0 Spindle start by means of external switch. Select rpm or m/min and enter the desired value. DB3x.DBB30.1 starts the spindle rotating clockwise. DB3x.DBB30.2 starts the spindle rotating counter-clockwise. DB3x.DBB30.0 stops the spindle.
Rotational speed (driven tool)	The rotational speed is displayed in rpm. SD 43206 SA_SPIND_SPEED_TYPE is set. SD 43200 SPIND_S is written.
	You have the following possibilities for starting the spindle:
	 MD 9897 MM_ST_OPTION_MASK_MAN_FUNC Bit 0 = 1 Spindle start by means of "Cycle start". In the input field enter the desired value for the rotational speed. Select the direction of rotation and start the spindle by means of "Cycle start".
	 MD 9897 MM_ST_OPTION_MASK_MAN_FUNC Bit0 = 0 Spindle start by means of external switch. In the input field enter the desired value for the rotational speed. DB3x.DBB30.1 starts the spindle rotating clockwise. DB3x.DBB30.2 starts the spindle rotating counter-clockwise.

DB3x.DBB30.0 stops the spindle.

11.7 Action log

You can log sequences of operations in ShopTurn in the action log to obtain a history of events for later examination.

More detailed information about the action log can be found in: **References:** /IHE/, Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl

Please refer to directory DOCUMENTATION\WINDOWLISTS on the ShopTurn DVD for the assignment between ID numbers listed in the log and the corresponding ShopTurn windows.

Note

If you are using a PCU 50.3 with HMI Advanced and wish to log ShopTurn operating sequences, you must enter the settings for the action log directly in MD 9012 \$MM_ACTION_LOG_MODE. The log is stored in the F:\MMCOW32\TMP_AC_LOG.BIN file. No support for display or readout of this file is provided.

11.8 Version display

11.8 Version display

You can see the ShopTurn version in the boot screen.

The version data of the installed system software are output in a version display.

- For this purpose switch to the CNC ISO operator interface.
- Select the menu "Diagnostics" ---> "Service displays" ---> "Version".

More detailed information about the version display can be found in the following documentation:

References: /IHE/, Commissioning Base Software and HMI Embedded sl, SINUMERIK 840D sl; /BAD/ Operating Manual HMI Advanced, SINUMERIK 840D sl/840D/840Di BEMsl/ Operating Manual HMI Embedded sl, SINUMERIK 840D sl

Α

Abbreviations

ASUB	Asynchronous subroutine
BAG	Mode group
BUFF	Buffer
CNC	Computerized Numerical Control
СОМ	Communication Component of NC control that performs and coordinates communication.
DB	Data block
DBB	Data Block Byte
DBD	Data Block Double Word
DBW	Data Block Word
DBX	Data Block Bit
FC	Function Call, function block on the PLC
GUD	Global User Data
HPU	Handheld Programming Unit
IBN	Commissioning
МСР	Machine control panel
MD	Machine data
MDA	Manual Data Automatic
MPF	Main program file: Part program (main program)
МРІ	Multi-Port Interface
NC	Numerical Control The NC control comprises the components NCK, PLC, PCU and COM.

NCK	Numerical Control Kernel Component of NC control that executes programs and basically coordinates movements for the machine tool.
NCU	Numerical Control Unit: NC module
ОВ	Organization block in the PLC
OP	Operator Panel
PC	Personal computer
PCU	Personal Computer Unit Component of NC control allowing communication between operator and machine.
PG	Programming device
PLC	Programmable Logic Control Component of NC control for processing machine tool control logic
RAM	Random Access Memory, i.e. program memory that can be read and written to
SD	Setting data
SK	Softkey
SPF	Sub Program File
STL	Statement List
SW	Software
тм	Tool management
T No.	Tool number
ΤΟΑ	Tool Offset Active: Identifier for tool offsets
wz	Tool

Index

Α

Abbreviations, A-177 Action log, 11-175

В

B axis, Turning machines, 9-146 Bar loader, 10-156 Basic components, 1-11

С

Commissioning First, 4-18 NCK, 4-22 PCU 50.3, 4-20 PLC, 4-21 PLC tool management, 8-92 Process, 4-18 ShopTurn on NCU (HMI Embedded sl), 4-20 Software, 4-17 Tool management NCK, 8-78 Configuration file, 8-86 Variables, 8-88 Coolant, 8-104 Counterspindle, 9-143 Custom screen, 10-152 Cycles Link, 10-157 Transfer to machining plan, 10-156 User-configured, 10-152 Cylinder surface transformation, 9-129

D

Data transfer, 4-17 DB 71, 8-95 DB 72, 8-97 DB 73, 8-98 Direction of rotation, 11-168 Display machine data, 7-41 Tool management, 8-103

Ε

End of program, 11-168

F

FB110, 8-94 FC 100, 8-94 First commissioning, 4-18 Front end machining, 9-129

Н

Hardware, 1-11 Basic components, 1-11 Operator Components, 1-11

I

Inclined axis, 9-138 Input signals, 6-34 Interface DB 19, 6-29 Interface signals, 6-29 for ShopTurn, 5-27 ISO dialects, 11-171

Μ

Machine data, 7-39 Display, 7-41 NCK, 7-39 ShopTurn, 7-41 Machine manufacturer cycle, 11-167 Manual machine, 11-173 Measuring cycle, Display machine data, 9-126 Measuring cycles, 9-125 Integrate, 10-158 Support, 9-141

Ν

NCK commissioning, 4-22 NCK machine data, Tool management, 8-78 Network, 9-128

0

OP hotkeys, 10-164 Operator Components, 1-11 Output signals, 6-36

Ρ

Parts gripper, 10-156 PCU 50.3, Commissioning, 4-20 PLC Interface signals, 6-29 Program, 5-25 Program structure, 5-25 PLC commissioning, 4-21 PLC keys, 10-164 Programs, generated automatically, 11-172

R

Reserved functions, 3-15 Revolver, Manual movement, 8-105

S

Sample source files, 5-25 Screen form, User–configured, 10-152 Setup feed rate, 7-40 ShopTurn interface DB 82, Former, 6-34 ShopTurn on NCU (HMI Embedded sl) Commissioning, 4-20 Settings for operator interface, 10-160 ShopTurn Open, 10-159 ShopTurn software, 4-17 Software commissioning, 4-17 Spindle, 8-104 Spindle control, 11-168 ST_CUST, 11-167 Start softkey, 10-152, 10-153 Status display, 10-161 Supplementary axis, 7-62, 7-63 Supplementary Conditions, 2-13 Support, Measuring cycles, 9-141

Т

Tailstock, 10-156 to turn.ini, 8-110 Tool list, Coolant and direction of rotation, 8-104 Tool management, 8-75 Blocks, 8-93 Configuration file, 8-86 Configuring the operator interface, 8-108 Coolant, 8-104 Display machine data, 8-103 NCK commissioning, 8-78 NCK machine data, 8-78 Overview of functions, 8-75 PLC commissioning, 8-92 Spindle, 8-104 Toolholder, Two, 9-147 **TRAANG**, 9-138 **TRACYL**, 9-129 TRANSMIT, 9-129 Turning machines, B axis, 9-146 Two tool carriers, 9-147

U

User status display, 10-161

V

Version display, 11-176

W

Window ID, 11-175
	Suggestions
	Corrections
	For Publication/Manual:
Postrach 3180	SINUMERIK 840D sl
D–91050 Erlangen	ShonTurn
Phone: +49 (0) 180 5050 – 222 [Hotline]	
Fax: +49 (0) 9131 98 – 63315 [Documentation] mailto:docu.motioncontrol@siemens.com	Manufacturer/Service Documentation
From	Commissioning Manual
Name	Order No.: 6FC5397–5AP10–2BA0 Edition: 01/2008
Address of your company/department	If you find any errors when reading this
Address	publication, please use this form to notify us.
Zip code: City:	welcome.
Phone: /	_
Fax: /	

Suggestions and/or corrections

Overview



DOCONCD *) DOCONWEB

*) Recommended minimum scope of documentation