

VM15 Panel quick guide

User manual VM15 – Panel quick guide

> 9UMEN1513-1200 Release: 220128



VM15 Panel & Keyboard









VM15 HMI Panel Functions



Access the System page			
Press until the dialog box displays "SYSTEM" then release to access	s the System	bage	
Balancer 1 Devices Version Status VM251H011 v.100.090713 0 BS ModRM:rest v.100.090713 D BS ModRM:rest v.100.090713 D BS Tomich Deletory 1 v.100.090713 D BS Deletory 1 v.100.090713 D BS		F1	Connect to the system (scan)
System		F2	Disconnect communication with the system
0.00 mm/s 0 0		F3	Go to <u>SERVICE</u> mode

VM15 HMI Setup access				
Starting from System page, press then:				
Devices Version Status	ABC	F1	Language setup	
VM25 HMI 1 V. 10.0.080713 D BS HMI Mutilink 1 V. 10.0.080316 D BALANCER 1 Balancer 1 V. 10.0.080423 D BS TOUCH DETECTOR 1 Touch Detector 1 V. 10.0.081405 D HW MULTILINK 1	******	F2	Login access	
	†	F3	Backup / Restore / Upgrade	
Press (ENTER) to execute the command	×.	F4	Contrast / Brightness regulation (for monochrome display only)	
	S REBOOT	F2	Reboot VM15 HMI	



П

Language setup			ᢪ ABC
Using or or select the language and press . The activation	tion of the new lar	nguage t	takes a few seconds
Language Italian English-LK Press [ENTER] to execute the command	F	-6 Ex	ćit

Login access			****
Using + key in the PASSWORD to login and press .	For a complete	e list of	the passwords see table below.
Login level: Balance Systems Digit password ****		F1	Save login & Exit
Login level: Installer ◆ 💾 👰	•	F6	Apply & Exit without saving

Password	Name	Description
Login		
1	Observer	The system works in automatic mode only with no commands available for the user
1294	Operator	The system works in automatic mode only. The user can access the commands available in automatic mode (i.e. LIMITS CORRECTION, GAUGE OFFSET, etc.). Depending upon the choices of the system installer, the manual mode for the balancer functions can be available for the user
1 4 3 2	Programmer	The system works both in automatic and in manual mode. The user has access the working parameters and some setup parameters
1 2 2 1	Installer	Full system control and access to all parameters
Config		
13489	Output Logic	Enables changing of the digital output logic of the function cards

Backup / Restore system parameters and configuration – Software Upgra	ade		2
	sys 💾	F2	System backup
HMI BALANCER 1 MULTNET 1 TOUCH DETECTOR 1	Mst 💾	F3	Master backup (portable file)
WD Counter 0	Rst 💾	F4	Restore
Press [ENTER] to execute the command		F5	Software Up-grade
		F6	Log file viewer



Parameter modification

Parameters	Procedure to access		
HMI PARAMETERS (System parameters)	press	until the dialog box displays	"SYSTEM" then <u>release</u> to access the System page ect "HMI" and to access the HMI parameters
FUNCTION CARD PARAMETERS - Balancer - Touch Detector - Gauge - Multilink	NOTE: the acce press An alternative: press	ess to function card parameter from the status page of until "SYSTEM" is disp	er is allowed <u>in MANUAL MODE only</u> of the function card blayed then <u>release</u> to access the System page to select the function card (i.e. BALANCER 1) and
Parameter category	Com	mand to access	Description
WORK		F1	Working parameters to perform the process under control. They are usually identified as PART-PROGRAM
SETUP	∦ ÷>	F2	Full set of parameters to setup the input/output, to configure the sensors and actuators and to optimize the filters and algorithms
OPTION	\mathbf{V}	F3	List of options which can be installed for each function

Parameter type	Property	Procedure to modify the value
		• SHIFT + to key in the numerical value
	DEFAULT VALUE: factory presets	 value to decrement or increment the
Numerical	<u>RANGE</u> : MinMax <u>MEASURING UNIT</u> (if applicable)	to apply the DEFAULT (factory set) value
		NOTE: A value out of RANGE is rejected
List of values	DEFAULT VALUE: factory presets	to change the value in the list to apply the DEFAULT (factory set) value to save the new value







List of System commands

Main comma	ands				
	F1	Connect to the system			
	F2	Disconnect communication with the system			
	F3	Go to <u>SERVICE</u> mode			
📲 ABC	F1	Language setup			
* *	F2	Login access			
10 1	F3	Backup / Restore / Softwar	re Up-grade		
<mark>∳</mark> sys	F2	System Parameters Backu	ıp		
nst	F3	Master Parameters Backup	Master Parameters Backup (portable file)		
Rst 💾	F4	Parameters Restore			
•	F5	Software Up-grade			
	F6	Log file viewer			
$\dot{\nabla}$	F4	Contrast / Brightness regulation (for monochrome display only)			
S REBOOT	F2	Reboot VM15 HMI			
General com	mands avai	ilable in the procedures			
	-	Confirm / Apply		-	Cancel
\bigcirc	-	Start	\bigcirc	-	Stop
	F6	Next menu or step	-	F1	Previous menu or step
	-	Delete file			
	F1	Save & Exit	→ 🚺	F6	Exit



Device recognizing









Status icons

Unbalance					
∔	Unbalance inside min tolerance				
¢←	Unbalance inside max tolerance				
•	Unbalance out of tolerance				
(ALARM: Max vibration				
	Spindle rotation speed				
6	Spindle steady				
e nin Ok	Spindle at nominal speed				
33	Spindle not at nominal speed				
MAX	ALARM: Spindle speed over max limit				
	ALARM: Rotation speed fault				

	Balancing head			
Ø	Neutral position reached			
1	WARNING: Neutral cycle impossible			
•	ALARM: Neutral cycle fault			
MAX	ALARM: Max compensation reached			
1,2	ALARM: Balancing head motors fault > Execute Neutral cycle			
	Accelerometer (pick-up)			
PICKUP	ALARM: Dickup foult			
.				
	Balancing cycle			
	Balancing cycle WARNING: Automatic balancing impossible			
	Balancing cycle WARNING: Automatic balancing impossible WARNING: Balancing timeout			
	Balancing cycle WARNING: Automatic balancing impossible WARNING: Balancing timeout			
	Balancing cycle WARNING: Automatic balancing impossible WARNING: Balancing timeout General			
	Balancing cycle WARNING: Automatic balancing impossible WARNING: Balancing timeout General ALARM (generic)			

	NoLink collector
1)	WARNING: Collector not ready
	Hardware link in progress (animated)
	Communication link in progress (animated)
)	Collector connected
Ϧ₽	WARNING: Collector misaligned
₽₽	WARNING: Static part protection
₽₽	WARNING: Rotating part protection
Ĵ [€]	ALARM: Temperature on static part
₽ <mark>₽</mark> ₽	ALARM: Temperature on rotating part
k e	ALARM: Static part
P <mark>.</mark>	ALARM: Rotating part
	Brushes collector
₽0N *	Brushes collector: Power ON
	Ring collector: Electrovalve ON



Commands

	Main commar	nds				e e e e e e e e e e e e e e e e e e e
	₽ ₽	F1	Start automatic balancing c	ycle [1 plane]		
	0	F2	Start automatic neutral pos	itioning cycle [w	veights @ 18	0°]
	🦣 🔶 🕩	F3	Start manual driving of bala	incing head mo	tors	
Г	•	F4	IF ENABLED - Start guided	l manual balanc	ing procedu	re [1 plane] (PRE-BALANCING)
				Manual balar	ncing proce	dure [1 plane]
				(+)=?	F2	Calibration

				Assess of the second		
Į	8	F2	Weights acquisition	<u>8</u> 73	-	End weights acquisition
	\mathbb{Z}	-	Change	1 (+) 2	F3	Corrections
	⇒ 💾	-	Save calibration	} →	-	Ignore / Skip

Manual driving of balancing head motors										
	COMBI	NED mode		INDEPENDENT mode						
1(+)2	F1	Cross forward	1 + 1	F1	Motor 1 forward					
1(+)2	F2 F2 Cross backward		1 (+)	F2	Motor 1 backward					
1(+)2	F3	Both forward	(İ +) 2	F3	Motor 2 forward					
1(+)2	F4	Both backward	(† +) 2	F4	Motor 2 backward					
(+) _{1/2}	F6	Switch to "Single mode"	(+) ₁₊₂	F6	Switch to "Combined mode"					

Commands ir	n Parameter	Setup	∕∕ �
E TEST	F4	To check the wiring of the DIGITAL INTERFACE [Connector B1]	



TOUCH DETECTOR [TD]



Status icons

	Outputs			Sensors		F
1 2 3 4	Output limits activated		AE1 √/→	WARNING: Acoustic Emission sensor No.1 not ready	FFT	FF
1 2 3 4	Output limits ready		AE2 √/→→	WARNING: Acoustic Emission sensor No.2 not ready	FFT MAX	FF
		-	AE3	WARNING: Acoustic Emission sensor No.3 not ready	FFT Ø	FF
			AUX ≁/	WARNING: Auxiliary sensor not ready		
			₽ ↓/,====	WARNING: Power sensor not ready		



Glossary

AE = Acoustic Emission Aux = Auxiliary source P = Power V = Variable



	Elivei
MASTER	No stored time duration
	Time duration learning in process
	Time duration learning error
MASTER	Time duration learning correct executed
	No stored master
	Master learning in process
	Master learning error
	Master learning good
Ľ	Process timeout
de la companya de la comp	Autostart timeout
<u>це</u> ,	Envelope in progress
	Process stopped

Envelope - Status signalling

U U	
	Zone over tolerance
цШ ЦЦ	Zone below tolerance
	Zones out of tollerance
	lp max
	lp min
	lp crash
	lp max – min
四 日	Envelope End
eccor	Envelope good
MAX بىلى	Process over tolerance
μ <u>η</u>	Process below tolerance
	Process out of tolerance





Commands

	Commands in Automatic Mode									
/	<u></u> ‡ 1	F1	Quick Limit 1	correction						
	2	F2	Quick Limit 2 correction							
	‡ 3	F3	Quick Limit 3	correction						
	↓ ‡ 4	F4	Quick Limit 4	correction						
	Commands in I	Manual Mode			<u>ب</u>					
	// RESET	F1	Reset							
	1= 2= 3=	F2	Edit Part Prog	ram FORMULA for	output limits definition					
•		F3	Access to Qui	ck Limits correction	1					
	n	F4	IF ENABLED	- Part-Program sele	ection					
	ZOOM ⊕ N	F5	Zoom in on di	agrams						
		F5	Zoom out on o	diagrams						
		F2	Setup of Variable V1							
	V2	F3	Setup of Varia	able V2						
	V3.	F4	Setup of Varia	able V3						
	يت المراجع	F5	Setup of Varia	able V4						
	🥢 Р	F2	Setup of Powe	er transducer [Conr	nector D4]					
			Zoom	1.4 9.4						
					Toggle ON/OFF V1 diagram					
					Toggle ON/OFF V2 diagram					
					Toggle ON/OFF V3 diagram					
					Toggle ON/OFF V4 diagram					
					Toggle ON/OFF P diagram					
	Limi	ts correction								
	NOT	E: the content	s of the menu de	pends on the formu	la of the active part-program					
	a	V x	aP x		Absolute limit correction					
	i۱	/ x	iP x		Incremental limit correction					
	ď	V x	dP x		Delta limit correction					



Edit Part-F	Edit Part-Program: FORMULA								
			Те	rm					
	Output	Digital Output signalling	Source elaboration	Source	Channel	Compare	Threshold	Operator	
	Limit 1 = Limit 2 = Limit 3 = Limit 4 =	[N] = No Latch [L] = Latch [E] = Edge	[a] = absolute [i] = incremental [d] = delta	V P	18	~ v	xxx	+ = logical OR with next term . = end	
			Term Pr	otection			Threshold protection		
Example: ⁻ Limit 1 = N	The process I iV 1 > 30.0 Limit 1 is us 15%). The d	s uses acoustic of + N iP 1 > 15 sed as <u>GAP ELIMIN</u> igital output signal is	emission and powe ATION based on increr NO LATCHED (free ru	r sensors s nental value c nning)	i multaneou s f variable 1 (g	sly greater than 30%	5) OR power cha	nnel 1 (greater than	
Limit 2 = L	.a > 0.0								
	Limit 2 not u	sed							
Limit 3 = L	. aP 1 > 80.	0							
	Limit 3 is us digital outpu	sed as <u>ANTI-CRASH</u> t signal is LATCHED	<u>H</u> detection based on th until the next reset.	ne absolute is	tantaneous va	lue of the powe	r channel 1 (gre	ater than 80%). The	
Limit 4 = L	.a > 0.0								
	Limit 4 not u	sed							
NOTE: Ter	NOTE: Terms or Thresholds which appears in "reverse mode" are protected by the system installer								
Ex	ample: Lim	it 1 = N iAE 1 > 3	0.0 + <mark>N iP 1 ></mark> 15						
Th	e term "N iP	1 >" is protected	and can only be mod	lified by syst	em installer	only.			

Commands in FORMULA editing									
-	F1	Lock term or threshold for protection							
-	F1	Unlock term or threshold for protection							

Commands	Commands in Power input Setup								
□ VM 1 2		F1		To assign the network address to the power transducers					
^{KW} 100%		F2		Motor power setup [100% = Max power]					
RMS RMS		F3		RMS filter setup					



Commands	in \	/x Variable S	etup	الليليم 🥓	ساسل مح	2. <u>/ 1.1.173</u> / 1.1.174
RESET					F1	Reset status
adada. 🎢		idicile. MAX			F2	Toggle FFT: Free running / Peak detection
հոր ¦ճեր		hille FFT			F3	Toggle FFT: Zeroing / Reset zeroing
- ^B					F4	Gain of the input signal
					F5	Digital filters setup
			F2		F1	Digtal Band-Pass No.1 setup
			F2	OFF	F2	Toggle: Digtal Band-Pass No.1 ON / OFF
					F3	Move down digital high pass filter
					F4	Move up digital high pass filter
				llzlt	F5	Move down digital low pass filter
					F6	Move up digital low pass filter
			F3		F1	Digtal Band-Pass No.2 setup
		ON	F2	OFF	F2	Toggle: Digtal Band-Pass No.2 ON / OFF
					F3	Move down digital high pass filter
					F4	Move up digital high pass filter
					F5	Move down digital low pass filter
					F6	Move up digital low pass filter
1000 //					F2	Variable setup: RMS Filter / Fullscale
					F4	Working window selection
					F3	Move down working window
					F4	Move up working window
		4			F5	Decrease gain in working window
		Å+			F6	Increase gain in working window
•//>*					F5	Sensor ready check setup

Commands in Parameters Setup					
E TEST	F4		To check the wiring of the digital interface [connectors D1 and D2]		





Envelope commands in Manual Mode			
// RESET	F1	Reset / Enable	
⊗ & ⊘ &	F2	Start process Stop process	
	F3	Start learning Stop learning	
西区	F4	Master delete	
🥖 🧑	F7	Edit mode	
Commands in e	edit mode p	age	<u>/</u>
< 🛄	F1	Move left and select	
<u>p</u>	F2	Move right and select	
((() +	F3	Increase top selected	
	F4	Decrease top selected	
<u></u> +	F5	Increase bottom selected	
- 🖽	F6	Decrease bottom selected	
	F 7	Disable selected	
он 🕕	F7	Enable selected	
- 📠	F1	Decrease top curve	
<u>4</u>	F2	Increase top curve	
- 🖽	F3	Decrease bottom curve	
+	F4	Increase bottom curve	
日日	F6	Master save	



GAUGE [Type GA - NG]

In-Process Gauging and In-Process Gauging with Roundness Analysis





Pre/Post-Process Gauging



Post-Process Roundness & Shape Analysis





Status icons

Outputs				
1 2 3 4 0 8	In-Process skip commands activated			
1 2 3 4 0 A	In-Process skip commands resetted			
12	Post-Process Gauging or Roundness components out of tolerance			
12	Post-Process Gauging or Roundness components in tolerance			
τ	Start cycle delay expired			
τ	Start cycle delay not expired			
D	Dwell timer expired			
D	Dwell timer inactive			
0	Runout out of tolerance			
	Runout in tolerance			
0	Roundness disabled			
	Roundness & Shape			
\bigcirc	Runout error			
\bigcirc	External deviation			
Q	Internal deviation			
Ô	Excentricity			
Q	Ovality			
\bigcirc	3-lobe			
	4-lobe			
\Diamond	5-lobe			
1 mg	Residual			

Transducers			
₽	Overrange		
1	Max measurable dimension		
OK D	In gauging position		
OK 1	Retracted		
	ALARM: retraction not executed		
	ALARM: retraction hold		
OK 📕	Retraction hold executed		

Gauging			
₽ ₽₽	In-process gau	ging	
	Pre / Post-proc	ess gauging	
□ 1	Flagging		
\bigcirc	Roundness & shape analysis		
μm mils	Measuring unit		
ر	Correction offset value		
Dimension			
+	<mark>─→</mark> OVR	Overrange	
MAX Max limit			



Commands

	Commands in A	Automatic mo	ode				
\langle	Ø	F1	Offset increme	ent			
	Ø	F2	Offset decrem	ient			
	Ø	F3	Offset reset	Offset reset			
	Commands in I	Manual mode			Ф		
		F1	Signalling rese	et and start cycle			
	Ø	F2	Access to offs	set correction			
	Ø	F3	Access to zero	oing menu			
	n	F5	Part program	change			
	\bigcirc	F6	Access to rou	ndness and shape	analysis		
			Roundness				
		F	/RESET	F1	Signalling reset and start cycle		
			Ø D==	F2	Access to mechanical zeroing		
			Zeroing				
			Ø 5=-	F1	Access to mechanical zeroing		
			→Ø←	F2	Electrical zeroing		
			+ +	F3	Electrical zeroing reset		
			- Ø + Master	F4	Master deviation from zero setting		
Ļ							











Part program: ROUNDNESS FORMULA					
Rnd = K Gx Transducer name Gain coefficient Roundness dimension					
The gauging of roundness is defined by setting a formula, of single term, where one of the four transducers is selected (G2, G3, G4, G5). The structure of the formula is as follows:					
Rnd = K Gx where x = 2, 3, 4, 5.					
the meaning of coefficient K can be summarised: K = Kq Kx (see <u>measure formula</u>). The role of coefficient K is that of weighing up the reading made by the transducer. The coefficient value is normally supplied in the technical sheet for the gauging head, since it depends on the sensitivity and mechanical construction of the transducer.					
The value of this coefficient can be set using the previously described procedure for the measure formula.					
Example: Formula for finger Lb = 70mm : Rnd = 1.614 G2					

Commands in Gx Transducers setup			
	F1	Connection and recognizing of the TG200 gauging head Every time that a gauging head, TG200-LG type, is connected with the system already on, it is necessary to execute the command for it to be acknowledged. In case, after the command, the corresponding configuration parameters are not displayed on the screen, it means the gauge head is not correctly connected or is faulty	

Commands in I	Parameter Set	tup 🗡 🍾
E TEST	F4	To check the wiring of the DIGITAL INTERFACE [Connettore G1]



Notes:	