

# VM15 HMI Quick guide

User manual VMx5 HMI - Quick guide

> 9UMENX521-1200 Release: 220128



#### VM15 HMI & Keyboard

VM25 HMI - Ver. 12.0.170209 15/02/2017	15:58:08						[]
System info	Device	Ver.				$\bigcirc$	Shift + F1
Login level Installer	€ HMI 50	12.0.170209					
Language English US Host address 10,168,0,67							
Port 4000							Shift + F2
Connection status Connected							Offine 112
							Shift + F3
							51111 + 1 5
						<b>A</b>	
							Shift + F4
							Shift + F5
							Shift + F6
							Shift + F7
Balance							
Systems							
<b>S</b>							Shift + F8
		~ <b>€</b>					
F1 F2	F3   F4	F5	F6	F7	F8		
					ĿŬ		

#### LEGENDA

Screenshot	ID	lcon	Button	Description
	0017	•	Shift+F8	Exit

# NOTES

Tooltips on command and status icon could appear as further help to the user



# **VMX5 HMI Functions**

While the system starts up				
	Software version			
Function cards included in the SYSTEM CONFIGURATION Host address 10,168,0.69 Port 4000 Connection status Connected	Prison-51 Device Ver. HMI 50 12.0.170224 Balancer 1 Gauge 1 12.0.170218 Touch Detector 1 Statement of the second se	atus:  recognized ok atus:  not recognized C o m m a n d s		
Balance Systems	€			
	Commands			

Access the System page							
Click on to access the System page							
	0002		F1	Connect to the system (scan)			
	0003	, <b>x</b>	F2	Disconnect communication with the system			
	0004		F3	Go to <u>SERVICE</u> mode			



Login access						
In the systems page click on	to access to login page					
And A former A many and A more and A many an		0015	Ŋ	F2	Confirm	
Regarding production for includent	\$	0006	<b>○</b> <u>***</u> -	F3	Change password	
	-0	0017	►	Shift + F8	Exit	

Password	Name	Description
Login		
1	Observer	The system works in automatic mode only with no commands available for the user
1294	Operator	The system works in automatic mode only. The user can access the commands available in automatic mode (i.e. LIMITS CORRECTION, GAUGE OFFSET, etc.). Depending upon the choices of the system installer, the manual mode for the balancer functions can be available for the user
1 4 3 2	Programmer	The system works both in automatic and in manual mode. The user has access the working parameters and some setup parameters
1 2 2 1	Installer	Full system control and access to all parameters
Config		
13489	Output Logic	Enables changing of the digital output logic of the function cards

VMX5 HMI Setup access	
Starting from System page, press to access the HMI system	em setup
	Language setup
	Connection setup
	Devices setup
	Layout setup
Balance Systems	Data recording setup
	Print setup
	VM Link setup



#### Language setup



# **Parameter modification**

Parameters	Procedure to access							
HMI PARAMETERS (System parameters)	Click on       Image: Click on       to access the System         Click on       to access the HMI para	page ameters						
FUNCTION CARD PARAMETERS - Balancer - Touch Detector - Gauge - Multilink	NOTE: the access to function card parameters <u>Click on</u> from the status p	er is allowed <u>in MANUAL MODE only</u> age of the function card						
Parameter category		Description						
WORK	Working parameters to perform the process under control. They are usually identified as PART-PROGRAM							
SETUP	Full set of parameters to setup the input/output, to configure the sensors and actuators and to optimize the filters and algorithms							
OPTION	List of options which can be installed for each function							
Parameter type	Property	Procedure to modify the value						
Numerical	DEFAULT VALUE: factory presets RANGE: MinMax	<ul> <li>Double Click on value to modify</li> <li>Type the new value</li> <li>Press enter to apply the changes</li> </ul>						
	MEASURING UNIT (if applicable)	<b><u>NOTE</u></b> : A value out of RANGE is rejected						
List of values	DEFAULT VALUE: factory presets	<ul> <li>Double Click on value to access the list of values</li> <li>Click on the value to set it</li> </ul>						







#### List of System commands

ID	Icon	Button	Description
0001		Shift + F1	Shut down VMX5 HMI application
0002		F1	Perform the connection between the VMX5 HMI and the control unit
0003	· <b>×</b>	F2	Disconnect the VMX5 HMI application from the control unit
0004		F3	VMX5 HMI application goes in "sleep" mode in order to allow a remote connection for service operation
0005	બ્ન	F5	Change the login level. Enter a password is needed
0006	<b>میں</b> ***-		Change the password to login
0008	í	Shift + F3	Show additional information on parameters
0095		Shift + F3	It displays last opened viewer page
0010	<b>©</b>	Shift + F2	Change the displayed page between the devices included in the system configuration
0011	Ē	Shift + F4	Print screen on the default printer
0012		Shift + F6	Switch between Automatic and Manual mode
0013	ومر 🗐	Shift + F4	Access to parameters setting
0014			Access the system configuration
0015	$\mathbf{\nabla}$		Confirm the operation
0016	$(\mathbf{X})$		Cancel the request



ID	Icon	Button	Description
0017	→ [	Shift + F8	Exit from the function
0018			Exit from the function and save all data
0019	<b>B</b>	F1	Load the factory preset value
0020		F5	Show the parameters organization as Explorer
0021		F7	Show the parameters organization as list
0022			Resize the preview as whole page
0023			Restore or load data
0024			Backup or save data
0025	Š		Change the setup
0026			Load the factory preset colors
0027			Move up the cursor
0028	▼		Move down the cursor
0029			Move left the cursor
0030			Move right the cursor
0031	+		Increase the value of the parameter



ID	Icon	Button	Description
0032	—		Decrease the value of the parameter
0033	◀	F1	Show previous menu
0034		F8	Show next menu
0035	I.↓ O.↓ Profi		Access to Profibus / ProfiNET monitor function ("sniffer")
0036	I.↓ O.↓		Access to digital I/O interface test function
0037	<b>∐€</b> K7		Access to digital I/O interface test function on connector K7
0038	[[ <b>↓</b> [○] • K8		Access to digital I/O interface test function on connector K8
0039	0		Set the digital output to "0" (low)
0040	1		Set the digital output to "1" (high)
0041	n		Select and activate the part program
0042	// RESET		Reset or enable the device
0043	x1 = x2 =		Switch off the display of diagnostic data
0044	x1 = x2 =		Switch on the display of diagnostic data
0045	$\bigcirc$		Switch off
0046	U		Switch on



ID	Icon	Button	Description
0047			Start
0048	$\bigcirc$		Stop
0049	ſ		Lock the selected parameter. Only the login as "installer" has the rights to unlock the data
0050	Ţ		Unlock the selected parameter
0051	+ A.O. - 010V		Access to analog output calibration procedure
0052	+ A.O. - ± 10V		Access to analog output calibration procedure
0053	1		Start the test cycle No.1
0054	2		Start the test cycle No.2
0057	Ð,		Zoom in
0058	Q		Zoom out
0059	REC	Shift + F5	Start the data recording
0060	STOP	Shift + F5	Stop the data recording



#### **Device recognizing**

Device card layout	
BI (DIGITAL INTERACT BI (DIGITAL INTERC BI (DIGITAL INTERCACT BI (DIGITAL INTERCACT	Balancer [BN type]
DI DITAL NEW VITH UNIT NUM VITHO DIGITAL NEW VITH UNIT NUM VITHO DIGITAL NEW VITH UNIT NUM VITH UNIT NUM VITH UNIT NUM VITHO DIGITAL NEW VITH UNIT NUM VITH UNIT NUM VITHON VITH UNIT NUM VI	Touch detector [TD type]
GAUGE G2 G3 G4 06 00 00 00 00 00 00 00 00 00 00 00 00	Gauge [GA type]
GI GI GI GI GI GI GI GI GI GI	Gauge [NG type]
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	Multinet [MN Type]



#### 1 PLANE BALANCER [BN type]



- A. Current device & Part-Program
- B. Operating mode (Automatic / Manual). Blinks while cycle in progress
- C. Area reserved to status icons.
- D. Graphic area to rappresent the unbalance diagram:
  - Diagram
  - Programmed tolerance limits
    - Unbalance value
- E. Spindle rotation speed diagram: rotation status, limits.
- F. Balancing head diagram. The indication in the bar graphs are proportional to the speed of the weights. The symbol "→I" indicates that the two compensation weights are in contact.
- G. Messages and diagnostic data display area
- H. Horizontal command line, accessible by [Fx] buttons.
- I. Vertical command line, accessible by [Shift+Fx] buttons.



# Status signalling

Unbalance								
3001	↓ ●←	Unbalance inside min tolerance						
3002	↓ ●←	Unbalance out of tolerance						
3022	<u>e</u>	ALARM: Max vibration						
	Spindle rotation speed							
3008	Ø	Spindle steady						
3004	OK	Spindle at nominal speed						
3005	n	Spindle not at nominal speed						
3006	MAX	ALARM: Spindle speed over max limit						
3007		ALARM: Rotation speed fault						
	NoLin	k collector						
3031	î» 👌	Warning: link impossible						
3023 3028		Communication link in progress (animated)						
3029 3030		Link optimization in progress						
3032	I OK	Link OK						
3015	₽ <mark>?</mark> □	WARNING: Collector misaligned						
3010	₽□	Warning: current limit reached on static part						
3013	P 🗧	Warning: current limit reached on rotating part						
3009	₽.	ALARM: Temperature on static part						
3012	• <b>C</b>	ALARM: Temperature on rotating part						
3011	<u>,</u> d	Warning: static part error or fault						
3014	₽ <b>=</b>	Warning: rotating part error or fault						
3033		Warning: Active AE link impossible						
3034	Î ok	Active AE sensor OK						
3035	AE •//•	Warning: Active AE sensor not ready						

	Balancing head						
3017	0	Neutral position reached					
3019	(Ø)	Warning: neutral cycle error or fault					
3018	<b>@</b>	Warning: neutral cycle impossible					
3021	MAX St	Warining: Max compensation reached					
3020	() ()	Warning: motors error or fault >> Neutral cycle required					
	Accelerometer (pick-up)						
3003		ALARM: Pickup error or fault					
		Balancing cycle					
3039	<b>↓</b> ▲	WARNING: balancing cycle impossible					
3038	<b>+</b> <sup>™</sup>	WARNING: Balancing timeout expired					
		General					
1004	1	Generic error or fault					
	Brushes collector						
3016	ON ON	Brushes collector: Power ON					
3036		Ring collector: Electrovalve ON					



# Commands

Main comm	ands		۳.
2001 2002	<u>+@</u> + <u>+⊘</u> +	F1	Start/ Stop automatic balancing cycle [1 plane]
2038 2039	0	F2	Start/Stop automatic neutral positioning cycle [weights @ 180°]
2015	¢	F4	Manual driving of balancing head motors
2044	<u>+</u> ∰ +	F2	IF ENABLED - Start guided manual balancing procedure [1 plane] (PRE-BALANCING)
2014		F7	Unbalance diagram
2043 2042	I) O I 3 O	F2	Collector ON/OFF

				▲ Manual balancing procedure [1 plane]			
				2049	+)=?	-	Function to learn the weight
2046	<u>i</u> +	-	Balancing weight acquisition	2047		-	Stop balancing weight acquisition
2062	₽Š	-	Weight change	2050	$\odot$	F1	Weight position correction
0024	⇒∎	-	Data save	2048		-	Ignore

Manual driving of balancing head motors									
	COM	ode		SINGLE mode					
2031	1 🔁 2	F1	Cross forward	2020	1👀	F1	Weight 1 forward		
2030	1 🔂 2	F2	Cross backward	2019	1 🕀	F2	Weight 1 backward		
2032	1 🔂 2	F3	Parallel backward	2022	(+ <b>)</b> 2	F3	Weight 2 forward		
2033	1 🔂 2	F4	Parallel forward	2021	( <del>+</del> )2	F4	Weight 2 backward		
2018	$\odot$	F6	Switch to "Single mode"	2029	$\odot$	F6	Switch to "Combined mode"		

Commands	in Paramete	r Setup	
0036		F2	DIGITAL INTERFACE test [Connector B1]
0051	+ A.O. - 010V	F2	010V analog output calibration [Connector B2]



#### TOUCH DETECTOR [TD type]



- A. Device, Section, Setup, Part-Program
- B. Operating mode (Automatic / Manual). Blinks when cycle in progress
- C. Area reserved to status icons.
- D. Graphic area to rappresent the diagrams of the sources used to activate the limits 1, 2 and 3. The number of the diagrams displayed depends on the active part-program.
  - Source vs time diagram
  - Programmed limits
  - Status of the programmed limits
  - Numerical value of the sources

Sources values:

- a = absolute
- i = incremental
- d = delta
- M = max (peak)
- E. Graphic area to rappresent the source for an independent control of the limit 3. In this case the source is rappresented with a bar graph.
- F. Horizontal command line, accessible by [Fx] buttons.
- G. Vertical command line, accessible by [Shift+Fx] buttons.



		Status						
Outpu	its							
5001 5004 5007 5010	12 34	Output limits activated						
5003 5006 5009 5012	1 2 3 4	Output limits inactiveted						
FFT A	FFT Analysis							
5014	FFT パ	FFT in run mode						
5015	FFT PEAK	FFT in peak detection mode						
5013	FFT Ø	FFT ZERO active						
Envelope								
5056	MASTER	No stored time duration						
5043		Time duration learning in process						
5049	MASTER	Time duration learning error						
5050	MASTER	Time duration learning correct executed						
5030	MASTER	No stored master						
5042	MASTER	Master learning in process						
5054	MASTER	Master learning error						
5053	MASTER	Master learning good						
5031		Process timeout						
5032		Autostart timeout						
5034		Envelope in progress						

ig	nalling	l				
	5046	STOP	Process stopped			
	5040	MAX	Zone over tolerance			
	5041		Zone below tolerance			
	5055	MAX - MIN	Zones out of tollerance			
	5044	MAX	lp max			
	5047		lp min			
	5039         CRASH           5051         MAX - MIN		lp crash			
			lp max – min			
	5028	END	Envelope End			
	5033 <b>GOOD</b>		Envelope good			
	5045		Process over tolerance			
	5048		Process below tolerance			
	5052		Process out of tolerance			
			Sensor			
	5019	AE1	WARNING: Acoustic Emission sensor No.1 not ready			
	5021	AE2	WARNING: Acoustic Emission sensor No.2 not ready			
	5017	₽	WARNING: Power sensor not ready			
	5027	AUX	Warning: AUX sensor not ready			
	5018	POWER	Warning: Power sensor error or fault			
	5020	AE1	Warning: AE1 sensor error or fault			
	5022	AE2	Warning: AE2 sensor error or fault			
	5028	AUX	Warning: AUX sensor error or fault			

**Glossary** AE = Acoustic Emission Aux = Auxiliary source P = Power V = Variable



# Commands

Comma	Commands in Automatic Mode					
4001	<b>‡</b> 1	F1	Limit 1 correction			
4002	1002 <b>F2</b> Limit 2 correctio		Limit 2 correction			
4003	<b>‡</b> 3	F3	Limit 3 correction			
4004 <b>F</b> 4		F4	Limit 4 correction			
Commands in Manual Mode				$\mathbb{Q}$		
0042	RESET	F1	Reset / Enable			
4006	1 = 2 = 3 =	F2	Part-program formula setup			
4005		F3	Quick limit correction			
0041	n	F4	Part-program select			
4061	<b>V1</b>	F2	V1 variable setup			
4064	₽ V2	F3	V2 variable setup			
4067	y V3	F4	V3 variable setup			
4070	8 V4	F5	V4 variable setup			
4079	P A	F6	Power sensor setup			

Limits correction						
NOTE: the	NOTE: the contents of the menu depends on the formula of the active part-program					
aV x		aP x	Absolute limit correction			
iV x		iP x	Incremental limit correction			
dV x		dP x	Delta limit correction			



	Edit Part-Pr	ogram: FORMUL	A						
	Town								1
	Output	Digital Output signalling	Source elaboration	Source	Channel	Compare	Threshold	Operator	
	Limit 1 = Limit 2 = Limit 3 = Limit 4 =	[N] = No Latch [L] = Latch [E] = Edge	[a] = absolute [i] = incremental [d] = delta	V P	18	> <	xxx	+ = logical OR with next term . = end	
			Term Pr	otection			Threshold protection		
Example:	The process N iV 1 > 30.0 Limit 1 is us 15%). The d	s uses acoustic of + N iP 1 > 15 sed as <u>GAP ELIMIN</u> ligital output signal is	emission and power ATION based on incren NO LATCHED (free rur	r sensors si nental value c nning)	i <b>multaneou</b> : f variable 1 (c	<b>sly</b> greater than 30%	6) OR power cha	annel 1 (greater ti	han
Limit 2 = L	_ a > 0.0	lood							
Limit 3 = L	_ aP 1 > 80.	0							
	Limit 3 is us digital outpu	sed as <u>ANTI-CRASI</u> t signal is LATCHED	H detection based on th until the next reset.	ne absolute is	tantaneous va	lue of the powe	r channel 1 (gre	ater than 80%).	The
Limit 4 = L	_ a > 0.0								
	Limit 4 not u	ised							
NOTE: Terms or Thresholds which appears in "reverse mode" are protected by the system installer Example: Limit 1 = N iAE 1 > 30.0 + $NiP1 > 15$									
Tr	ne term "N iP	1 >" is protected	and can only be moc	lified by syst	em installer	only.			

₽ <u>∧</u> P	- Commands in	n Power inp	out Setup
4080		F2	Config power sensor network
4081	kW 100%	F4	Nominal power setup
4073	RMS	F3	RMS filter setup



₽ V		V3 &	/4 <sup>■…</sup> Commands in Vx	Variable Set	ир		
4046	FFT					F1	FFT Reset
4047	FFT - プ	4045	FFT PEAK			F2	FFT in run-time/peak- detector mode
4050	FFT +⊘+	4049	FFT + +			F3	FFT save/reset background noise offset
4056	B -					F4	Input gain setup
		4057	B			F1	Reduce input gain
		4058	B			F3	Increase input gain
		0015	$\checkmark$			F6	Confirm
4030						F5	Digital filters setup
		4031	[ <b>1</b> ]			F2	Band-pass filter No.1
		4033		4032		F4	Enable/Disable band-pass filter No.1
				4039	⊲k	F5	Reduce lower frequency
				4040	Lan II	F6	Increase upper frequency
				4037		F7	Reduce upper frequency
				4038		F8	Increase upper frequency
		4034				F3	Band-pass filter No.2
		4036		4035		F4	Enable/Disable band-pass filter No.2
				4043		F5	Reduce lower frequency
				4044		F6	Increase lower frequency
				4041		F7	Reduce upper frequency
				4042	L'W _ W ▶	F8	Increase upper frequency
4048	FFT					F2	FFT setup
		4071	AEx Vx			F3	Link AE source to variable
		4073	RMS			F4	RMS filter setup
		4072	Vx 100%			F5	Full scale of the variable setup
		4076	AE U	4075	AE U	F6	Enable sensor ready check function
		4074	i <b>T</b> irriti			F7	Downsample filter for incremental mode
		4082	No. RMS			F8	Number of samples for RMS input filter



₽ V		V3 8	/4 <sup>■</sup> Commands in Vx	Variable Set	up		
4051	Þ					F5	Reduce frequency of the working window
4052	Δ					F6	Increase frequency of the working window
4053	A -					F4	Working frquency windows gain setup
		4054	A			F1	Reduce gain into working window
		4055	A t			F3	Increase gain into working frequency
		0015	N			F6	Confirm

Comma	nds in Paramet	ter Setup	
0036		F2	Digital interface test
0051	+ A.O. - 010V	F2	010V analog output calibration [Connector B2]

Envelop	nvelope commands in Manual Mode					
0042	RESET	F1	Reset / Enable			
4106 4107		F2	Start process Stop process			
4109 4110		F3	Start learning Stop learning			
4098		F4	Master delete			
4099		F7	Edit mode			



Comma	nds in edit moo	de page		
4104		F1	Move left and select	
4105		F2	Move right and select	
4103		F3	Increase top selected	
4097	₽	F4	Decrease top selected	
4102		F5	Increase bottom selected	
4096	₽	F6	Decrease bottom selected	
4111		E7	Disable selected	
4112	<b>U</b>	Γ/	Enable selected	
4095	₽	F1	Decrease top curve	
4101		F2	Increase top curve	
4094	₽	F3	Decrease bottom curve	
4100		F4	Increase bottom curve	
4114	€	F5	Stretch out	
4113	≠ <u>∭</u> ←	F6	Stretch in	
4115		Shift +	Enable draw mode	
4116		F3	Enable selected mode	
0093	ン	Shift + F5	Undo	
0094	C	Shift + F6	Redo	
4108		Shift + F7	Master save	
0034		F8	Go to next menu	



#### GAUGE [GA type]

#### In-Process Gauging and In-Process Gauging with Roundness Analysis



- A. Current device, Section & Part-Program
- B. Operating mode (Automatic / Manual). Blinks when cycle in progress
- C. Area reserved to status icons.
- D. Ruler
- E. Output signalling F. Graphic area to r
  - Graphic area to rappresent the diagrams of the sources
    - Dimension diagram
      - Output commands status
      - Gauging head status
      - Numerical value of the dimension
      - Numerical value of the programmed offset
      - Rotation speed of the workhead
      - Numerical value of each gauging transducer
- G. Command line, accessible by [Fx] buttons.
- H. Vertical command line, accessible by [Shift+Fx] buttons.







- A. Current device, Section & Part-Program
- B. Operating mode (Automatic / Manual). Blinks when cycle in progress
- C. Area reserved to status icons.
- D. Output signalling
- E. Shape components value F. Graphic area to rappresen
  - Graphic area to rappresent the diagrams of the sources
    - Roundness diagram
      - Output commands status
      - Value of the shape components
      - Rotation speed of the workhead
      - Measuring unit
- G. Command line, accessible by [Fx] buttons.
- H. Vertical command line, accessible by [Shift+Fx] buttons



#### **Pre/Post-Process Gauging**



- A. Current device, Section & Part-Program
- B. Operating mode (Automatic / Manual). Blinks when cycle in progress
- C. Area reserved to status icons.
- D. Dimension index
- E. Output signalling
- F. Graphic area to rappresent dimension, offset, workhead rotation speed and transducers value
- G. Command line, accessible by [Fx] buttons.
- H. Vertical command line, accessible by [Shift+Fx] buttons.



#### Post-Process Roundness & Shape Analysis



- A. Current device, Section & Part-Program
- B. Operating mode (Automatic / Manual). Blinks when cycle in progress
- C. Area reserved to status icons.
- D. Output signalling
- E. Shape components value
- F. Graphic area to rappresent the diagrams of the sources
  - Roundness diagram
    - Output commands status
    - Value of the shape components
    - Rotation speed of the workhead
    - Measuring unit
- G. Command line, accessible by [Fx] buttons.
- H. Vertical command line, accessible by [Shift+Fx] buttons



# Status signalling

		Outp	uts
7036 7033 7030 7027 7039 7045	1 2 3 4 0 A	In-Pr activ	ocess skip commands ated
7038 7035 7032 7029 7041 7047	1 2 3 4 0 A	In-Pr reset	ocess skip commands ted
7062 7065 7068	1 2 3	Post- Rour tolera	Process Gauging or idness components out of ance
7060 7063 7066	1 2 3	Post- Rour tolera	Process Gauging or idness components in ance
7024	τ	Start	cycle delay active
7026	τ	Start	cycle delay expired
7042	D	Dwel	l timer expired
7044	D	Dwel	I timer inactive
7048	Ско	Run-	out out of tolerance
7049	Сок	Run-	out in of tolerance
7050 C Roundne impossib			idness & shape analysis ssible
		Gaug	ing
7012	Þ Ý	Part-	program for in-process
7013	<b>E</b>	Part-	program for post-process
7014		Part-	program for flagging
7015	O	Part- shap	program with roundness & e analysis
7011	JUU	Sync	hronized gauge head
7010	⊘≞±	Corre	ection offset value
7016	, ÎN	Sync	ronized dimension
7001 7002	mil µm	Meas	suring unit: mil or µm
		Dimen	sion
1	→ 0\	/R	Overrange
Ľ	→ M/	AX	Limite max

Transducers					
7017	ŦĮ	Over-range			
7018	ŦŢ	Gauge head on mechanical stopper			
7004	ok □⊐∡	Measuring position OK			
7005	OK □_▼	Retraction OK			
7006		Warning: Retraction impossible			
7007		Warning: Retraction error			
7008		Data hold			
7009		Warning: Retraction error while data hold			
7003		Warning: Gauge head error or fault			
	F	Roundness & Shape			
7051	$\bigcirc$	Roundness error			
7053	$\bigcirc$	Extrenal deviation			
7052	$\bigcirc$	Internal deviation			
7054	$\bigcirc$	Eccentricity			
7055	$\bigcirc$	Ovality			
7056	$\bigcirc$	3-lobes component			
7057	0	4-lobes component			
7058	$\bigcirc$	5-lobes component			
7059	$\bigcirc$	Shape residual			



# Commands

Comma	nds in Automat	tic mode	Ę.	]
6003	⊘≜+	F1	Offset increment	
6002	∅	F2	Offset decrement	
6004	⊘∔	F3	Offset reset	
0057 0058	⊕ <b>∕</b> O <b>∕</b>	F7	Zoom in / Zoom out	
Comma	nds in Manual	mode	d.	9
0042	RESET	F1	Reset / Enable	
6001	⊘≜+	F2	Offset correction setup	
6005	0	F3	Zeroing functions	
6039	Ô	F5	Roundness & shape analysis functions	
6013 6012	62 65	F6	Enable / Disable synchronized gauge head	
0057 0058	⊕ <b>€</b> O <b>€</b>	F7	Zoom in / Zoom out	

<b>O</b> <sub>F</sub>	Roundness		
0047		F1	Start
0048	$\bigcirc$	F1	Stop
0033		F3	Previous
0034		F4	Next
0057	Ð,	F7	Zoom in
0058	Q	F6	Zoom out

0	Zeroing		
6008	\$° 🖉	F1	Mechanical zeroing
6006	<b>→⊘</b> ←	F2	Electrical zeroing
6007	<b>→                                    </b>	F3	Reset electrical zero
6009	+ Ø – MASTER	F4	Master deviation from zero setup













Part program: ROUNDNESS FORMULA
Rnd     =     K     Gx       Image: Second state
The gauging of roundness is defined by setting a formula, of single term, where one of the four transducers is selected (G2, G3, G4, G5). The structure of the formula is as follows:
Rnd = K Gx where x = 2, 3, 4, 5.
the meaning of coefficient K can be summarised: K = Kq Kx (see measure formula). The role of coefficient K is that of weighing up the reading made by the transducer. The coefficient value is normally supplied in the technical sheet for the gauging head, since it depends on the sensitivity and mechanical construction of the transducer.
The value of this coefficient can be set using the previously described procedure for the measure formula.
Example: Formula for finger Lb = 70mm : Rnd = 1.614 G2

	Commands in Gx Transducers setup				
6041 <b></b>	F1	TG200 connect Every time that a gauging head, TG200-LG type, is connected with the system already on, it is necessary to execute the command for it to be acknowledged. In case, after the command, the corresponding configuration parameters are not displayed on the screen, it means the gauge head is not correctly connected or is faulty			

Commands in Parameter Setup				
0036		F2	Digital interface test	



#### GAUGE [NG type]

#### In-Process Gauging and In-Process Gauging with Roundness Analysis



- A. Current device, Section & Part-Program
- B. Operating mode (Automatic / Manual). Blinks when cycle in progress
- C. Area reserved to status icons.
- D. Ruler
- E. Output signalling
- F. Graphic area to rappresent the diagrams of the sources
  - Dimension diagram
  - Output commands status
  - Gauging head status
  - Numerical value of the dimension
  - Numerical value of the programmed offset
  - Rotation speed of the workhead
  - Numerical value of each gauging transducer
- G. Command line, accessible by [Fx] buttons.
- H. Vertical command line, accessible by [Shift+Fx] buttons.
- I. Gauge heads rulers







- A. Current device, Section & Part-Program
- B. Operating mode (Automatic / Manual). Blinks when cycle in progress
- C. Area reserved to status icons.
- D. Output signalling
- E. Shape components value F. Graphic area to rappresen
  - Graphic area to rappresent the diagrams of the sources
    - Roundness diagram
      - Output commands status
      - Value of the shape components
      - Rotation speed of the workhead
      - Measuring unit
- G. Command line, accessible by [Fx] buttons.
- H. Vertical command line, accessible by [Shift+Fx] buttons



#### **Pre/Post-Process Gauging**



- A. Current device, Section & Part-ProgramB. Operating mode (Automatic / Manual). Blinks when cycle in progress
- C. Area reserved to status icons.
- D. Dimension index
- E. Output signalling
- F. Graphic area to rappresent dimension, offset, workhead rotation speed and transducers value
- Command line, accessible by [Fx] buttons. G.
- H. Vertical command line, accessible by [Shift+Fx] buttons.
- I. Gauge heads rulers



#### Post-Process Roundness & Shape Analysis



- A. Current device, Section & Part-Program
- B. Operating mode (Automatic / Manual). Blinks when cycle in progress
- C. Area reserved to status icons.
- D. Output signalling
- E. Shape components value
- F. Graphic area to rappresent the diagrams of the sources
  - Roundness diagram
    - Output commands status
    - Value of the shape components
    - Rotation speed of the workhead
    - Measuring unit
- G. Command line, accessible by [Fx] buttons.
- H. Vertical command line, accessible by [Shift+Fx] buttons



# Status signalling

		Outp	uts		
7036 7033 7030 7027 7039 7045	1 2 3 4 0 A	In-Pr activ	ocess skip commands ated		
7038 7035 7032 7029 7041 7047	1 2 3 4 0 A	In-Pr reset	ocess skip commands ted		
7062 7065 7068	12 3	Post- Rour tolera	Process Gauging or idness components out of ance		
7060 7063 7066	12 3	Post- Rour tolera	Process Gauging or idness components in ance		
7024	τ	Start	cycle delay active		
7026	τ	Start	cycle delay expired		
7042	D	Dwel	I timer expired		
7044	D	Dwel	I timer inactive		
7048	Ско	Run-	out out of tolerance		
7049	Сок	Run-	out in of tolerance		
7050		Rour impo	ndness & shape analysis ssible		
Gauging					
7012	Þ Ý	Part-	program for in-process		
7013	<b>E</b>	Part-	program for post-process		
7014		Part-	program for flagging		
7015	O	Part- shap	program with roundness & e analysis		
7011	JUU	Sync	hronized gauge head		
7010	⊘≞±	Corre	ection offset value		
7016	, ÎN	Sync	ronized dimension		
7001 7002	mil µm	Meas	suring unit: mil or µm		
		Dimen	sion		
ļ	) O\	/R	Overrange		
ļ	→ M/	AX	Limite max		

Transducers			
7017	ŦĮ	Over-range	
7018	ŦŢ	Gauge head on mechanical stopper	
7004	ок □-∡	Measuring position OK	
7005	OK □_▼	Retraction OK	
7006		Warning: Retraction impossible	
7007		Warning: Retraction error	
7008		Data hold	
7009		Warning: Retraction error while data hold	
7003		Warning: Gauge head error or fault	
	F	Roundness & Shape	
7051	$\bigcirc$	Roundness error	
7053	$\bigcirc$	Extrenal deviation	
7052	$\bigcirc$	Internal deviation	
7054	$\bigcirc$	Eccentricity	
7055	$\bigcirc$	Ovality	
7056	$\bigcirc$	3-lobes component	
7057	0	4-lobes component	
7058	$\bigcirc$	5-lobes component	
7059	$\bigcirc$	Shape residual	



# Commands

Comma	Commands in Automatic mode				
6003	⊘≜+	F1	Offset increment		
6002	∅	F2	Offset decrement		
6004	⊘	F3	Offset reset		
0057 0058	⊕ <b>∕</b> O <b>∕</b>	F7	Zoom in / Zoom out		
Comma	nds in Manual	mode	d"	5	
0042	RESET	F1	Reset / Enable		
6001	⊘≜+	F2	Offset correction setup		
6005	$\oslash$	F3	Zeroing functions		
6039	Ô	F5	Roundness & shape analysis functions		
6013 6012	62 65	F6	Enable / Disable synchronized gauge head		
0057 0058	⊕ <b>€</b> O <b>€</b>	F7	Zoom in / Zoom out		

© Roundness					
0047		F1	Start		
0048	$\bigcirc$	F1	Stop		
0033		F3	Previous		
0034		F4	Next		
0057	Ð,	F7	Zoom in		
0058	Q	F6	Zoom out		

0	Zeroing		
6008	₽Ø	F1	Mechanical zeroing
6006	<b>→⊘</b> ←	F2	Electrical zeroing
6007	<b>→</b> ←	F3	Reset electrical zero
6009	+ Ø – MASTER	F4	Master deviation from zero setup













Part program: ROUNDNESS FORMULA				
Rnd       =       K       Gx         Image: Second state sta				
The gauging of roundness is defined by setting a formula, of single term, where one of the four transducers is selected (G2, G3, G4, G5). The structure of the formula is as follows:				
<b>Rnd = K Gx</b> where $x = 2, 3, 4, 5$ .				
the meaning of coefficient K can be summarised: K = Kq Kx (see measure formula). The role of coefficient K is that of weighing up the reading made by the transducer. The coefficient value is normally supplied in the technical sheet for the gauging head, since it depends on the sensitivity and mechanical construction of the transducer.				
The value of this coefficient can be set using the previously described procedure for the measure formula.				
Example: Formula for finger Lb = 70mm : Rnd = 1.614 G2				

Commands in Gx Transducers setup				
6041 <b></b>	F1	TG200 connect Every time that a gauging head, TG200-LG type, is connected with the system already on, it is necessary to execute the command for it to be acknowledged. In case, after the command, the corresponding configuration parameters are not displayed on the screen, it means the gauge head is not correctly connected or is faulty		

Commands in Parameter Setup				
0036		F2	Digital interface test	