In the 1NCE Customer Portal, configure your account and user

Manage new and existing **Users** of the Customer Portal like Owner, Admin, User, API.

Set **monthly limits** for your data and SMS usage.

Configure **SMS Forwarding** to forward mobile originated SMS towards a configurable IP/URL.

Secure your SIM with an **IMEI lock** so that the SIM can only be used with one specific device.

Administer **Organisations** to assign SIM cards between different sub-orgs.

Implement an **Open VPN** for a secure tunnel between the 1NCE network and your own environment.

Find all details in the 1NCE Documentation at help.1nce.com