

1

ARMADIO 1.1
S1.1 PR1/SP1

PR1/SP1 CONSOLE
PR1/SP1 PULT

	1	
1M2	2	
1M2	3	
1M2	4	
1P1010	5	
1P1020	6	
1P1070	7	
1P1080	8	
1P2040	9	
31402	10	
31403	11	
A31.0	12	
	13	
	14	
	15	
	16	
	17	
	18	
	19	
	20	
31506	21	
31509	22	
31004	23	
31005	24	

	1	
1M2	2	
1M2	3	
1M2	4	
1P1010	5	
1P1020	6	
1P1070	7	
1P1080	8	
1P2040	9	
31402	10	
31403	11	
A31.0	12	
	13	
	14	
	15	
	16	
	17	
	18	
	19	
	20	
31506	21	
31509	22	
31004	23	
31005	24	

PR2/SP2

	1	
1M2	2	
1M2	3	
1M2	4	
1M2	5	
1M2	6	
1P2091	7	
1P2102	8	
1P2111	9	
1P2121	10	
1P2132	11	
1P2142	12	
1P2152	13	
1P2162	14	
102002	15	
	16	
06001	17	
06003	18	
33001	19	
33002	20	
33003	21	
33004	22	
33005	23	
33006	24	

PR2/SP2

	1	
1M2	2	
1M2	3	
1M2	4	
1M2	5	
1M2	6	
1P2091	7	
1P2102	8	
1P2111	9	
1P2121	10	
1P2132	11	
1P2142	12	
1P2152	13	
1P2162	14	
102002	15	
	16	
06001	17	
06003	18	
33001	19	
33002	20	
33003	21	
33004	22	
33005	23	
33006	24	

FMA

DIS. N. 31239.11863

MACCHINA/IMPIANTO : FMA 453

CAD 'Autocad 10 LAVORAZIONE : ALBERO MOTORE

ORDINE : 30.007629

SCHEMA DI MORSE CONN.

FUGLID 1

N. FILE : 16B1K

DENOMINAZIONE : TRASFERITA

ESECUTORE : TP/BR

SCHEMA DI MORSE CONN.

UNITA 16B

SEQUE

ARMADIO 1.1