

FC31 - <offline>

"Ausgaenge"

Nome:
Autore:
Famiglia:
Versione: 0.1
Versione blocco: 2
Data e ora Codice: 10/04/2013 10.54.53
Interfaccia: 13/12/2006 08.55.10
Lunghezze (blocco / codice / dati): 00190 00098 00000

Nome	Tipo di dati	Indirizzo	Commento
IN		0.0	
OUT		0.0	
IN_OUT		0.0	
TEMP		0.0	
RETURN		0.0	
RET_VAL		0.0	

Blocco: FC31 Ausgaenge rangieren

Segmento: 1 Ausgaenge rangieren
--

```

U      "AM LM-Stoer"           M30.0
=      "LM-Stoer"             A0.1
U      "AM LM-Auto"           M30.1
=      "LM-Autom"             A0.0
U      "AM Reset-Not-Aus"     M30.2
=      "SB Reset-Not-Aus"     A0.6
U      "OUT-> CrusherREADY"   M10.0
=      "SST-Startbereit"     A0.2
U      "AM SStelle-Stoer-Frei" M30.3
=      "SB SStelle-Stoer-Frei" A0.4
U      "AM SStelle-Freigabe Mat" M30.4
=      "SB SStelle-Freigabe Mat" A0.3
U      "AM Reset-Stillstand"   M30.5
=      "SB Reset-Stillstand"   A0.5
U      "AM Hydr_Pumpe"        M31.0
=      "SB Hydr-Pumpe"        A1.0
U      "AM Druckaufb.A"       M32.0
=      "SB Druckaufb.A"       A4.0
U      "AM Druckaufb.B"       M34.0
=      "SB Druckaufb.B"       A4.1
U      "AM VP-Y-A"            M32.1
=      "SB VP Y-A"            A4.2
U      "AM VP-Y-B"            M34.1
=      "SB VP Y-B"            A4.6

U      "AM HP-Y-A"            M32.2
=      "SB HP Y-A"            A4.4
U      "AM HP-Y-B"            M34.2
=      "SB HP Y-B"            A4.5

// nur Platzhalter !!
U      "AM MB-Y-A"            M32.3
=      "AM MB-Y-A"            M32.3
U      "AM MB-Y-B"            M34.3
=      "AM MB-Y-B"            M34.3
U      "AM MBv-Y-A"           M32.4
=      "AM MBv-Y-A"           M32.4
U      "AM MBv-Y-B"           M34.4
=      "AM MBv-Y-B"           M34.4

U      "AM V-Klappt-Y-A"       M32.5
=      "SB V-Klappt-Y-A"       A5.4
U      "AM V-Klappt-Y-B"       M34.5
=      "SB V-Klappt-Y-B"       A5.5
U      "AM Einl-Boden-Y-A"     M32.7
=      "SB-Einl-Boden-Y-A"     A5.6
U      "AM Einl-Boden-Y-B"     M34.7
=      "SB-Einl-Boden-Y-B"     A5.7

```

```

// nur Platzhalter !!

```

U	"AM RT-Drehv-A"	M33.0
=	"AM RT-Drehv-A"	M33.0
U	"AM RT-Drehv-B"	M35.0
=	"AM RT-Drehv-B"	M35.0